



DTS1 CSfC

1-Slot Data Transport System (CSfC)

User Guide

Part Number: DDOC0099-000-B4

This Page Intentionally Left Blank

Front Matter

Revisions

Document Number	Media	Revision	Date	Description	PCN
DDOC0099-000	PDF	A1	07/17/18	Multiple updates.	1227
DDOC0099-000	PDF	A2	08/14/18	Multiple updates.	0818-0001
DDOC0099-000	PDF	A3	10/01/18	Multiple updates.	1018-0001
DDOC0099-000	PDF	A4	11/01/18	Multiple updates.	1118-0001
DDOC0099-000	PDF	A5	01/22/19	Multiple updates.	0119-0001
DDOC0099-000	PDF	A6	04/24/19	Conversion to new format.	0419-0001
DDOC0099-000	PDF	A7	05/15/19	Corrected as noted by change bars.	0519-0005
DDOC0099-000	PDF	A8	08/15/19	Corrected as noted by change bars.	0819-0005
DDOC0099-000	PDF	A9	09/03/19	Removed references to RUGS-E system	0919-0001
DDOC0099-000	PDF	AA	09/19/19	Revised encryption password / passphrase requirements.	0919-0005
DDOC0099-000	PDF	AB	10/25/19	Revised to include video stream capture. Additional revisions / corrections as noted by change bars.	1019-0014
DDOC0099-000	PDF	AC	3/27/20	Revised format and style of illustrations and tables. Technical changes incorporated as noted by change bars.	0320-0012
DDOC0099-000	PDF	AD	4/9/20	Deleted VS-RMC-003 RMC, 1 TB and Secure Erase from Appendix C	0420-0004
DDOC0099-000	PDF	AE	5/8/20	Corrected as noted by change bars.	0520-0003
DDOC0099-000	PDF	AF	6/2/20	Corrected as noted by change bars.	0620-0003
DDOC0099-000	PDF	AG	6/8/20	Update istarget information. Corrected as noted by change bars.	0620-0005
DDOC0099-000	PDF	AH	6/29/20	Add Quick Start section. All other corrections / updates noted by change bars.	0620-0012
DDOC0099-000	PDF	AI	8/26/20	Corrected as noted by change bars.	0820-0004
DDOC0099-000	PDF	AJ	9/15/20	Add cmlog command to CLI. Corrected as noted by change bars.	0920-0005
DDOC0099-000	PDF	AK	9/30/20	Add 8 TB RMC.	0920-0007
DDOC0099-000	PDF	AL	11/5/20	Updated as noted by change bars.	1120-0004
DDOC0099-000	PDF	AM	01/28/21	Updated as noted by change bars.	0121-0008
DDOC0099-000	PDF	AN	03/24/21	Updated as noted by change bars.	0321-0007
DDOC0099-000	PDF	AO	04/05/21	Updated as noted by change bars.	0421-0001
DDOC0099-000	PDF	AP	05/11/21	Updated as noted by change bars.	0521-0003
DDOC0099-000	PDF	AQ	07/06/21	Updated as noted by change bars.	0721-0007
DDOC0099-000	PDF	AR	11/18/21	Updated as noted by change bars.	1121-0007
DDOC0099-000	PDF	AS	01/24/22	Updated as noted by change bars.	0122-0007

Document Number	Media	Revision	Date	Description	PCN
DDOC0099-000	PDF	AT	03/02/22	Remove Proprietary notification.	0322-0002
DDOC0099-000	PDF	AU	03/09/22	Updated as noted by change bars.	0322-0008
DDOC0099-000	PDF	AV	04/28/22	Update rmcfree CLI command information.	0422-0020
DDOC0099-000	PDF	AX	07/26/22	Update ground cable installation information.	0722-0003
DDOC0099-000	PDF	AY	07/29/22	Add nfscfl CLI command information and revised as noted by change bars.	0722-0005
DDOC0099-000	PDF	AZ	09/16/22	Updated as noted by change bars.	0922-0010
DDOC0099-000	PDF	B1	11/18/22	Updated as noted by change bars.	1122-0004
DDOC0099-000	PDF	B2	02/13/22	Deleted paragraph in paragraph 2.2 Protocols .	0223-0004
DDOC0099-000	PDF	B3	03/10/23	Updated as noted by change bars.	0323-0005
DDOC0099-000	PDF	B4	03/21/23	Updated as noted by change bars.	0323-0008

The Curtiss-Wright 1-Slot Data Transport System (CSfC) User Guide (DDOC0099-000) is made up of the following individual chapters and appendices.

Chapter / Appendix	Topic	Content Revision
1.0	Introduction section	3.0
2.0	Overview section	10.0
3.0	Controls and Indicators section	4.0
4.0	Installation section	5.0
5.0	Encryption section	10.0
6.0	Quick Start section	4.0
7.0	Operation section	7.0
8.0	System Configuration section	1.0
9.0	Troubleshooting section	0.0
10.0	Remove / Replace section	6.0
11.0	Simple Network Management Protocol section	1.0
12.0	Command Line Interface section	13.0
A	Specifications section	7.0
B	Connectors / Cables section	4.0
C	Ordering Information section	5.0

Changes to technical content are shown through the use of change bars placed in the left margin next to the changed material (as shown here). Corrections to typographical errors are not noted unless they significantly impact the content.

Copyright

All content in this User Guide (DDOC0099-000-B4) is copyrighted by Curtiss-Wright Defense Solutions.

Safety

WARNING

HAZARD. A potential hazard that could result in serious injury or death.

Information contained in **WARNINGS** applies to dangers and hazards that may result in injury and / or death to personnel. The actual hazard is provided in **CAPITALIZED** letters and the information that mitigates the danger is provided in sentence case. This information typically precedes procedural steps. It also may be present in narrative text to warn operators or maintenance personnel of dangers present in the equipment.

CAUTION

HAZARD. A potential hazard that could result in equipment damage or improper operation.

Information contained in **CAUTIONS** applies to dangers and hazards that may result in damage to equipment or improper operation. The actual hazard is provided in **CAPITALIZED** letters and the information that mitigates the danger is provided in sentence case. This information typically precedes procedural steps. It also may be present in narrative text to warn operators or maintenance personnel of dangers present in the equipment.

NOTE

Amplifying information that helps in making a task or procedure more easily understood.

NOTES are used to supply amplifying information that will result in ease of testing or be beneficial to personnel. This information typically precedes procedural steps. It also may be present in narrative text as well.

Style and Conventions

This User Guide uses the following typographical conventions.

This style	Refers to
Ready	Text the software displays.
go	Anything you type, exactly as it appears, whether referenced in text or at a prompt.
ENTER	Special keys on the keyboard, such as enter, alt, and spacebar.
Save	Software command buttons and sections of dialog boxes, such as group boxes, text boxes, and text fields.
File → Open	A menu and a specific menu command.
ALT+F1	Pressing more than one key at the same time.
ALT, TAB	Pressing more than one key in sequence.
xx,yy	Variable in error messages and text.
jobfile.dat	File names.
◆	Denotes the result of an action or procedure.
xyz	Hyperlink.
STOP	Controls on equipment.

Table of Contents

Introduction

1.1 Purpose	1-1
1.2 Scope	1-1
1.3 Quality	1-1
1.4 CE Conformity	1-2
1.4.1 DTS1	1-2
1.4.2 RMC	1-2
1.5 Related Information	1-2
1.6 Technical Support.....	1-2
1.7 Ordering Process.....	1-3

Overview

2.1 Description.....	2-1
2.1.1 Chassis	2-1
2.1.2 RMC Module	2-3
2.2 Protocols.....	2-3
2.3 CSfC Encryption	2-4
2.3.1 Hardware Encryption Layer	2-4
2.3.1.1 Account Creation	2-4
2.3.1.2 Account Login	2-5
2.3.2 Software Encryption Layer	2-5
2.3.3 Zeroize	2-6
2.4 Features	2-6

Controls and Indicators

3.1 Chassis Indicators	3-1
3.1.1 POWER LED	3-1
3.1.2 FAULT LED	3-1
3.1.3 KEY LOADED LED	3-1
3.1.4 DRIVE CAPACITY LEDs	3-1
3.2 Chassis Controls	3-2
3.2.1 Key Clear Button	3-2
3.2.2 Write-Enable Switch	3-2
3.3 RMC Module Controls / Indications	3-3
3.3.1 STATUS LED (Green / Left)	3-3
3.3.2 ACTIVITY LED (Green / Middle)	3-3
3.3.3 FAULT LED	3-3
3.3.4 Removal Request Button	3-4

Installation

4.1 Package.....	4-1
4.2 Inspection	4-1
4.3 Mounting.....	4-2
4.4 Cables	4-3
4.4.1 Power Cable	4-3
4.4.2 Utility Cable	4-4

4.4.3 Ethernet Cable 4-4

4.4.4 Ground Cable 4-5

Encryption

5.1 Passwords / Passphrases 5-1

5.1.1 Hardware Layer Passwords 5-1

5.1.2 Software Layer Passwords / Passphrases 5-1

5.1.3 Incorrect Password / Passphrase Entered 5-1

5.1.4 Change Password / Passphrase 5-1

5.2 Check Hardware Layer Status 5-2

5.2.1 Hardware Layer Definitions 5-2

5.3 Hardware Layer Encryption 5-3

5.3.1 Initialize / Login - Crypto Module 5-3

5.3.2 Verify Successful Login 5-4

5.3.3 Access RMC Module (Plain Text DEK / Encrypted DEK) 5-4

5.3.3.1 Access RMC Module (Plain Text DEK) 5-4

5.3.3.2 Access RMC Module (EDEK) 5-5

5.3.4 Hardware Encryption Key Storage 5-5

5.4 Software Layer Encryption 5-5

5.4.1 Unpartitioned Disk 5-5

5.4.1.1 Initialize Container (Unpartitioned Disk) 5-6

5.4.1.2 Open SWE Container (Unpartitioned Disk) 5-6

5.4.1.3 Format / Mount SWE Container (Unpartitioned Disk) 5-6

5.4.1.4 Close SWE Container (Unpartitioned Disk) 5-7

5.4.1.5 Delete SWE Container (Unpartitioned Disk) 5-7

5.4.2 Partitions 5-7

5.4.2.1 Initialize SWE Containers (Partitions - Different Passphrases) 5-8

5.4.2.2 Open SWE Container (Partitions - Different Passphrases) 5-8

5.4.2.3 Initialize SWE Encryption (Partitions - Same Passphrase) 5-9

5.4.2.4 Open SWE Container (Partition - Same Passphrase) 5-10

5.4.2.5 Format / Mount SWE Containers (Individual Partitions) 5-10

5.4.2.6 Format / Mount SWE Containers (All Partitions) 5-11

5.4.2.7 Close SWE Containers (Individual Partitions) 5-11

5.4.2.8 Close SWE Container (All Partitions) 5-11

5.4.2.9 Delete SWE Container (Individual Partitions) 5-12

5.4.2.10 Delete SWE Containers (All Partitions) 5-12

5.5 Zeroize HWE Key / Delete SWE Container / RMC Purge 5-12

5.5.1 Zeroize HWE Key 5-12

5.5.2 Delete SWE Container 5-13

5.5.3 RMC Purge 5-13

Quick Start

6.1 Connections / Preparation 6-1

6.2 Preparation (Initialization Procedure Only) 6-1

6.3 Initialization 6-2

6.4 Login 6-5

Operation

7.1 Setup / Connections 7-1

7.2 Basic Operation 7-2

7.2.1 Communications 7-2

- 7.2.1.1 Terminal Emulation 7-2
- 7.2.1.2 Ethernet 7-3
- 7.2.2 IP Address 7-4
- 7.2.3 Account Management 7-4
- 7.2.4 Passwords 7-4
- 7.2.5 Time / Date 7-5
- 7.3 Login 7-5
- 7.4 Encryption 7-6
 - 7.4.1 Hardware Encryption Layer 7-6
 - 7.4.2 Software Encryption Layer 7-6
 - 7.4.3 Zeroize / Delete SWE Container / RMC Purge 7-6
- 7.5 Storage Media 7-6
 - 7.5.1 Preparation for Partition 7-6
 - 7.5.2 Partition Disk 7-7
 - 7.5.3 Services 7-8
 - 7.5.3.1 Assign Services 7-8
 - 7.5.3.2 Boot Services 7-9
 - 7.5.3.3 Restart Services 7-9
 - 7.5.4 Assign Mount Point Names 7-10
 - 7.5.5 Format / Mount 7-11
 - 7.5.5.1 Format Only 7-11
 - 7.5.5.2 Format / Mount 7-12
 - 7.5.6 iSCSI 7-14
- 7.6 PCAP 7-15
- 7.7 Health 7-16
 - 7.7.1 Sens 7-16
- 7.8 Built In Test 7-17
 - 7.8.1 IBIT (Initiated BIT) 7-17
 - 7.8.2 MBIT (Maintenance BIT) 7-17
- 7.9 Update Software / Firmware 7-18
 - 7.9.1 Update Operating System Software 7-18
 - 7.9.2 Update Crypto Firmware 7-19
- 7.10 Access from Windows as NAS Device 7-20
- 7.11 Access from Linux as NAS Device 7-20

System Configuration

- 8.1 Crypto Module 8-1
 - 8.1.1 Initialize / Log In 8-1
 - 8.1.2 Key Load / Unload 8-1
 - 8.1.3 Key Removal / Zeroize 8-1
 - 8.1.4 Key Commands 8-1
- 8.2 DTS1 8-1
 - 8.2.1 **Versions** 8-2
 - 8.2.2 Configure 8-2
- 8.3 RMC Module 8-2
 - 8.3.1 RMCCTL Definitions 8-2
 - 8.3.2 Configure 8-3
 - 8.3.3 Encrypt / Decrypt 8-3
 - 8.3.4 Insert / Remove 8-3

8.3.5 Service	8-3
Troubleshooting	
9.1 Chassis LED Fault Indicators	9-1
9.2 RMC Module LED Fault Indications	9-1
9.3 Encryptor Error Codes	9-2
Remove / Replace	
10.1 RMC Module.....	10-1
10.1.1 Install	10-1
10.1.2 Remove	10-2
10.2 Battery	10-2
Simple Network Management Protocol	
11.1 SNMP MIB.....	11-1
Command Line Interface	
12.1 DTS1	12-1
12.2 RMC Module.....	12-1
12.3 Commands	12-1
12.3.1 amnt	12-2
12.3.2 cmfwupdate	12-4
12.3.3 cmkey	12-5
12.3.4 cmlog	12-8
12.3.5 cmlogin	12-9
12.3.6 dhcpconfig	12-11
12.3.7 fdefaults	12-13
12.3.8 fupdate	12-14
12.3.9 fwall	12-15
12.3.10 help	12-17
12.3.11 ibit	12-18
12.3.12 info	12-19
12.3.13 ipconfig	12-21
12.3.14 istarget	12-23
12.3.15 ledctrl	12-25
12.3.16 log	12-26
12.3.17 mbit	12-27
12.3.18 nfsctl	12-29
12.3.19 ntpdate	12-30
12.3.20 password	12-32
12.3.21 pcap	12-33
12.3.22 reboot	12-34
12.3.23 rmcctl	12-35
12.3.24 rmcfree	12-38
12.3.25 rmcinfo	12-39
12.3.26 rmcpurge	12-41
12.3.27 rtp	12-42
12.3.28 sens	12-44
12.3.29 serv	12-45
12.3.30 shutdown	12-47
12.3.31 sysdate	12-48

Specifications

A.1 Envelope / Mounting Dimensions.....A-1
 A.1.1 RMC ModuleA-1
 A.1.2 Panel MountA-2
 A.1.3 DZUS Fastener MountA-3
A.2 DTS1 Specifications.....A-4
A.3 RMC Module Specifications.....A-4
A.4 Mean Time Between FailuresA-4
A.5 Environmental, EMI, Electrical SpecificationsA-5

Connectors / Cables

B.1 Power Connector J1 / Power Lab CableB-1
B.2 Utility Connector J2 / Utility Lab Cable.....B-2
B.3 Ethernet Connector J3 / Ethernet Lab CableB-3
B.4 Ground Cable.....B-5

Ordering Information

C.1 DTS1 / RMC Module / Lab Cables.....C-1

List of Figures

Figure 2.1	DTS1.....	2 - 1
Figure 2.2	DTS1 Chassis / Components	2 - 2
Figure 2.3	DTS1 Rear Panel / Battery Access Cover and Rear Connectors.....	2 - 2
Figure 2.4	DTS1 Processor Carrier PCB Programming Connector / Write-Enable Switch	2 - 3
Figure 2.5	DTS1 With RMC Module	2 - 3
Figure 2.6	Hardware Encryption Layer Account Creation.....	2 - 4
Figure 2.7	Hardware Encryption Layer Account Login	2 - 5
Figure 3.1	DTS1 Controls / Indicators.....	3 - 1
Figure 3.2	Remaining Disk Capacity Indicators	3 - 2
Figure 3.3	DTS1 Write-Enable Switch	3 - 2
Figure 3.4	RMC Module Controls / Indicators.....	3 - 3
Figure 4.1	DTS1 Chassis Anti-Tamper Label Locations.....	4 - 1
Figure 4.2	RMC Module Anti-Tamper Label Location.....	4 - 2
Figure 4.3	DTS1 Chassis Mounting	4 - 2
Figure 4.4	DTS1 Required Door Clearance.....	4 - 3
Figure 4.5	DTS1 Rear Panel Connectors	4 - 3
Figure 4.6	Power Lab Cable	4 - 3
Figure 4.7	Utility Lab Cable.....	4 - 4
Figure 4.8	Ethernet Lab Cable.....	4 - 4
Figure 4.9	DTS1 Ground Connection	4 - 5
Figure 6.1	Initialization Overview Flowchart	6 - 3
Figure 6.2	Login Overview Flowchart	6 - 5
Figure 7.1	DTS1 Test Setup	7 - 1
Figure 7.2	PuTTY Terminal Emulator (Serial Data).....	7 - 2
Figure 7.3	PuTTY Terminal Emulator (SSH)	7 - 3
Figure 7.4	DTS1 Update Utility	7 - 19
Figure 10.1	RMC Module Install / Remove.....	10 - 1
Figure 10.2	Battery Assembly Replacement.....	10 - 3
Figure 10.3	Battery Access Panel Screws Tightening Sequence.....	10 - 3
Figure A.1	RMC Module.....	A - 1
Figure A.2	DTS1 (Panel Mount).....	A - 2
Figure A.3	DTS1 (Dzus Mount).....	A - 3
Figure B.1	Power Connector J1	B - 1
Figure B.2	Power Lab Cable Diagram.....	B - 2
Figure B.3	Utility Connector J2.....	B - 3
Figure B.4	Utility Lab Cable Diagram	B - 3
Figure B.5	Ethernet Connector J3.....	B - 4
Figure B.6	Ethernet Lab Cable Wiring Diagram	B - 5
Figure B.7	DTS1 Ground Connection	B - 5

List of Tables

Table 3.1	RMC Module STATUS LED Indications	3-3
Table 7.1	Ethernet Interfaces	7-2
Table 9.1	Chassis LED Fault Indications	9-1
Table 9.2	RMC Module LED Fault Indications	9-2
Table 9.3	Encryptor Error Codes.....	9-2
Table 10.1	Consumable Materials.....	10-2
Table A.1	DTS1 / RMC Calculated Mean Time Between Failures	A-4
Table B.1	Power Connector J1 Signals	B-1
Table B.2	Power Lab Cable (VS-DTS1PWRCAB-0)	B-1
Table B.3	Utility Connector J2 Signals	B-2
Table B.4	Utility Lab Cable (VS-DTS1ETHCAB-J2)	B-3
Table B.5	Ethernet Connector J3 Signals.....	B-4
Table B.6	Ethernet Lab Cable (VS-DTS1ETHCAB-J3)	B-4
Table C.1	DTS1 CSfC Chassis	C-1
Table C.2	RMC Module	C-1
Table C.3	DTS1 Lab Cables	C-1
Table C.4	DTS1 Battery	C-1

Introduction

1.1 Purpose

The purpose of this guide is to describe the Curtiss-Wright Data Transport System 1-slot (DTS1) LRU (Line Replaceable Unit) product and to guide users through the process of unpacking, installing, configuring, and using. The unit requires the use of a Removable Memory Cartridge (RMC) module. From this point forward, the product will be referred to as the DTS1 and the associated cartridge will be referred to as the RMC module.

1.2 Scope

The information in this user guide is intended for information systems personnel, systems coordinators, or highly skilled network users. This manual contains the following information:

- An overview of the DTS1.
- Unpacking, installation, and setup information.
- User interface connections.
- User input.
- Configuration options.
- Product specifications.
- Operation requirements.
- Environmental restrictions.
- Connector pinout and specifications.
- Ordering information for related products and parts

1.3 Quality

Curtiss-Wright Controls, Inc., Electronic Systems is committed to leveraging our technology leadership to deliver products and services that meet or exceed customer requirements. In addition to the physical product, the company provides documentation, sales and marketing support, hardware and software technical support, and timely product delivery. Our quality commitment begins with product concept and continues after receipt of the purchased product.

Curtiss-Wright Controls, Inc., Electronic Systems' Quality Management System is accredited to the latest revision of the aerospace standard, AS9100 Quality Management Systems - Requirements for Aviation, Space, and Defense Organizations.

Our Quality System addresses the following basic objectives:

- Achieve, maintain, and continually improve the quality of our products and service through established design, test, production and service procedures.
- Improve the quality of our operations to meet the needs of our customers, suppliers, and other stakeholders.
- Provide our employees with the tools and overall work environment to fulfill, maintain, and improve product and service quality.
- Ensure our customer and other stakeholders that only the highest quality product or service will be delivered.

Eagle Registrations Inc. assessed Curtiss-Wright's Quality Management System and confirmed conformance to AS9100D including ISO 9001:2015 with Certificate No. 5819. The scope of the registration is as follows: "Design manufacture, test and repair of board level products, electronic sub-systems, related software and services for commercial, aerospace and military applications."

Customer feedback is integral to our quality and reliability program. We encourage customers to contact us with questions, suggestions, or comments regarding any of our products or services. We guarantee professional and quick responses to your questions, comments, or problems.

1.4 CE Conformity

1.4.1 DTS1

Curtiss-Wright certifies, in accordance with directives 0214/30/EU, 2011/65/EU, and 2006/1907/EC, the following units:

- VS-DTS1-F
- VS-DTS1-FD

conform to the applicable requirements of EN 55022, EN 55024, EN 50581, and EN 62368-1.

1.4.2 RMC

Curtiss-Wright certifies, in accordance with directives 0214/30/EU, 2011/65/EU, and 2006/1907/EC, the following units:

- VS-RMC256M-00
- VS-RMC1024M-00
- VS-RMC2048M-00
- VS-RMC4096M-00
- VS-RMC8192M-00

conform to the applicable requirements of EN 55022, EN 55024, EN 50581, and EN 62368-1.

1.5 Related Information

- AES (Advanced Encryption Standard). <https://nvlpubs.nist.gov/nistpubs/FIPS/NIST.FIPS.197.pdf>
- EIA-232 RS-232 electrical characteristics single-ended voltage digital interface circuit. <http://www.eia.org/>
- VITA 46, 47, 48, and 58. <https://www.vita.com/Standards>
- FIPS 140-3. <https://csrc.nist.gov/publications/detail/fips/140/3/final>
- EMI Mil-Std-461
- NAS, <http://www.pdl.cmu.edu/PDL-FTP/NASD/hotnet99.pdf>
- Ruggedization, Curtiss-Wright, www.cwcdefense.com
- Curtiss-Wright Controls Defense Solutions www.cwcdefense.com
- PuTTY User Manual (client program for SSH, Telnet, and R login network protocols).
- MIL-STD-704F Department of Defense Interface Standard, Aircraft Electric Power Characteristics.
- MIL-HDBK-704-8 Guidance For Test Procedures For Demonstration Of Utilization Equipment
- Compliance To Aircraft Electrical Power Characteristics 28 VDC
- 0214/30/EU Electromagnetic Compatibility Directive
- 2011/65/EU RoHS Directive
- 2006/1907/EC REACH Directive
- EN 55022 Information Technology Equipment-Radio Disturbance Characteristics (2010)
- EN 55024 Information Technology Equipment-Immunity Characteristics Limits (2010)
- EN 50581 Technical Documentation for the Assessment of Electrical and Electronic Products with Respect to the Restriction of Hazardous Substances (2012)
- EN 62368-1 Audio/Video, Information and Communication Technology Equipment (2014)

1.6 Technical Support

Technical documentation is provided with all of our products. This documentation describes the technology, its performance characteristics, and includes some typical applications. It also includes comprehensive support information, designed to answer any technical questions that might arise concerning the use of this product. We also publish and distribute technical briefs and application notes that cover a wide assortment of topics. Although we try to tailor the applications to real scenarios, not all possible circumstances are covered.

While we have attempted to make this document comprehensive, you may have specific problems or issues this document does not satisfactorily cover. Our goal is to offer a combination of products and services that provide complete, easy-to-use solutions for your application.

If you have any technical or non-technical questions or comments, contact us. Hours of operation are from 8:00 a.m. to 5:00 p.m. Eastern Standard/Daylight Time.

- Phone: (937) 252-5601 or (800) 252-5601
- E-mail: DTN_support@curtisswright.com
- Fax: (937) 252-1465
- World Wide Web address: www.cwcdefense.com

1.7 Ordering Process

To learn more about Curtiss-Wright Defense Solutions' products or to place an order, please use the following contact information.

- E-mail: DTN_info@curtisswright.com
- World Wide Web address: <http://www.cwcdefense.com/>

To contact a local Curtiss-Wright sales representative go to: <http://www.cwcdefense.com/sales.html> and point to your location on the map presented, then click on the pop-up with the sales representative's name.

Overview

2.1 Description

The Curtiss-Wright DTS1 (Figure 2.1) is a rugged Network Attached Storage (NAS) device with solid state storage capacities from 256 GB up to 8 TB. The DTS1 provides data storage to assorted network clients via two IEEE 802.3 / 802.3u / 802.3ab Ethernet ports. The DTS1 is a ruggedized unit designed to operate on vehicles, in field stations, or in laboratories.

The DTS1 is configured/controlled through a Command Line Interface (CLI) via RS-232 or Ethernet (Telnet or SSH). The CLI utilizes Curtiss-Wright's proprietary command structure, which includes built in Help. The DTS1 uses the Commercial Solutions for Classified (CSfC) specification and associated dual layer data security system to provide a NSA-acceptable data encryption method. Data is encrypted by hardware and software to fulfill the CSfC dual layer requirements.




Figure 2.1 DTS1


2.1.1 Chassis

The chassis (Figure 2.2) is made up of the following major assemblies:

- RMC Module Mount
- Backplane PCB
- Power Supply PCB
- Processor Carrier PCB
- Mini Comm PCB
- USB Flash Module

It also contains a battery used to power the EPROM that stores the encryption key.

The RMC module mount positions the RMC module in the chassis. The backplane is used to interface the RMC module to the processor carrier PCB. The mini comm PCB is the primary assembly in the unit. It contains the processor / CPU, memory, and the encryption circuitry. The processor carrier PCB is used to interface the mini comm PCB to the rest of the system. It also has the utility (J2) and Ethernet (J3) connectors installed on it. The power supply assembly takes the 28 VDC input power, cleans and conditions it, and then distributes it to the entire system.




DDOC0099-0043

Figure 2.2 DTS1 Chassis / Components

The enclosure is compliant with Military Specification MS25212 rail mounting standard for military/aviation utilizing Dzus quarter-turn fasteners. A standard platform mounting option is also available. Front panel LEDs give the user an at-a-glance DTS1 status report. Additional status information is available through the CLI.

Two rear panel 10/100/1000 Ethernet ports (connectors J2 and J3) (Figure 2.3) are available for network connections supporting NFS, CIFS, FTP, iSCSI, PCAP, and HTTP file transfer protocols. The DTS1 also supports the Preboot eXecution Environment (PXE) giving remote computers the capability to boot from files stored on the DTS1. Connector J2 also supports RS-232 communication protocol (primarily used for configuring the DTS1) as well as a discrete zeroize and reset function. Connector J1 is used to connect the DTS1 to 28 VDC (operating voltage). In addition, the DTS1 has a removable panel located on the underside of the unit. It is removed to allow replacement of the crypto module battery.


The E1 ground lug located on the rear of the DTS1 is electrically bonded internally to the DTS1 chassis and the EMI / safety ground on J1 pin 4. Electrically, these points are all the same. It is intended that the E1 ground lug be used as the primary equipment tie point to bond the DTS1 to the user's system/structure/facility ground. This single tie point should suffice as the chassis / EMI / safety ground for the DTS1 in most applications.



DDOC0099-0005

Figure 2.3 DTS1 Rear Panel / Battery Access Cover and Rear Connectors

A set of processor carrier PCB connections (Figure 2.4) is provided under a panel on the side of the DTS1. Currently they are reserved for manufacturing and service activities. Contact Curtiss-Wright for more information about end-user utilization of these connectors. A write-enable switch is provided as well. The switch must be in the READ-WRITE position to enable configuring the DTS1. Refer to paragraph 3.2.2 **Write-Enable Switch** for detailed information.




DDOC0099-0019

Figure 2.4 DTS1 Processor Carrier PCB Programming Connector / Write-Enable Switch

2.1.2

RMC Module

One RMC module (Figure 2.5) is housed in the DTS1. The RMC module is accessed via a sealed door with a quarter-turn latch located on the front panel of the unit. The RMC module within the DTS1 is also a rugged compact unit that can be personally transported with minimal precautions to a secure location or deployment.



DDOC0099-0002

Figure 2.5 DTS1 With RMC Module

2.2

Protocols

The DTS1 supported protocols include Telnet, TFTP, CIFS, NFS, FTP, HTTP, DHCP, SNMP, and iSCSI in addition to its RS-232 console port. The CIFS and NFS protocols are enabled by default, all others are disabled. The unit also supports SSH, which is always enabled. The user can enable the desired protocols to support their application. Refer to paragraph 12.3.29 **serv** for additional information.

The FDEEEcPP20 and FDEAAcPP20 Protection Profiles did not consider, nor did they include networking protocols as part of the security functional requirements, and as a result, did not include any requirements for addressing those protocols.

Therefore, as per the FDEEEcPP20 and FDEAAcPP20, the protocols have not been examined as part of the required assurance activities and consequently the evaluation can make no claims about the DTS1's networking protocols.

2.3 CSfC Encryption

Commercial Solutions for Classified (CSfC) encryption is based on a National Security Agency (NSA) specification. The CSfC program requires multi-layered security. Hardware data encryption is used for the first security layer. The second security layer is software data encryption. Both encryption processes are performed in the DTS1, one in the HW crypto module, the other by the Processor. The hardware encryption key is retained in the DTS1 crypto module memory, the software encryption key is stored on the RMC module.

2.3.1 Hardware Encryption Layer



CAUTION

DATA LOSS. If the Specific User Token Key is lost, the user account will be rendered unusable.



NOTE

Refer to paragraph 5.3 **Hardware Layer Encryption** for information regarding the actual commands and procedures used to create and log into the hardware encryption layer.

2.3.1.1 Account Creation

Before use, an account must be created (Figure 2.6) on the DTS1 Hardware Encryption (HWE) layer. To start the account creation, the user logs into the DTS1 via the Command Line Interface (CLI). Once logged in, additional commands are entered to create an account on the DTS1 HWE layer. The HWE layer contains a Pre-Shared Key (PSK) which is generated at initial equipment power-on at the manufacturer and provided separately by Curtiss-Wright. The PSK cannot be read out of the DTS1. When the account is created, a user token key is internally generated by the HWE layer. The layer then keywraps the user token key using the PSK and supplies it to the end user through the CLI. The keywrapped user token key is validated on a third-party system by comparing the DTS1-generated HMAC and the third-party-generated HMAC. If both match, the user token is unwrapped using the PSK. The unwrapped user token key is then used in subsequent logins as the specific-user token.




Figure 2.6 Hardware Encryption Layer Account Creation

2.3.1.2 Account Login

Any subsequent use of the equipment requires logging in (Figure 2.7) to the HWE layer before data storage and/or transfer can begin. The user enters their user name and password into the DTS1. The HWE layer checks the information against its accounts. If the user name and password are recognized, a random one-time 64-byte key (also referred to as a nonce) is generated. The nonce is sent to the end-user via the CLI. The user then enters the nonce and their specific-user token key (generated when the account was created) into a third-party HMAC generator using the user token as the key. The CLI then sends this data as a user-generated HMAC to the DTS1 HWE layer. The layer compares the user HMAC and the HWE layer HMAC. If they are the same, the user is logged in. If they do not compare, the user is denied access.




Figure 2.7 Hardware Encryption Layer Account Login

2.3.2 Software Encryption Layer

⚠ CAUTION

DATA LOSS. If the software encryption key / passphrase is lost, the RMC module will be rendered unusable.

⚠ NOTE

Refer to paragraph 5.4 **Software Layer Encryption** for information regarding the actual commands and procedures used to create and log into the software encryption layer

⚠ NOTE

If the drive is going to be partitioned, the partition(s) must be created before the software encryption is activated.

To create the software encryption layer, the user must first log into the HWE layer. After that procedure has been accomplished, creation of the Software Encryption (SWE) layer can begin.

Software encryption is performed before the RMC module is formatted or mounted. Multiple RMC modules can be encrypted using the same or different encryption key / passphrase. In addition, RMC modules can be partitioned and have each partition use the same or different encryption key / passphrase. Before attempting to encrypt the RMC module, the status should be checked. If the status is not correct, creation of the SWE layer will fail. After the software encryption has been performed, the RMC module can be formatted and mounted.

Subsequent use of the RMC module is dependent upon the proper encryption key / passphrase being entered using the CL). Failure to enter the proper information will result in the RMC module being inaccessible for data storage or use.

2.3.3 Zeroize

There are two methods to zeroize the DTS1:

- Local
- Remote

To locally initiate zeroization, the KEY CLEAR button is depressed and held for a minimum of five seconds. To remotely initiate zeroization, the Zeroize_N signal is shorted to ground for approximately five seconds.

The Zeroize_N signal (connector J2-1) is internally pulled-up to +3.3V. The external device is required to sink no more than approximately 3.3 mA when Zeroize_N is shorted to GND. This can be accomplished by a switch, relay, or an open drain/collector type semiconductor device as long as the DTS GND reference (connector J2-3) is used. Refer to paragraph B.2 **Utility Connector J2 / Utility Lab Cable** for additional information regarding external connections.

2.4 Features

- Services
 - CIFS
 - DHCP
 - FTP
 - HTTP
 - NFS
 - SNMP
 - TFTP
 - TEL
- Performance (typical)
 - NFS & CIFS, single Ethernet channel and client
 - Sustained read: 105 Megabytes per second
 - Sustained write: 108 Megabytes per second
 - NFS & CIFS, two Ethernet channels, single client per channel
 - Sustained read: 61 Megabytes per second per channel
 - Sustained write: 64 Megabytes per second per channel
- Supported block data transfer protocol
 - iSCSI
- Supported packet capture protocol
 - PCAP
- Supported video stream capture protocol
 - RTP
- Client remote boot from DTS1 via Preboot eXecution Environment (PXE)
- User control, status, & maintenance interface
 - Command Line Interface (CLI) via:
 - Secure shell (SSH)
 - Serial RS-232
 - Ethernet
 - SNMP via Ethernet
- Rear panel connections
 - J1: Power input
 - Remote Power Disable
 - MIL-STD-704E compliant +28VDC
 - 20 Watts maximum power dissipation
 - 1.3 Amps peak inrush current
 - J2: Ethernet interface, RS-232, Reset, and Zeroization
 - 10/100/1000 copper
 - IEEE 802.3, 802.u, and 802.ab
 - RS-232 serial communications
 - Zeroize discrete
 - Reset (reboot) discrete

- J3: Ethernet interface
 - 10/100/1000 copper
 - IEEE 802.3, 802.u, and 802.ab
- Front panel controls and indicators
 - POWER LED (green)
 - FAULT LED (red)
 - KEY LOADED LED (yellow)
 - DRIVE CAPACITY LEDs
 - KEY CLEAR Button
- Built In Test (BIT) capability
 - Provides overall health and status and out-of limits detection and notification
 - Start-up BIT (SBIT) (displayed upon start up)
 - Periodic BIT (PBIT)
 - Initiated BIT (IBIT)
 - Maintenance BIT (MBIT)
 - Test control via CLI, health status query via CLI and SNMP
- Environmental, EMI Compliance, and Electrical Characteristics
 - Refer to paragraph A.5 **Environmental, EMI, Electrical Specifications** for detailed information.
- Physical
 - Dimensions and mounting compliant with Military Specification MS25212
 - Military/aviation rail mounting utilizing Dzus quarter-turn fasteners
 - Platform mounting utilizing standard L-brackets.
 - RMC module accessed via environmentally sealed front door with quarter turn locking mechanism
- Data encryption
 - Elliptical Curve Cryptography (ECC)
 - AES-256, in-line battery backed-up encryption module for encryption of data-at-rest prior to storage on RMC module
 - NIST/FIPS 140-2 certifiable
 - External encryption key loading
 - Key may be zeroized by external hardware discrete or by software command
- RMC Module
 - One module individually mounted and accessible
 - Solid-state storage
 - Optional capacities from 256 GB to 8 TB per RMC module.
 - Low insertion/removal force: 40 oz.
 - High insertion/removal cycle: > 100,000 cycles
 - Hot insertion/removal
 - User writeable cartridge/volume name/description (up to 32 characters) stored in cartridge non-volatile memory accessible via out-of-band interface.
 - RMC module removal request via front panel push button
 - LED status indicators:
 - STATUS (green): on when RMC module is installed, mounted and ready for access
 - ACTIVITY (green): on when disk is accessed (not supported on some RMC module configurations)
 - FAULT (red): DTS1 system monitor has detected a fault with the RMC module

Controls and Indicators

3.1 Chassis Indicators

The DTS1 has four LED status indicators (Figure 3.1) on the bottom of the front panel:

- POWER
- FAULT
- KEY LOADED
- DRIVE CAPACITY

The brightness of the chassis LEDs can be independently set from 0 to 100% brightness. This accomplished by changing the duty cycle of the power applied to the individual LEDs. The CLI `ledctrl` command is used in association with `-s` option to select the individual LED and `-d` option to select its duty cycle. See paragraph 12.3.15 `ledctrl` for detailed information.




Figure 3.1 DTS1 Controls / Indicators

3.1.1 POWER LED

This LED will illuminate green shortly after the 28 volt supply is switched on. This LED remains illuminated while power is supplied.

3.1.2 FAULT LED

This LED may illuminate for a short time after power is applied (during booting) and will extinguish if the Built-In-Test (BIT) passed. The periodic BIT will illuminate this LED if it detects an anomaly such as an out of tolerance voltage level. If an error or failure has occurred in the encryption hardware or software the FAULT LED will light and no encrypted data can be transferred. If the FAULT LED remains on, try:

- Restarting the DTS1
- Reseating the RMC

Refer to the **Troubleshooting** section for possible causes and solutions. Contact Curtiss-Wright Defense Solutions if the fault indications persist.

3.1.3 KEY LOADED LED

When this yellow LED is illuminated, it indicates that the encryption key has been successfully loaded to the RMC.

3.1.4 DRIVE CAPACITY LEDs

ⓘ NOTE

The capacity LEDs only correlate to the entire unpartitioned physical RMC. On partitioned RMC modules the LEDs are not valid. See paragraph 12.3.24 `rmcfree` to acquire disk and partition capacity information.

These LEDs (Figure 3.2) are an indicator of the remaining storage capacity of the installed RMC. There are 5 LEDs: 3 GREEN, 1 AMBER, and 1 RED. When all 5 LEDs are on, this indicates that there is approximately 80% to 100% of RMC storage capacity available. As storage is utilized in the RMC the LEDs will be extinguished in succession starting from left to right. LEDs may take up to a minute to change state when capacity remaining crosses the thresholds.




Figure 3.2 Remaining Disk Capacity Indicators

3.2 Chassis Controls

3.2.1 Key Clear Button

When this button is pushed and held for a minimum of 5 seconds, all encryption related material within the DTS1 will be erased. This includes loaded keys, stored keys, and all previously loaded login/authentication credentials (user names and passwords). After zeroization, the yellow KEY LOADED LED will turn off. In order to use the unit again the encryptor will require reinitialization and any previously loaded credentials and keys to be reloaded.

3.2.2 Write-Enable Switch



CAUTION

EQUIPMENT DAMAGE. Exercise ESD precautions when installing, removing, or handling the DTS1.



CAUTION

EQUIPMENT DAMAGE. Extreme caution must be used to ensure all ESD handling precautions are followed when setting the write-enable switch. Failure to properly handle the DTS1 will result in equipment damage.

The write-enable switch (Figure 3.3) is used to lock the USB flash memory so it cannot be inadvertently changed. The switch is placed in the READ-WRITE position to configure the flash memory. After the configuration is set, the switch is moved to the READ position.




Figure 3.3 DTS1 Write-Enable Switch

3.3 RMC Module Controls / Indications

The RMC module (located behind the DTS1's storage bay door) has its own controls / indicators as shown in Figure 3.4. The function of these controls and indicators is as follows.

3.3.1 STATUS LED (Green / Left)

When this green (left) LED is illuminated it indicates that the RMC module is functioning properly. If there is a change in status or a problem, this LED will indicate the nature of the condition by the behavior outlined in Table 3.1.




Figure 3.4 RMC Module Controls / Indicators

Table 3.1 RMC Module STATUS LED Indications

LED Behavior	Meaning
Steady On	RMC module detected, mounted, and ready
Steady Off	RMC module not detected
Slow blinking (1Hz)	RMC module detected, not mounted
Fast blinking (5Hz) for 2 seconds	Button-hold acknowledge*
1 blink, 4 seconds off	Ready for removal*
2 blink, 3 seconds off	Auto-mount failure
5 blink, 3 seconds off	RMC module monitoring error

3.3.2 ACTIVITY LED (Green / Middle)

This green (middle) LED is an indicator of SATA disk activity. This function is not supported on all configurations.

3.3.3 FAULT LED

This red LED indicates the BIT has failed or an operational anomaly was detected such as power levels, data connections, or optional security functions. This LED will be ON during initialization and then remain OFF during normal operation. See the **Troubleshooting** section for actions to take if the RMC module FAULT LED is illuminated.

3.3.4 Removal Request Button

**CAUTION**

EQUIPMENT DAMAGE. Exercise ESD precautions when installing, removing, or handling the RMC module.

**CAUTION**

EQUIPMENT DAMAGE. The RMC is hot-swappable (remove / install with power applied), however, extreme caution must be used to ensure all ESD handling precautions are followed.

Press and hold this button for three to five seconds to request removal of the RMC module. The STATUS LED will blink at 5Hz for two seconds to acknowledge the request. After acknowledgment, the system will unmount and prepare the RMC module for removal. When the RMC module is ready for removal, the STATUS LED will blink one time every five seconds. Removal may also be requested with the CLI command `rmctl`.

Installation

CAUTION
EQUIPMENT DAMAGE. Exercise ESD precautions when installing, removing, or handling the DTS1.

4.1 Package

NOTE
Either L-brackets or a Dzus mount is included depending on the ordered configuration.

The DTS1 package contents are listed below:

- DTS1 Chassis
 - L-Brackets*
 - Dzus Mount*
- Product Documentation CD

Optional Items (Refer to **Ordering Information** section for part numbers).

- RMC Module(s)
- Power Lab Cable
- Utility Lab Cable
- Ethernet Lab Cable

4.2 Inspection

The DTS1 is a two-part data storage system that consists of a DTS1 chassis and a RMC module. Additional accessories may be included (if ordered). All received items should be inspected for damage. Inspect all units as follows:

- All screws should be tight.
- The door gasket should be free from any cuts, crushing, or flattening damage
- All anti-tamper labels (Figure 4.1 and Figure 4.2) should be unbroken.
- All components should be free from any dents, cracks, or damage.
- All connectors pins should be present, straight, and undamaged.

If the DTS1 chassis or any accessories were damaged in shipping or the enclosure was breached, immediately notify Curtiss-Wright Defense Solutions or your supplier.




Figure 4.1 DTS1 Chassis Anti-Tamper Label Locations




Figure 4.2 RMC Module Anti-Tamper Label Location

4.3 Mounting

Mounting environment considerations should include operating temperature limits, humidity, and vibration limits. Other considerations should include clearance for mounting hardware, cables, and safe installation or removal of the DTS1 chassis from its mounting structure. Precautions should be taken when cables are routed around structures that could cause excessive abrasion, such as around the corner of vibrating equipment.

Installation of the DTS1 can put an increased demand on cooling systems by raising ambient air temperatures. Evaluate changes in airflow obstructions and temperatures around equipment and possible detrimental surface temperatures due to conducted heat. See paragraph A.5 **Environmental, EMI, Electrical Specifications** for thermal limit specifications.

Two mounting methods (Figure 4.3) provide secure attachment to a platform: standard platform mounting brackets or a Dzus mount. This will require the acquisition of the appropriate mounting components and precise installation per the selected platforms mounting specifications.

Mechanical mounting of the DTS1 with Dzus option requires compliance to MIL-STD MS25212. If installation and removal of the RMC module is desired while the DTS1 remains mounted, be sure to allow clearance (Figure 4.4) for the door to open and the RMC module to be positioned in front of the DTS1.




Figure 4.3 DTS1 Chassis Mounting




Figure 4.4 DTS1 Required Door Clearance

4.4 Cables

All connections to the DTS1 are on the rear panel (Figure 4.5). Be sure the power supply is off when making connections.




Figure 4.5 DTS1 Rear Panel Connectors

4.4.1 Power Cable

The Power Lab Cable (VS-DTS1PWRCAB-0) (Figure 4.6) is used to make power connections to the DTS1. The DTS1 requires an input power of +28 volts and ground. Refer to paragraph B.1 **Power Connector J1 / Power Lab Cable** for connector pin signal information.




Figure 4.6 Power Lab Cable

Connections

- The 4-pin connector (P1) mates to DTS1 J1.
- The red plug connects to 28 VDC.
- The black plug connects to 28 VDC return.
- The green plug connects to chassis ground.
- The audio jack (if used) connects to a user-designed power disable switch.

4.4.2 Utility Cable

The Utility Lab Cable (VS-DTS1ETHCAB-J2) (Figure 4.7) is used for initial setup operations through RS-232 or Ethernet. Refer to paragraph B.2 **Utility Connector J2 / Utility Lab Cable** for connector pin signal information.

Connections

- The 19-pin connector (P1) mates to DTS1 J2.
- The RJ-45 plug (P2) connects to a terminal or PC Ethernet port.
- The DB-9 connector (J1) mates to a terminal or PC serial port.
- The audio jack (J2) connects to user-configured switches for zeroization and reboot.




Figure 4.7 Utility Lab Cable

4.4.3 Ethernet Cable

The Ethernet Lab Cable (VS-DTS1ETHCAB-J3) (Figure 4.8) is used to make network connections to the DTS1. Refer to paragraph B.3 **Ethernet Connector J3 / Ethernet Lab Cable** for connector pin signal information.

Connections

- The 19-pin connector (P1) mates to DTS1 J3.
- The RJ-45 plug (P2) connects to the desired network outlet panel, hub, etc.




Figure 4.8 Ethernet Lab Cable


4.4.4 Ground Cable



NOTE

Do not loosen nut / washer installed on ground stud E1. Ensure nut / washer on ground stud remain properly tightened when installing / removing ground cable.

To ensure proper grounding of the DTS1, a ground cable, split lock washer, and hex nut are required, but not provided. The ground cable (Figure 4.9) terminal is installed on the DTS1 ground stud E1. Refer to paragraph B.4 **Ground Cable** for detailed installation instructions.



DDOC0099-0047

Figure 4.9 DTS1 Ground Connection

Encryption

**NOTE**

Throughout this section, **yellow highlighted text** is used to denote user-defined or software-generated inputs. **Green highlighted text** is used to show changes in values, settings, or responses due to implementation of a software command.

5.1 Passwords / Passphrases

5.1.1 Hardware Layer Passwords

The following is required for hardware layer passwords:

- Must be 8-64 characters in length.
- Must contain at least one number.
- Must contain at least one alpha character.
- No special characters allowed.

5.1.2 Software Layer Passwords / Passphrases

The following is required for software layer passwords / passphrases:

- Must be 15-512 characters in length.
- If using password, must pass dictionary test.
- Requires at least 1 upper case char, 1 lower case char, 1 number, and 1 special character.
- A character must not repeat more than 3 times.
- There shall be no more than 4 consecutive characters from a single character class (no more than 4 digits, lower case, upper case, or special characters in a row).

5.1.3 Incorrect Password / Passphrase Entered

Hardware Layer

The hardware layer password can be incorrectly entered two times without issue. On the third try if an incorrect password is entered, the hardware layer key will automatically zeroize. Once this occurs, the DTS1 will need to be reinitialized with the correct password.

Software Layer

The software layer password /passphrase can be incorrectly entered four times without issue. On the fifth try if an incorrect password / passphrase is entered, the DTS1 will automatically reboot. There is no limitation to the number of times an incorrect entry /reboot occurs.

5.1.4 Change Password / Passphrase

Hardware Layer

To change the hardware layer password the following must occur:

- The hardware layer must be zeroized. Refer to paragraph 5.5 **Zeroize HWE Key / Delete SWE Container / RMC Purge** for information.
- A new account must be created using the new / changed password. Refer to paragraph 5.3.1 **Initialize / Login - Crypto Module** and paragraph 5.3.3 **Access RMC Module (Plain Text DEK / Encrypted DEK)** for information.

Software Layer

To change the software layer password the following must occur:

- The software layer container(s) must be deleted. Refer to paragraph 5.5 **Zeroize HWE Key / Delete SWE Container / RMC Purge** for information.
- New software container(s) must be created using the new / changed password. Refer to paragraph 5.4.1.1 **Initialize Container (Unpartitioned Disk)** for information.

5.2 Check Hardware Layer Status

NOTE
All values listed below should equal na or 0 for a new DTS1 / RMC module.

1. Check login status

Command:

- ```
cmlogin
```
- init =0 not initialized / =1 initialized
  - login =0 not logged into / =1 active login

**Example:**

```

cw_dts> cmlogin
[cmlogin]
CMLOGIN: state=uninit/init init=<0/1> login=<0/1> status=OK
[!cmlogin] OK

```

2. Check key status

**Command:**

- ```
cmkey
```
- init =0 not initialized / =1 initialized
 - login =0 not logged into / =1 active login
 - s0 =0 no key loaded / =1 key loaded

NOTE
In the example below id=<int> is the crypto module ID. The deks=0x0 is the location information for saved keys. See paragraph 3.2.2 **Write-Enable Switch** for information regarding key storage location.

Example

```

cw_dts> cmkey
[cmkey]
CMKEY: id=<int> init=<0/1>login=<0/1>s0=<0/1>s1=<0>s2=<0> deks=0x0 status=OK
[!cmkey] OK
    
```

3. Check RMC module status

Command:

- ```
rmcctl
```
- scryp =na / =0 no software encryption / =1 software encryption present
  - fmt =na / =0 not formatted / =1 formatted
  - mnt =na / =0 not mounted / =1 mounted

**Example**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 na na -- ---- ---- na/0/1 na na/0/1 na/0/1 0 ----
[!rmcctl] OK

```

### 5.2.1 Hardware Layer Definitions

**NOTE**  
The cmkey command applies only to the hardware encryption layer. The software encryption layer is controlled by options associated with the rmcctl command.

The key management command cmkey provides the user the ability to compose keys, load and unload keys to the RMC module, save keys in the crypto module, delete saved keys, and set up an auto-load key feature. All of these functions are explained in the following subsections.

Before proceeding, it is helpful to have a brief description of the terms used in the subsections that follow.

|               |                                                                                                                                                                         |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Key.....      | This term is used in the context of the RMC module, referring to the DEK and PSK or EDEK and MAC. The singular form key applies to all keys required by the RMC module. |
| DEK .....     | Data Encryption Key in plain text.                                                                                                                                      |
| EDEK.....     | Encrypted DEK is a DEK that is encrypted or wrapped.                                                                                                                    |
| PSK.....      | Pre-Shared Key is a common key between the user workstation and the DTS1 crypto module, allowing each to read the encryption of the other.                              |
| KEK.....      | Key Encryption Key is the key used to create the EDEK.                                                                                                                  |
| MAC.....      | Message Authentication Code is a value used to validate messages carrying a key.                                                                                        |
| CM .....      | Crypto Module is the circuitry in the DTS1 that manages encryption keys and uses them to encrypt/decrypt data.                                                          |
| Install ..... | Sending the key from the user's workstation to the encryption chip serving a specified RMC module slot.                                                                 |
| Save.....     | Store a key to the CM memory.                                                                                                                                           |
| Load.....     | Move (copy) the saved key from the CM memory to the encryption chip serving a specified RMC module slot.                                                                |
| Unload .....  | Removal of the key from the CM encryption chip.                                                                                                                         |
| Delete .....  | Removal of the key from the CM memory.                                                                                                                                  |

## 5.3 Hardware Layer Encryption

### 5.3.1 Initialize / Login - Crypto Module



**NOTE**

[username] and [password] are selected and entered by the user.

- User name (-u) requirement is 1-15 characters in length.
- Password (-p) requirement: see paragraph 5.1.1 **Hardware Layer Passwords** for requirements.

1. Obtain user token.

**Command:**

**cmlogin -u [username] -p -I**

**Example**

```

cw_dis> cmlogin -u [username] -p -I
[cmlogin]
Please enter password: [password]
Please verify password: [password]
CMLOGIN: action=init status=OK
USER_TOKEN=[Generated random string 128 characters (64 bytes Hex) long]
TOKEN_HMAC=[Generated random string 96 characters (48 bytes Hex) long]
PSK=[Curtiss-Wright provided. 64 f's will be shown in place of the actual PSK]
[!cmlogin] OK

```



**NOTE**

Decrypting the user token requires a 3rd-party AES256 key-unwrapping algorithm and the PSK.

2. Decrypt user token.
3. Generate challenge.

**Command:**

**cmlogin -u [username] -p -I**

**Example**

```

cw_dts> cmlogin -u [username] -p -L
[cmlogin]
Please enter password: [password]
CHALLENGE=[Generated random string 128 characters (64 bytes Hex) long]
[!cmlogin] OK

```

**NOTE**

Generating the HMAC requires the decrypted user token, challenge, and a HMAC hash generator that supports the SHA-384 algorithm.

4. Generate the HMAC.
5. Login to crypto module.

**Command:**

```
cmlogin -M [Generated HMAC string]
```

**Example**

```

cw_dts> cmlogin -M [Generated HMAC string]
[cmlogin]
CMLOGIN: action=auth status=ok
[!cmlogin] OK

```

**5.3.2 Verify Successful Login**

To verify a successful login type `cmlogin` and press ENTER key.

- State should show ready
- Init show 1
- Status show OK

**Example**

```

CW_dts> cmlogin
[cmlogin]
CMLOGIN: state=ready init=1 status=OK
[!cmlogin] OK

```

**5.3.3 Access RMC Module (Plain Text DEK / Encrypted DEK)****CAUTION**

DATA ACCESS. Use of slot option (-s 0) is required to when entering key (DEK and PSK).

**NOTE**

Use of -s 0 option denotes slot 0, -F option forces an over-write of any key previously installed.

Entering a plain text DEK or an encrypted DEK (EDEK) is required to access the RMC. The EDEK provides additional security, but requires additional effort on the part of the user.

**5.3.3.1 Access RMC Module (Plain Text DEK)****NOTE**

The DEK is a user-generated 64-character string.

1. To access the RMC, enter the DEK and PSK.
2. Type `cmkey -s 0 -d -p --force` and press ENTER key.

**Example**

```

cw_dts> cmkey -s 0 -d -p --force
[cmkey]
Please enter plaintext DEK: [User-generated plain text DEK string]
Please enter current PSK: [Curtiss-Wright provided PSK string]
CMKEY: action=inst slot=0 status=ok
[!cmlogin] OK

```

### 5.3.3.2 Access RMC Module (EDEK)

1. Generate an EDEK as follows:
  - a. To obtain the KEK and associated MAC type `cmkey --kek` and press ENTER key.

#### Example

```

cw_dts> cmkey --kek
[cmkey]
CMKEY: kek=[KEK] mac=[MAC]
status=OK
[!cmkey] OK

```

- b. Using a 3rd-party HMAC SHA384 application, generate an HMAC using the KEK and Curtiss-Wright supplied PSK as the key.
    - ◆ The generated HMAC should be the same as the MAC from the example above.
  - c. Using a 3rd-party application capable of performing an AES256 key-unwrapping algorithm, perform an AES key unwrap function on the KEK using the PSK. This will yield the actual/unwrapped KEK you will use to encrypt your DEK.
  - d. Using a 3rd-party application capable of performing an AES256 key wrap function, encrypt the DEK using the unwrapped KEK. This will yield the wrapped/encrypted DEK (EDEK).
  - e. Using a 3rd-party HMAC SHA384 application, calculate a new MAC using the HMAC SHA384 function for the EDEK using the unwrapped KEK as the key.
2. To access the RMC, enter the EDEK and MAC.
3. Type `cmkey -s 0 -e [EDEK string] -m [MAC string] -force` and press ENTER key.

#### Example

```

cw_dts> cmkey -s 0 -e [EDEK string] -m [MAC string] -force
[cmkey]
CMKEY: action=inst slot=0 status=ok
[!cmlogin] OK

```

### 5.3.4 Hardware Encryption Key Storage



#### NOTE

This section is no longer applicable and has been deleted.

## 5.4 Software Layer Encryption



#### CAUTION

**DATA SECURITY.** Be sure to CLOSE the SSH session after initializing or entering the software encryption layer. Leaving the SSH session open can expose the passphrase to unauthorized access.



#### CAUTION

**DATA SECURITY.** Only SSH session may be used for configuring software encryption layer. The console or serial port cannot be used for setting up software encryption as the passphrase is not cleared from memory as required.



#### NOTE

The RMC module must have services assigned before the software encryption layer can be initialized / entered.

The `rmcctl -C` command allows the user to view and alter the DTS1 disk encryption options. The software encryption layer uses containers to hold the data. Creation of a container requires the use of a password or passphrase. Refer to paragraph 5.1.2 **Software Layer Passwords / Passphrases** for requirements.

### 5.4.1 Unpartitioned Disk

Disks cannot be partitioned after software encryption has been performed.

### 5.4.1.1 Initialize Container (Unpartitioned Disk)



#### CAUTION

DATA LOSS. Initializing SWE will overwrite / destroy any existing data on the disk. As a result the -force option must be used.

Initialize a Software Encryption (SWE) container on an RMC module as follows:

1. Type `rmcctl --force -C` and press ENTER key.



#### NOTE

After the above command has been issued, the user must acknowledge that all data on the disk will be overwritten

2. At the overwrite query prompt type `YES` and press ENTER key.



#### NOTE

Refer to paragraph 5.1.2 **Software Layer Passwords / Passphrases** for requirements.

3. Enter a **password / passphrase** that complies with the password / passphrase requirements and press ENTER key.
4. Reenter the **password / passphrase** and press ENTER key.

- ◆ If the passphrase is entered correctly both times and meets the requirements the following message will be displayed: `RMC_C0; action=crp status=OK.`

#### Example of RMC Module Status

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 -- 100GB NAS 1 0 na na 0 rmc0
[!rmcctl] OK

```

### 5.4.1.2 Open SWE Container (Unpartitioned Disk)



#### NOTE

The SWE container must be opened before it can be used.

Open the SWE container on an RMC module as follows:

1. Type `rmcctl -E` and press ENTER key.



#### NOTE

After five failed attempts to open the SWE container, the DTS1 will reboot and another five attempts be granted.

2. Enter the **password / passphrase** and press ENTER key.

- ◆ If the passphrase is entered correctly the following message will be displayed: `RMC_C0; action=enter status=OK 'Resetting attempts to 0'.`

#### Example of RMC Module Status

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 -- 100GB NAS 1 1 0 na 0 rmc0
[!rmcctl] OK

```

### 5.4.1.3 Format / Mount SWE Container (Unpartitioned Disk)



#### NOTE

NTFS format is not allowed on a software encrypted RMC module.

After opening the SWE container, it can be formatted, mounted, and used.

- To format only:  
**Command:**  
`rmcctl -F`

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 -- 100GB NAS 1 1 ext4 0 0 rmc0
[!rmcctl] OK

```

- To format and mount:  
**Command:**  
`rmcctl -F -M`

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 -- 100GB NAS 1 1 ext4 1 0 rmc0
[!rmcctl] OK

```

**5.4.1.4 Close SWE Container (Unpartitioned Disk)**



**NOTE**

To close the SWE container it must be unmounted.

1. Type `rmcctl -U` and press ENTER key.
2. Type `rmcctl -X` and press ENTER key.

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 -- 100GB NAS 1 0 na na 0 rmc0
[!rmcctl] OK

```

**5.4.1.5 Delete SWE Container (Unpartitioned Disk)**



**CAUTION**

LOSS OF CONTENT. Deletion of the SWE container will result in making the stored content unrecoverable.

To delete software encryption layer container:

- Command:**  
`rmcctl -D`

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 -- 100GB NAS 0 na 0 na 0 rmc0
[!rmcctl] OK

```

**5.4.2 Partitions**



**NOTE**

Refer to paragraph 5.1.2 **Software Layer Passwords / Passphrases** for requirements.

Partitions can have the same or different passwords / passphrases assigned.

### 5.4.2.1 Initialize SWE Containers (Partitions - Different Passphrases)



**CAUTION**

DATA LOSS. Initializing the software encryption layer will overwrite / destroy any existing data on the partition. As a result the `--force` option must be used.

1. Initialize the SWE container on partition 1 of a 100GB RMC module as follows:
  - a. Type `rmcctl -p 1 --force -C` and press ENTER key.
  - b. After the above command has been issued, the user must acknowledge that all data on the partition will be overwritten
  - c. At the overwrite query prompt type **YES** and press ENTER key.



**NOTE**

Refer to paragraph 5.1.2 **Software Layer Passwords / Passphrases** for requirements.

2. Enter a **password / passphrase** that complies with the password / passphrase requirements and press ENTER key.
  - d. Reenter the **password / passphrase** and press ENTER key.
    - ◆ If the passphrase is entered correctly both times and meets the requirements the following message will be displayed: `RMC_C0; action=cryp status=OK.`

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 50 GB NAS 1 0 na na 0 rmc0p1
RMC_S0: 1 1 1 2 50 GB NAS 0 na 0 na 0 rmc0p2
[!rmcctl] OK

```

3. Initialize the SWE container on partition 2 of a 100GB RMC module as follows:
  - a. Type `rmcctl -p 2 --force -C` and press ENTER key.
  - b. After the above command has been issued, the user must acknowledge that all data on the partition will be overwritten
  - c. At the overwrite query prompt type **YES** and press ENTER key.
  - d. Enter a **password / passphrase** than is different than the partition 1 passphrase and complies with the password / passphrase requirements.
  - e. Press ENTER key.
  - f. Reenter the **password / passphrase** and press ENTER key.
    - ◆ If the passphrase is entered correctly both times and meets the requirements the following message will be displayed: `RMC_C0; action=cryp status=OK.`

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 50 GB NAS 1 0 na na 0 rmc0p1
RMC_S0: 1 1 1 2 50 GB NAS 1 0 na na 0 rmc0p2
[!rmcctl] OK

```

### 5.4.2.2 Open SWE Container (Partitions - Different Passphrases)



**NOTE**

The SWE containers must be opened before they can be used.

1. Open the SWE container on partition 1 of a 100GB RMC module as follows:

- a. Type `rmcctl -p1 -E` and press ENTER key.
- b. Enter the partition 1 `password / passphrase` and press ENTER key.
  - ◆ If the passphrase is entered correctly the following message will be displayed:  
RMC\_C0; action=enter status=OK `Resetting attempts to 0`.

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 50 GB NAS 1 1 0 na 0 rmc0p1
RMC_S0: 1 1 1 2 50 GB NAS 1 0 0 na 0 rmc0p2
[!rmcctl] OK

```

2. Open the SWE container on partition 2 of a 100GB RMC module as follows:
  - a. Type `rmcctl -p2 -E` and press ENTER key.
  - b. Enter the partition 2 `password / passphrase` and press ENTER key.
    - ◆ If the passphrase is entered correctly the following message will be displayed:  
RMC\_C0; action=enter status=OK `Resetting attempts to 0`.

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 50 GB NAS 1 1 0 na 0 rmc0p1
RMC_S0: 1 1 1 2 50 GB NAS 1 1 0 na 0 rmc0p2
[!rmcctl] OK

```

**5.4.2.3 Initialize SWE Encryption (Partitions - Same Passphrase)**



**CAUTION**  
DATA LOSS. Initializing the software encryption layer will overwrite / destroy any existing data on the partition. As a result, the `--force` option must be used.

Initialize the SWE containers on all partitions of a 100GB RMC module as follows:

1. Type `rmcctl -p all --force -C` and press ENTER key.
2. Partition 1
  - a. After the above command has been issued, the user must acknowledge that all data on the partitions will be overwritten
  - b. At the overwrite query prompt type `YES` and press ENTER key.



**NOTE**  
Refer to paragraph 5.1.2 **Software Layer Passwords / Passphrases** for requirements.

- c. Enter a partition 1 `password / passphrase` that complies with the password / passphrase requirements and press ENTER key.
  - d. Reenter the `password / passphrase` and press ENTER key.
    - ◆ If the passphrase is entered correctly both times and meets the requirements the following message will be displayed: RMC\_C0; action=crp status=OK.
3. Partition 2
  - a. At the overwrite query prompt type `YES` and press ENTER key.
  - b. Enter the same `password / passphrase` for partition 2 and press ENTER key.



- c. Reenter the **password / passphrase** and press ENTER key.
  - ◆ If the passphrase is entered correctly both times and meets the requirements the following message will be displayed: RMC\_C0; action=cryp status=OK.

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 50 GB NAS 1 0 na na 0 rmc0p1
RMC_S0: 1 1 1 2 50 GB NAS 1 0 na na 0 rmc0p2
[!rmcctl] OK

```

**5.4.2.4 Open SWE Container (Partition - Same Passphrase)**



**NOTE**

The SWE containers must be opened before they can be used.

Open the SWE containers on all partitions of a 100GB RMC module as follows:

1. Type `rmcctl -p all -E` and press ENTER key.
2. Partition 1: Enter the **password / passphrase** and press ENTER key.
3. Partition 2: Enter the **password / passphrase** and press ENTER key.

- ◆ If the passphrase is entered correctly the following message will be displayed: RMC\_C0; action=enter status=OK `Resetting attempts to 0`.

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 50 GB NAS 1 1 0 na 0 rmc0p1
RMC_S0: 1 1 1 2 50GB NAS 1 1 0 na 0 rmc0p2
[!rmcctl] OK

```

**5.4.2.5 Format / Mount SWE Containers (Individual Partitions)**



**NOTE**

NTFS format is not allowed on software encrypted RMC module partitions.

After opening the SWE containers on individual partitions, they can be formatted, mounted, and used.

- To only format the SWE containers:
  - Command:**  
`rmcctl -p 1 -F`
- To format and mount the SWE containers:

**Command:**  
`rmcctl -p 2 -F -M`

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 100GB NAS 1 1 ext4 0 0 rmc0p1
RMC_S0: 1 1 1 2 25 GB NAS 1 1 ext4 1 0 rmc0p2
[!rmcctl] OK

```

### 5.4.2.6 Format / Mount SWE Containers (All Partitions)

**NOTE**  
NTFS format is not allowed on software encrypted RMC module partitions.

After opening the SWE containers on individual partitions, they can be formatted, mounted, and used.

- To only format the SWE containers:

**Command:**  
`rmcctl -p all -F`

#### Example of RMC Module Status

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 100GB NAS 1 1 ext4 0 0 rmc0p1
RMC_S0: 1 1 1 2 25 GB NAS 1 1 ext4 0 0 rmc0p2
[!rmcctl] OK

```

- To format and mount the SWE containers:

**Command:**  
`rmcctl -p all -F -M`

#### Example of RMC Module Status

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 100GB NAS 1 1 ext4 1 0 rmc0p1
RMC_S0: 1 1 1 2 25 GB NAS 1 1 ext4 1 0 rmc0p2
[!rmcctl] OK

```

### 5.4.2.7 Close SWE Containers (Individual Partitions)

**NOTE**  
To close the SWE container on a partition it must be unmounted.

- Type `rmcctl -p 2 -U` and press ENTER key.
- Type `rmcctl -p 2 -X` and press ENTER key.

#### Example of RMC Module Status

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 100GB NAS 1 1 ext4 1 0 rmc0p1
RMC_S0: 1 1 1 2 25 GB NAS 1 0 na na 0 rmc0p2
[!rmcctl] OK

```

### 5.4.2.8 Close SWE Container (All Partitions)

**NOTE**  
To close the SWE containers on the partitions they must be unmounted.

- Type `rmcctl -p all -U` and press ENTER key.
- Type `rmcctl -p all -X` and press ENTER key.

**Example of RMC Module Status**


```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 100GB NAS 1 0 na na 0 rmc0p1
RMC_S0: 1 1 1 2 25 GB NAS 1 0 na na 0 rmc0p2
[!rmcctl] OK

```

**5.4.2.9 Delete SWE Container (Individual Partitions)**

 **CAUTION**  
 LOSS OF CONTENT. Deletion of a SWE container will result in making the stored content unrecoverable.

To delete a SWE container:

**Command:**  
`rmcctl -p 2 -D`

**Example of RMC Module Status**


```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 100GB NAS 1 0 na na 0 rmc0p1
RMC_S0: 1 1 1 2 25 GB NAS 0 na 0a na 0 rmc0p2
[!rmcctl] OK

```

**5.4.2.10 Delete SWE Containers (All Partitions)**

 **CAUTION**  
 LOSS OF CONTENT. Deletion of SWE containers will result in making the stored content unrecoverable.

To delete all software encryption layer containers:

**Command:**  
`rmcctl -p all -D`

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint


RMC_S0: 1 1 1 1 100GB NAS 0 na 0a na 0 rmc0p1
RMC_S0: 1 1 1 2 25 GB NAS 0 na 0a na 0 rmc0p2
[!rmcctl] OK

```

**5.5 Zeroize HWE Key / Delete SWE Container / RMC Purge**

- The destruction of the HWE key(s) is accomplished via zeroization.
- The SWE passphrase(s) is /are destroyed via deleting the SWE container(s).
- The RMC module data is destroyed via the rmcpurge command.

**5.5.1 Zeroize HWE Key**

 **CAUTION**  
 DATA LOSS. Pushing the Key Clear button will zeroize the hardware encryption layer key. It will not affect SWE passphrase(s) / data.

The goal of zeroization is to destroy the HWE key loaded in the crypto module beyond recovery by any means.

The zeroization process is accomplished by one of the following:

- Pushing the front panel KEY CLEAR button for a minimum of 5 seconds.
- Issuing a `cmkey -zero` command via the CLI.
- Connecting utility connector (J2) pin 1 to ground for a minimum of 5 seconds.
- Incorrectly entering the hardware layer password three times consecutively.

Zeroization affects only the crypto module HWE key. It does not affect the RMC module. The data on the RMC module is still accessible:

- If the RMC module can be placed in another DTS1 with the same DEK / EDEK loaded in its crypto module.
- If the DEK can be restored / reloaded.

## 5.5.2 Delete SWE Container

### CAUTION

LOSS OF CONTENT. Deletion of SWE container(s) will result in making the stored content unrecoverable.

Refer to paragraph 5.4.1.5 **Delete SWE Container (Unpartitioned Disk)**, paragraph 5.4.2.9 **Delete SWE Container (Individual Partitions)**, and / or paragraph 5.4.2.10 **Delete SWE Containers (All Partitions)** for detailed instructions on how to use the SWE passphrase delete (`rmcctl -D`) commands.

## 5.5.3 RMC Purge

### CAUTION

DATA SECURITY. The `rmcpurge` command does not affect the HWE key(s).

### CAUTION

DATA SECURITY. Depending on the solid-state drive manufacturer, the `rmcpurge` may or may not delete the SWE passphrase(s). To be sure the passphrase has been removed, use the SWE passphrase delete (`rmcctl -D`) command.

To destroy the passphrase(s) and data on the RMC module, the `rmcpurge` command is used. There are two types of overwrite, Normal (`-N`) and Enhanced (`-E`). Refer to paragraph 12.3.26 **rmcpurge** for additional information

1. Purge RMC module in slot 0 with normal overwrite.

#### Command:

```
rmcpurge -s 0 -N
```

**Example:** Normal erase of RMC module in slot 0

```

cw_dts> rmcpurge -s 0 -N
[rmcpurge]
 RMC_P0: status=OK
0[!rmcpurge] OK

```

2. Purge all RMC modules with enhanced overwrite.

#### Command:

```
rmcpurge -s all -E
```

**Example:** Enhanced erase of all RMC modules

```

cw_dts> rmcpurge -s all -E
[rmcpurge]
 RMC_P0: status=OK
 RMC_P1: status=OK
 RMC_P2: status=OK
[!rmcpurge] OK

```

# Quick Start



## NOTE

Throughout this section, **yellow highlighted text** is used to denote user-defined or software-generated inputs. **Green highlighted text** is used to show changes in values, settings, or responses due to implementation of a software command.

This section provides guidance on how to quickly access the Removable Memory Cartridge (RMC) associated with the DTS1 CSfC unit. This section makes the following assumptions:

- A 28 VDC power supply is available.
- The Curtiss-Wright generated PSK is available.
- A computer with the following applications installed is available.
  - PuTTY application ([www.putty.org](http://www.putty.org))
  - 3rd-party AES256 key-unwrapping application ‡
  - 3rd-party HMAC hash generator application ‡

‡ Contact Curtiss-Wright for applications / source code.

## 6.1 Connections / Preparation



## CAUTION

Make sure no power is applied to DTS1 when inserting / removing RMC.



## NOTE

At a minimum, the DTS1 CSfC must have an RMC installed and be connected to both a computer and 28 VDC power source.

1. Turn door latch CCW, open door, and insert RMC into DTS1.
2. Connect lab power cable between 28 VDC source and DTS1 connector J1.
3. Connect lab utility cable between user computer Ethernet port and DTS1 connector J2.
4. Turn on 28 VDC source.
5. Log into user computer.



## NOTE

If unit has been initialized, do not press front panel KEY CLEAR button.

6. Push front panel KEY CLEAR button and hold for 5 seconds.
7. Start PuTTY application and configure as follows:
  - Connection Type: `SSH`
  - Port: `22`
  - Host Name or IP Address: `192.168.1.1`
8. Log into DTS1:
  - User name `admin`
  - Password `istrator`

## 6.2 Preparation (Initialization Procedure Only)

If the DTS1 / RMC has been previously configured with both hardware (HWFDE) and software (SWFDE) encryption active, prepare the unit as follows:

1. Delete HWFDE key. Type `cmkey --zero` or push DTS1 front panel KEY CLEAR button and hold for 5 seconds.



## NOTE

Due to code-sharing between DTS1 and DTS3 units, many CLI commands can include `-s 0` (slot 0) in the command line.

2. Stop services. Type `serv -s 0 --all 0` and press ENTER.

3. Unmount drive: Type `rmcctl -s 0 -U` and press ENTER.
4. Delete SWFDE container: Type `rmcctl -s 0 -D` and press ENTER.
5. Wipe RMC. Type `rmcctl -s 0 -W --force` and press ENTER.



**NOTE**

Refer to paragraph 12.3.23 **rmcctl** for information regarding **rmcctl** command results.

6. View RMC status. Type `rmcctl` and press ENTER.

**Example**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 0 0 -- ----- ---- na na na na 0 -----
[!rmcctl] OK

```

### 6.3 Initialization



**NOTE**

For DTS1 CSfC units, both HWFDE and SWFDE initialization / use is mandatory.



**NOTE**

In the following procedure, the PSK, DEK, HWFDE password and SWFDE password / passphrase will NOT be shown after being entered.

HWFDE / SWFDE must be initialized prior to first use and whenever changes to DEK, key storage location, password, or passphrase are desired. Refer to Figure 6.1 for an initialization overview flowchart. The numbers listed in the flowchart relate to the step numbers in the procedure.



**NOTE**

**Username** must be 1-15 characters; the HWFDE **password** must be 8 to 64 characters long, contain at least one number, one alpha character, and contain no special characters.

1. Obtain user token. Type `cmlogin -u username -p -I` and press ENTER.
  - User is prompted for password. Type `<password>` and press ENTER.
  - User is prompted to verify password. Type `<password>` and press ENTER.
    - ◆ User token and HMAC will be displayed.



**NOTE**

The PSK is provided on a removable label placed on top of DTS1 when shipped.

2. Using a 3rd-party application and factory supplied PSK, decrypt user token obtained in step 1. Save resulting decrypted user token for future use / logins.
3. Generate challenge. Type `cmlogin -u username -p -L` and press ENTER.
  - User is prompted for HWFDE password. Type `<password>` and press ENTER.
    - ◆ The challenge will be a random string 128 characters long.
4. Generate HMAC string using challenge generated in step 3 as input MESSAGE and unencrypted user token from step 2 as KEY.
5. Log into crypto module. Type `cmlogin -M generated HMAC string` and press ENTER.
6. Verify successful login. Type `cmlogin` and press ENTER.
  - ◆ CMLOGIN: state=login init=1 login=1 status=OK




Figure 6.1 Initialization Overview Flowchart

DDOC0099-0048

**NOTE**  
 <loc> refers to location (0 through 31) where key will be stored.

**NOTE**  
 The DEK is a user-generated 64 character string. There are no requirements other than being able to remember it.

7. Create / save encryption key. Type `cmkey --save <loc> -d -p` and press ENTER.

- User is prompted to enter user-generated DEK. Type `<User-generated DEK string>` and press ENTER.
- User is prompted to enter Curtiss-Wright-provided PSK. Type `<Curtiss-Wright provided PSK string>` and press ENTER.

8. Load encryption key. Type `cmkey --load <loc> -s 0` and press ENTER.

**NOTE**  
 To partition a drive, the number of partitions (-P 1, -P 2, etc.) and their size (in either percentage or physical size [i.e 10GB, 100GB, etc.]) must be contained in the command. For the purpose of this Quick Start Guide, the RMC has only 1 partition and it encompasses the entire drive.

**NOTE**  
 If any services / boot services are active, they must be turned off before partitioning / making changes to the state of the RMC. If required, type `serv -s 0 --all 0` and press ENTER.

9. Create partitions. Type `rmctl -s 0 -P 1 100% --force` and press ENTER.

**!** **NOTE**

The RMC module must have services assigned before SWFDE layer can be initialized.

10. Assign service: `rmcctl -s 0 -p 1 --serv NAS` and press ENTER.

**!** **NOTE**

Refer to paragraph 12.3.23 `rmcctl` for information regarding `rmcctl` command results.

11. View RMC status. Type `rmcctl` and press ENTER.

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 XX GB NAS 0 na 0 na 0 rmc0p1
[!rmcctl] OK

```

**!** **NOTE**

DTS1 CSfC units require use of SWFDE in addition to HWFDE.

**!** **NOTE**

Disks cannot be partitioned after SWFDE has been performed.

12. Initialize SWFDE. Type `rmcctl -s 0 -p 1 -C` and press ENTER.

- ◆ A warning will activate that SWFDE will overwrite all data.

13. When prompted about data overwrite, type: **YES** and press ENTER.

**!** **NOTE**

SWFDE passwords / passphrases must be:

- 15 to 512 characters long
- Use at least 1 upper case, 1 lower case, 1 number, and 1 special character
- Repeat no character more than 3 times
- Have no more than 4 consecutive characters from a character class (i.e lower case, upper case, etc.)
- If using a password, it must pass dictionary test

14. When prompted, enter **password / passphrase** to be used for activation of SWFDE.

15. Reenter the SWFDE **password / passphrase** to verify it.

16. Open SWFDE container. Type: `rmcctl -s 0 -p 1 -E` and press ENTER.

17. When prompted, enter same SWFDE **password / passphrase** as previously entered.

18. Format / mount drive. Type `rmcctl -s 0 -p 1 -F -M` and press ENTER.

**!** **NOTE**

Refer to paragraph 12.3.23 `rmcctl` for information regarding `rmcctl` command results.

19. View RMC status. Type `rmcctl` and press ENTER.

- ◆ DTS1 is ready to use with CSfC encryption.

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 XX GB NAS 1 1 ext4 1 0 rmc0p1
[!rmcctl] OK

```



## 6.4 Login



### NOTE

In the following procedure, the HWFDE password and SWFDE password / passphrase will NOT be shown after being entered.

After CSfC encryption has been initialized, subsequent use requires only following the login process. Refer to Figure 6.2 for a login overview flowchart. The numbers listed in the flowchart relate to the step numbers in the procedure.

1. Connect the user computer to the DTS1 and log in. Refer to paragraph 6.1 **Connections / Preparation** for detailed instructions.
2. Generate challenge. Type `cmlogin -u username -p -L` and press ENTER.
  - User is prompted for HWFDE password. Type `<password>` and press ENTER.
    - ◆ The challenge will be a random string 128 characters long.
3. Generate HMAC string using challenge generated in step 1 as input MESSAGE and unencrypted user token (generated during initialization) as KEY.




Figure 6.2 Login Overview Flowchart

4. Log into crypto module. Type `cmlogin -M generated HMAC string` and press ENTER.
5. Verify successful login. Type `cmlogin` and press ENTER.
  - ◆ `CMLOGIN: state=login init=1 login=1 status=OK`



### NOTE

<loc> refers to location (0 through 31) where key is stored.

6. Load encryption key. Type `cmkey --load <loc> -s 0` and press ENTER.



### NOTE

Refer to paragraph 12.3.23 `rmcctl` for information regarding `rmcctl` command results.

7. View RMC status. Type `rmcctl` and press ENTER.

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 XX GB NAS 1 0 na na 0 rmc0p1
[!rmcctl] OK

```

- 8. Open SWFDE container. Type `rmcctl -s 0 -p 1 -E` and press ENTER.
- 9. When prompted, enter same SWFDE **password / passphrase** as previously entered.
- 10. Mount drive. Type `rmcctl -s 0 -p 1 -M` and press ENTER.



**NOTE**

Refer to paragraph 12.3.23 **rmcctl** for information regarding **rmcctl** command results.

- 11. View RMC status. Type `rmcctl` and press ENTER.

◆ DTS1 is ready to use with CSfC encryption.

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 XX GB NAS 1 1 ext4 1 0 rmc0p1
[!rmcctl] OK

```



## 7.2 Basic Operation



### NOTE

Serial port access is recommended for initial configuration of the DTS1.

This topic describes how to use the DTS1 Command Line Interface (CLI) to configure the DTS1. Refer to **Command Line Interface** section for more information on the commands used in this topic. Changes to the DTS1 configuration must be performed through the admin account.

### 7.2.1 Communications



### NOTE

The DTS1 will auto log-off after 5 minutes of communications inactivity.

A copy of the PuTTY terminal emulator can be obtained from <https://www.putty.org/>.

A RS-232 serial data port is provided via utility connector (J2). A terminal emulation program (PuTTY) is used to communicate with the Command Line Interface (CLI) using the RS-232 port. Serial port accesses is recommended for initial configuration of the DTS1. The terminal emulation program should be set to 9600 bps, 8 bits, no parity, one stop bit, and no flow control.

The CLI is also accessible via Ethernet using Secure Shell (SSH). The default IP addresses are shown in Table 7.1.

**Table 7.1 Ethernet Interfaces**


| Connector | Port   | Interface | IP Address  | Subnet Mask   |
|-----------|--------|-----------|-------------|---------------|
| J2        | Port 0 | eth0      | 192.168.1.1 | 255.255.255.0 |
| J3        | Port 1 | eth1      | 192.168.2.1 | 255.255.255.0 |

Simple Network Management Protocol (SNMP) is also available to communicate with the DTS1. See **Simple Network Management Protocol** section for details.

#### 7.2.1.1 Terminal Emulation

This section explains setting up communications using serial communication (RS-232) and a PuTTY terminal emulator.

1. If not previously accomplished, download a copy of PuTTY terminal emulator and install on computer.
2. Open PuTTY terminal emulator (Figure 7.2).



DDOC0099-0032


**Figure 7.2 PuTTY Terminal Emulator (Serial Data)**

3. Configure PuTTY as follows:
  - Connection type: Serial
  - Serial line: COM1 (example - any computer serial port can be utilized)
  - Speed: 9600
4. Click **Open** button.
  - ◆ A terminal screen should activate.
5. Click **Enter** button.
  - ◆ A login prompt should activate.
6. Log into CLI as follows:
  - a. At the login prompt type **admin**.
  - b. At the password prompt type **istrator**.

### 7.2.1.2 Ethernet

This section explains setting up communications using secure shell (SSH) and a PuTTY terminal emulator.

1. If not previously accomplished, download a copy of PuTTY terminal emulator and install on computer.
2. Open PuTTY terminal emulator (Figure 7.3).



DDOC0099-0003

**Figure 7.3 PuTTY Terminal Emulator (SSH)**

3. Configure PuTTY as follows:
  - Connection Type: SSH
  - Port: 22
  - Host Name (or IP Address): see Table 7.1
4. Click **Open** button.
  - ◆ A terminal screen should activate.
5. Click **Enter** button.
  - ◆ A login prompt should activate.

6. Log into CLI as follows:
  - a. At the login prompt type **admin**.
  - b. At the password prompt type **istrator**.

## 7.2.2 IP Address

The default IP addresses can be changed if desired.

1. To change the eth0 IP address (utility connector J2), type:

```
cw_dts> ipconfig -e eth0 -i [desired IP address]
```

2. To change the eth1 IP address (Ethernet connector J3), type:

```
cw_dts> ipconfig -e eth1 -i [desired IP address]
```

3. To change the eth0 IP address and netmask, type:

```
cw_dts> ipconfig -e eth0 -i [desired IP address] -n [desired netmask]
```

### ! NOTE

The DTS1 can be configured as a DHCP client if desired. When configured in this manner, the IP address is set remotely by a DHCP server.

4. Configure the DTS1 as a DHCP client as follows:
  - a. To configure Ethernet port 0 type **ipconfig -e eth0 -D -F** and press ENTER key.
  - b. To configure Ethernet port 1 type **ipconfig -e eth1 -D -F** and press ENTER key.
5. To check DHCP status, type **ipconfig -V** and press ENTER key.

### ! NOTE

The green highlighted text below is assigned by the DHCP server.

### Example

```
cw_dts> ipconfig -V
[ipconfig]
 STS_ETH_0: link=1000 ip=10.19.6.64 nm=255.255.240.0 gw=10.19.1.5 status=OK
 STS_ETH_1: link=1000 ip=NA nm=NA gw=NA status=OK
 CFG_ETH_0: prot=dhcp status=OK
 CFG_ETH_1: prot=static ip=192.168.2.1 nm=255.255.255.0 gw=NA status=OK
[!ipconfig] OK
```

## 7.2.3 Account Management

The DTS1 operating system has two accounts:

- admin (default password is istrator)
- user (default password is password)

The admin account is used to setup and configure the unit via the CLI. The user account can only access the RMC module and cannot change or update any operational parameters.

The Hardware Encryption (HWE) layer and Software Encryption (SWE) layer each have one account. These accounts are independent of the DTS1 accounts. Refer to paragraph 5.3 **Hardware Layer Encryption** and paragraph 5.4 **Software Layer Encryption** for additional information.

## 7.2.4 Passwords

### ! NOTE

The administrator can configure the unit using the Command Line Interface (CLI).

#### Administrator

- Username: **admin**
- Password: **istrator**

**!** **NOTE**

The user can access the drives configured as network storage. The user cannot access the CLI.

**User**

- Username: **user**
- Password: **password**

**!** **NOTE**

The admin account has configuration privileges while the user account has access to only network storage functionality.

To change admin account password, type **password -u admin -p [desired password]** and press ENTER key.

**Example**

```
cw_dts> password -u admin -p [desired password]
```

To change user account password, type **password -u user -p [desired password]** and press ENTER key.

**Example**

```
cw_dts> password -u user -p [desired password]
```

The DTS1 software will prompt for the new password when -p command is used.

## 7.2.5 Time / Date

The time and date appear in some status displays and messages.

To display the current date and time, type **sysdate** and press ENTER key.

**Example**

```
cw_dts> sysdate
```

**!** **NOTE**

The date must be entered as yyyy/mm/dd. The time must be entered as hh:mm:ss

To change the current date, type **sysdate -d yyyy/mm/dd** and press ENTER key.

**Example**

```
cw_dts> sysdate -d yyyy/mm/dd
```

To change the current time, type **sysdate -t hh:mm:ss** and press ENTER key.

**Example**

```
cw_dts> sysdate -t hh:mm:ss
```

To change the current date and time, type **sysdate -d yyyy/mm/dd -t hh:mm:ss** and press ENTER key.

**Example**

```
cw_dts> sysdate -d yyyy/mm/dd -t hh:mm:ss
```

## 7.3 Login

Logging into the DTS1 is a three-part process. Before the RMC module can be accessed or configured, the user must (in the following order):

1. Log into DTS1.
2. Initialize HWE layer.
3. Log into HWE layer.

## 7.4 Encryption

The DTS1 uses two layers of encryption:

- Hardware encryption layer
- Software encryption Layer

The user is required to use the CLI to issue initialization and key management commands.

### 7.4.1 Hardware Encryption Layer

Refer to paragraph 5.3 **Hardware Layer Encryption** for detailed instructions on how to create / log into the HWE layer.

### 7.4.2 Software Encryption Layer

Refer to paragraph 5.4 **Software Layer Encryption** for detailed instructions on how to create / log into the SWE layer.

### 7.4.3 Zeroize / Delete SWE Container / RMC Purge



#### CAUTION

LOSS OF CONTENT. Deletion of SWE container(s) will result in making the stored content unrecoverable.

- The destruction of the HWE layer key is accomplished via zeroization.
- The SWE layer passphrase(s) is / are destroyed via deleting the SWE container(s).
- The RMC module data is destroyed via the `rmcpurge` command.

Refer to paragraph paragraph 5.5 **Zeroize HWE Key / Delete SWE Container / RMC Purge** for additional information,

## 7.5 Storage Media



#### NOTE

The DTS1 must have the hardware encryption layer initialized and open before the RMC module (storage media) can be accessed.

If desired, the RMC module disk can be used without partitioning. The unpartitioned disk must have services started and assigned before formatting and mounting. Refer to paragraph 6.6 Services for additional information.

### 7.5.1 Preparation for Partition

The following steps must be done in sequential order.

1. Stop services.

#### Commands:

```
Stop services: serv -a 0
Stop iSCSI targets: istarget --stop
Stop PCAP recording: pcap --stop
```

2. Unmount drive.

#### Command

```
rmctl -U
```



#### CAUTION

DATA LOSS. If the RMC has been previously used with full hardware and software encryption applied, erasing all partitions will delete the SWE container(s) and result in the loss of all data on the drive.

3. Erase existing partitions.

#### Command:

```
rmctl -W --force
```



4. Check drive status.



**NOTE**

Refer to paragraph 12.3.23 **rmcctl** for information regarding the **rmcctl** status indications.

**Command:**

**rmcctl**

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 -- 100GB NONE 0 na 0 na 0 ----
[!rmcctl] OK

```

**7.5.2 Partition Disk**

Create 1 partition on a 100GB RMC module.

**Command:**

**rmcctl -P 1 100%**

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 100GB NONE 0 na 0 na 0 ----
[!rmcctl] OK

```

Create 2 partitions on a 100GB RMC module, each with 50%.

**Command:**

**rmcctl -P 2 50% 50%**

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 50 GB NONE 0 na 0 na 0 ----
RMC_S0: 1 1 1 2 50 GB NONE 0 na 0 na 0 ----
[!rmcctl] OK

```

Create 4 partitions on a 100GB RMC module, each with 25%.

**Command:**

**rmcctl -P 4 25% 25% 25% 25%**

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 25 GB NONE 0 na 0 na 0 ----
RMC_S0: 1 1 1 2 25 GB NONE 0 na 0 na 0 ----
RMC_S0: 1 1 1 3 25 GB NONE 0 na 0 na 0 ----
RMC_S0: 1 1 1 4 25 GB NONE 0 na 0 na 0 ----
[!rmcctl] OK

```

Create 4 partitions on a 100GB RMC module as follows: 10GB, 50GB, 20GB, 20GB.



**NOTE**

Partition must be 100MB or greater.

**Command:**

**rmcctl -P 4 10GB 50GB 20GB 20GB**

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 10 GB NONE 0 na 0 na 0 ----
RMC_S0: 1 1 1 2 50 GB NONE 0 na 0 na 0 ----
RMC_S0: 1 1 1 3 20 GB NONE 0 na 0 na 0 ----
RMC_S0: 1 1 1 4 20 GB NONE 0 na 0 na 0 ----
[!rmcctl] OK

```

**7.5.3 Services**

Services are not available until the drive is mounted as a NAS drive.

**7.5.3.1 Assign Services**



**NOTE**

Services can be assigned to an unpartitioned or partitioned RMC module.

Assign NAS services to an unpartitioned 100GB RMC module.

**Command:**

```
rmcctl --serv NAS
```

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 100GB NAS 0 na 0 na 0 rmc0
[!rmcctl] OK

```

Assign NAS services to partition 1 of a 100GB RMC module with one partition.

**Command:**

```
rmcctl -p 1 --serv NAS
```

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 100GB NAS 0 na 0 na 0 rmc0p1
[!rmcctl] OK

```

Assign NAS services to partitions 1 and 2 of a 100 GB RMC module with three partitions.



**NOTE**

Must be done as two separate commands.

**Command:**

```

rmcctl -p 1 --serv NAS
rmcctl -p 2 --serv NAS

```

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 33 GB NAS 0 na 0 na 0 rmc0p1
RMC_S0: 1 1 1 2 33 GB NAS 0 na 0 na 0 rmc0p2
RMC_S0: 1 1 1 3 33 GB NONE 0 na 0 na 0 ----
[!rmcctl] OK

```

Assign NAS services to partitions 1 through 4 of a RMC module with four partitions.

**Command:**

```
rmcctl -p all --serv NAS
```

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 25 GB NAS 0 na 0 na 0 rmc0p1
RMC_S0: 1 1 1 2 25 GB NAS 0 na 0 na 0 rmc0p2
RMC_S0: 1 1 1 3 25 GB NAS 0 na 0 na 0 rmc0p3
RMC_S0: 1 1 1 4 25 GB NAS 0 na 0 na 0 rmc0p4
[!rmcctl] OK

```

**7.5.3.2 Boot Services**

Set one or multiple services to start on boot-up.

**Command:**

```
serv -B --[service name] 1
```

Where [service] is one (or more) of the following: cifs; dhcp; ftp; http; nfs; snmp; tftp; tel.

**Example Command:** `serv -B --cifs 1 --ftp 1 --http 1 --nfs 1`

**Example of Serv Status**

```

cw_dts> serv -B --cifs 1 --ftp 1 --http 1 --nfs 1
[serv]
BOOTCFG cifs=1 nfs=1 ftp=1 http=1 dhcp=0 tftp=0 tel=0 snmp=0 status=ok
LIVECFG cifs=0 nfs=0 ftp=0 http=0 dhcp=0 tftp=0 tel=0 snmp=0 status=ok
[!serv] OK

```

Set all services to start on boot-up.

**Command:**

```
serv -B -a 1
```

**Example of Serv Status**

```

cw_dts> serv -B -a 1
[serv]
BOOTCFG cifs=1 nfs=1 ftp=1 http=1 dhcp=1 tftp=1 tel=1 snmp=1 status=ok
LIVECFG cifs=0 nfs=0 ftp=0 http=0 dhcp=0 tftp=0 tel=0 snmp=0 status=ok
[!serv] OK

```

**7.5.3.3 Restart Services**

Restart one or multiple services.

**Command:**

```
serv --[service name] 1
```

Where [service] is one (or more) of the following: cifs; dhcp; ftp; http; nfs; snmp; tftp; tel.

**Example Command:** `serv --cifs 1 --ftp 1 --http 1 --nfs 1`

**Example of Serv Status**

```

cw_dts> serv -cifs 1 --ftp 1 --http 1 --nfs 1
[serv]
BOOTCFG cifs=1 nfs=1 ftp=1 http=1 dhcp=0 tftp=0 tel=0 snmp=0 status=ok
LIVECFG cifs=1 nfs=1 ftp=1 http=1 dhcp=0 tftp=0 tel=0 snmp=0 status=ok
[!serv] OK

```

Restart all services.

**Command:**

```
serv -a 1
```

**Example of Serv Status**

```

cw_dts> serv -a 1
[serv]
BOOTCFG cifs=1 nfs=1 ftp=1 http=1 dhcp=0 tftp=0 tel=0 snmp=0 status=ok
LIVECFG cifs=1 nfs=1 ftp=1 http=1 dhcp=1 tftp=1 tel=1 snmp=1 status=ok
[!serv] OK

```

Transfer boot-up configuration to live configuration.

**Command:**

```
serv -a 2
```

**Example of RMC Module Status**

```

cw_dts> serv -a 2
[serv]
BOOTCFG cifs=1 nfs=1 ftp=1 http=1 dhcp=0 tftp=0 tel=0 snmp=0 status=ok
LIVECFG cifs=1 nfs=1 ftp=1 http=1 dhcp=0 tftp=0 tel=0 snmp=0 status=ok
[!serv] OK

```

**7.5.4 Assign Mount Point Names****! NOTE**

The RMC module must be partitioned to assign mount point names. Each mount point name must be unique. Mount point names must be between 1 and 32 characters, some names might be truncated depending on CLI.

Add a mount point name to a 100GB RMC module with 1 partition.

**Command:**

```
rmcctl --mntpoint [name]
```

**Example of RMC Module Status (Where [name]=alpha)**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 100GB NAS 0 na 0 na 0 alpha
[!rmcctl] OK

```

Change the mount point name of a 100GB RMC module with one partition.

**Command:**

```
rmcctl --mntpoint [name]
```

**Example of RMC Module Status (Where [name]=aaa)**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 100GB NAS 0 na 0 na 0 aaa
[!rmcctl] OK

```

Add a mount point name to partitions 1 and 2 of a 100 GB RMC module with two partitions.

**! NOTE**

Must be done as two separate commands.

**Command:**

```
rmcctl -p 1--mntpoint [name 1]
```

```
rmcctl -p 2--mntpoint [name 2]
```

**Example of RMC Module Status** (where partition 1 [name 1]= aaa and partition 2 [name 2]= bbb)

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 50 GB NAS 0 na 0 na 0 aaa
RMC_S0: 1 1 1 2 50 GB NAS 0 na 0 na 0 bbb
[!rmcctl] OK

```

**7.5.5 Format / Mount**

**7.5.5.1 Format Only**

**NOTE**  
 NTFS format is not supported on an unpartitioned RMC module.  
 Format an unpartitioned 100GB RMC module as ext4 (default).

**Command:**

```
rmcctl -F
```

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 100GB NAS 0 na ext4 0 0 rmc0
[!rmcctl] OK

```

**NOTE**  
 Add the force option (---force) if changing format from NTFS to ext4.  
 Format partition 1 of a 100 GB RMC module with two partitions as ext4 (default).

**Command:**

```
rmcctl -p 1 -F
```

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 50 GB NAS 0 na ext4 0 0 rmc0p1
RMC_S0: 1 1 1 2 50 GB NAS 0 na 0 na 0 rmc0p2
[!rmcctl] OK

```

**NOTE**  
 Add the force option (---force) if changing format from ext4 to NTFS.  
 Format partition 2 of a 100 GB RMC module with two partitions as NTFS.

**Command:**

```
rmcctl -p 2 -F --fs NTFS
```

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 50 GB NAS 0 na ext4 0 0 rmc0p1
RMC_S0: 1 1 1 2 50 GB NAS 0 na NTFS 0 0 rmc0p2
[!rmcctl] OK

```

Change format of partition 2 of a 100 GB RMC module with two partitions to ext4 (default).

**Command:**

`rmcctl -p 2 -F --force`

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 50 GB NAS 0 na ext4 0 0 rmc0p1
RMC_S0: 1 1 1 2 50 GB NAS 0 na ext4 0 0 rmc0p2
[!rmcctl] OK

```



**NOTE**

Add the force option (---force) if changing format from NTFS to ext4.

Format partitions 1 through 4 of a 100GB RMC module with four partitions to ext4 (default).

**Command:**

`rmcctl -p all -F`

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 25 GB NAS 0 na ext4 0 0 rmc0p1
RMC_S0: 1 1 1 2 25 GB NAS 0 na ext4 0 0 rmc0p2
RMC_S0: 1 1 1 3 25 GB NAS 0 na ext4 0 0 rmc0p3
RMC_S0: 1 1 1 4 25 GB NAS 0 na ext4 0 0 rmc0p4
[!rmcctl] OK

```



**NOTE**

Add the force option (---force) if changing format from ext4 to NTFS.

Format partitions 1 through 4 of a 100GB RMC module with four partitions to NTFS.

**Command:**

`rmcctl -p all -F -fs NTFS`

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 25 GB NAS 0 na NTFS 0 0 rmc0p1
RMC_S0: 1 1 1 2 25 GB NAS 0 na NTFS 0 0 rmc0p2
RMC_S0: 1 1 1 3 25 GB NAS 0 na NTFS 0 0 rmc0p3
RMC_S0: 1 1 1 4 25 GB NAS 0 na NTFS 0 0 rmc0p4
[!rmcctl] OK

```

**7.5.5.2 Format / Mount**



**NOTE**

NTFS format is not supported on an unpartitioned RMC module.

Format (ext4) / mount an unpartitioned 100GB RMC module.

**Command:**

`rmcctl -F -M`

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 100GB NAS 0 na ext4 1 0 rmc0
[!rmcctl] OK

```



**NOTE**

Add the force option (`---force`) if changing format from NTFS to ext4.

Format (ext4) / mount partition 1 of a 100GB RMC module with two partitions.

**Command:**

```
rmcctl -p 1 -F -M
```

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 50 GB NAS 0 na ext4 1 0 rmc0p1
RMC_S0: 1 1 1 2 50 GB NAS 0 na 0 na 0 rmc0p2
[!rmcctl] OK

```



**NOTE**

Add the force option (`---force`) if changing format from ext4 to NTFS.

Format (NTFS) / mount partition 2 of a 100GB RMC module with two partitions.

**Command:**

```
rmcctl -p 2 -F --fs NTFS -M
```

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 50 GB NAS 0 na ext4 1 0 rmc0p1
RMC_S0: 1 1 1 2 50 GB NAS 0 na NTFS 1 0 rmc0p2
[!rmcctl] OK

```

Change mounted partition 2 format from NTFS to ext4 of a 100GB RMC module with two partitions.

**Command:**

```
rmcctl -p 2 -F --force
```

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 50 GB NAS 0 na ext4 1 0 rmc0p1
RMC_S0: 1 1 1 2 50 GB NAS 0 na ext4 1 0 rmc0p2
[!rmcctl] OK

```



**NOTE**

Add the force option (`---force`) if changing format from NTFS to ext4.

Format (ext4) / mount partitions 1 through 4 of a 100GB RMC module.

**Command:**

```
rmcctl -p all -F -M
```

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 25 GB NAS 0 na ext4 1 0 rmc0p1
RMC_S0: 1 1 1 2 25 GB NAS 0 na ext4 1 0 rmc0p2
RMC_S0: 1 1 1 3 25 GB NAS 0 na ext4 1 0 rmc0p3
RMC_S0: 1 1 1 4 25 GB NAS 0 na ext4 1 0 rmc0p4
[!rmcctl] OK

```

**! NOTE**

Add the force option (`--force`) if changing format from ext4 to NTFS.

Format (NTFS) / mount partitions 1 through 4 of a 100GB RMC module.

**Command:**

```
rmcctl -p all -F --fs NTFS -M
```

**Example of RMC Module Status**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcryp osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 25 GB NAS 0 na NTFS 1 0 rmc0p1
RMC_S0: 1 1 1 2 25 GB NAS 0 na NTFS 1 0 rmc0p2
RMC_S0: 1 1 1 3 25 GB NAS 0 na NTFS 1 0 rmc0p3
RMC_S0: 1 1 1 4 25 GB NAS 0 na NTFS 1 0 rmc0p4
[!rmcctl] OK

```

**7.5.6****iSCSI****! NOTE**

The hardware encryption must be active before initiating iSCSI operation. If software encryption is going to be used, it must be active before initiating iSCSI operation as well.

The DTS1 supports use of Internet Small Computer System Interface (iSCSI). It is configured to use either Ethernet port 0 or port 1. The desired Ethernet port must have an active link before running `istarget`.

1. To start iSCSI services:
  - a. Type `serv -a 0` and press ENTER key.
  - b. Type `rmcctl --serv iSCSI0 --force` and press ENTER key.
  - c. Type `serv -a 2` and press ENTER key.
  - d. Type `istarget --start` and press ENTER key.

**Example**

```

cw_dts> istarget --start
[istarget]
RMC_S0_P1_L0: iqn.2015-05.net.cwnas.iscsi:rmc0p1 is_tgt_en=1 status=OK
[istarget] OK

```

2. To check iSCSI status, type `istarget` and press ENTER key.

**Example**

```

cw_dts> istarget
[istarget]
RMC_S0_P1_L0: iqn.2015-05.net.cwnas.iscsi:rmc0p1 is_tgt_en=1 status=OK
[istarget] OK

```

3. To check RMC module services, type `rmcctl` and press ENTER key.



**Example**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 --- 100GB iSCSI na na na na 0 -----
[!rmcctl] OK

```

4. To stop iSCSI service type `istarget --stop` and press ENTER key.

**Example**

```

cw_dts> istarget --stop
[istarget]
RMC_S0_P1_L0: iqn.2015-05.net.cwnas.iscsi:rmc0p1 is_tgt_en=0 status=OK
[!istarget] OK

```

## 7.6 PCAP

**! NOTE**

The hardware encryption must be active before initiating PCAP operation. If software encryption is going to be used, it must be active before initiating PCAP operation as well.

The DTS1 supports use of the PCAP command to capture packets traveling over a network. Two data streams may be captured at any one time (Ethernet ports 0 and 1). A unique file name must be used with each recording in order to retain all recordings.

1. If not previously accomplished, type `rmcctl --serv NAS` and press ENTER key.
2. If not previously accomplished, type `rmcctl -F -M` and press ENTER key.

**! NOTE**

Both Ethernet ports can be used simultaneously to capture packets.

3. To start capturing packets:
  - a. Via Ethernet port 0, type `pcap -i eth0 -s 0 --start [file name 1]` and press ENTER key.

**Example**

```

cw_dts> pcap -i eth0 -s 0 --start [file name 1]
[pcap]
Start PCAP recording on eth0 to /rmc_shares/rmc0/[file name 1]
recording started
[!pcap] OK

```

- b. Via Ethernet port 1, type `pcap -i eth1 -s 0 --start [file name 2]` and press ENTER key.

**Example**

```

cw_dts> pcap -i eth1 -s 0 --start [file name 2]
[pcap]
Start PCAP recording on eth1 to /rmc_shares/rmc1/[file name 2]
recording started
[!pcap] OK

```

4. To get pcap status, type `pcap --stat` and press ENTER key.

**Example**

```

cw_dts> pcap --stat
[pcap]
PCAP recorder active
Interface eth0: Recorded 479232 Bytes (468K) to /rmc_shares/rmc0/[file name 1]
Interface eth1: Recorded 0 Bytes (0) to /rmc_shares/rmc0/[file name 2]
[!pcap] OK

```

**NOTE**

Ethernet port captures can be stopped independently or simultaneously.

5. To stop capturing packets:
  - a. from Ethernet port 0, type `pcap -i eth0 --stop` and press ENTER key.

**Example**

```

cw_dts> pcap -i eth0 --stop
[pcap]
Stopping active PCAP recording on eth0
[!pcap] OK

```

- b. from Ethernet port 1, type `pcap -i eth1 --stop` and press ENTER key.

**Example**

```

cw_dts> pcap -i eth1 --stop
[pcap]
Stopping active PCAP recording on eth0
[!pcap] OK

```

- c. from Ethernet port 0 and 1, type `pcap --stop` and press ENTER key.

**Example**

```

cw_dts> pcap --stop
[pcap]
Stopping active PCAP recording on eth0.
Stopping active PCAP recording on eth1.
[!pcap] OK

```

6. To start capturing packets and overwriting the previous capture, type `pcap -i eth0 -s 0 -start [file name 1] --ov` and press ENTER key.

**Example**

```

cw_dts> pcap -i eth0 -s 0 --start [file name 1] --ov
[pcap]
Start PCAP recording on eth0 to /rmc_shares/rmc0/[file name 1]
recording started
[!pcap] OK

```

7. To start capturing packets without overwriting the previous captures, type `pcap -i eth0 -s 0 --start [file name 3]` and press ENTER key.

**Example**

```

cw_dts> pcap -i eth0 -s 0 --start [file name 3]
[pcap]
Start PCAP recording on eth0 to /rmc_shares/rmc0/[file name 3]
recording started
[!pcap] OK

```

## 7.7 Health

The DTS1 has internal sensors that monitor critical environmental and operational parameters. The software provides this information to the user via the CLI when commanded. A FAIL status will be posted for any values that are out of tolerance.

### 7.7.1 Sens

To view operating voltages and temperatures and their status type `sens` and press ENTER key.

**NOTE**

Values provided in example are typical. As long as the sensed value is between MIN and MAX it is acceptable.

**Example**

```

cw_dts> sens
[sens]

```

| VOLTAGES   |       |       |       |        |
|------------|-------|-------|-------|--------|
| SENSOR     | VALUE | MIN   | MAX   | STATUS |
| V_ETH_CORE | 1.04  | 1.00  | 1.10  | Pass   |
| V_ETH_VDDa | 1.86  | 1.70  | 2.10  | Pass   |
| V_ETH_VDDd | 1.90  | 1.70  | 2.10  | Pass   |
| V_ETH_VDD  | 1.81  | 1.60  | 2.00  | Pass   |
| V_MAIN_12V | 11.98 | 11.00 | 13.00 | Pass   |
| V_V5.0     | 4.89  | 4.50  | 5.50  | Pass   |
| V_V3.3     | 3.31  | 3.00  | 3.60  | Pass   |
| V_RMC0_12  | 12.02 | 11.00 | 13.00 | Pass   |
| V_RMC0_5   | 5.03  | 4.50  | 5.50  | Pass   |
| V_RMC0_3   | 3.30  | 3.00  | 3.60  | Pass   |
| CAP_OK     | 1     | -     | -     | Pass   |
| V_CRYPT    | 3.67  | 3.40  | 3.90  | Pass   |

| TEMPERATURES |       |     |     |        |
|--------------|-------|-----|-----|--------|
| SENSOR       | VALUE | MIN | MAX | STATUS |
| T_COMF       | 37    | -45 | 90  | Pass   |
| T_COMM       | 42    | -45 | 90  | Pass   |
| T_COMR       | 38    | -45 | 90  | Pass   |
| T_VREG       | 43    | -45 | 90  | Pass   |
| T_PSUT       | 38    | -45 | 90  | Pass   |
| T_PSUB       | 38    | -45 | 90  | Pass   |
| T_RMC0_DR    | 35    | -45 | 90  | Pass   |
| T_RMC0_DF    | 38    | -45 | 90  | Pass   |
| T_CRYPT      | 40    | -45 | 90  | Pass   |

| ADVANTECH HWMON SENSORS |       |       |     |        |
|-------------------------|-------|-------|-----|--------|
| SENSOR                  | VALUE | MIN   | MAX | STATUS |
| V_12                    | 11.79 | 11.00 | 1   | Pass   |
| CORE0                   | 46    | 0     | 110 | Pass   |
| CORE1                   | 46    | 0     | 110 | Pass   |
| CORE2                   | 46    | 0     | 110 | Pass   |
| CORE3                   | 46    | 0     | 110 | Pass   |

```

[!sens] OK

```

**7.8 Built In Test**

**7.8.1 IBIT (Initiated BIT)**



**NOTE**

Results will be provided as 1 (Pass), 0 (Fail), and NA (function not active)

The `ibit` command provides a snap-shot of the DTS1 status. To view status, type `ibit` and press ENTER key.

- `IBIT_MON` line provides results for system monitor subsystem.
- `IBIT_ETH` line provides results for Ethernet subsystem.
- `IBIT_RMC#` line provides results for RMC module in slot #

**Example**

```

cw_dts> ibit
[ibit]
 IBIT_MON: mcu=1/0 i2c=1/0 volt=1/0 status=OK/ERR
 IBIT_ETH: eth0=1/0 eth1=1/0
 IBIT_RMC0: volt=1/0/NA ata=1/0/NA smart=1/0/NA status=OK/ERR
[!ibit] <summary>

```

**7.8.2 MBIT (Maintenance BIT)**

The `mbit` command is used with various options to perform maintenance built-in tests. Several of these tests either destroy or may destroy data on the RMC module. As a result, to perform these tests use of a `--go` option along with command option is required.

**CAUTION**

DATA LOSS. Use of following command options may / will destroy data on the RMC module.

Use --disk option to run disk test on the RMC module or on a partition.

Use --fsck option to run file system check on the RMC module on a partition.

Use --fsckauto option to fix simple problems without intervention.

Use --fsckyes to auto-repair problems by assuming yes to all repair prompts.

For additional information refer to paragraph 12.3.17 **mbit**.

## 7.9 Update Software / Firmware

### 7.9.1 Update Operating System Software

**CAUTION**

UPDATE ERROR / FAILURE. Before attempting to update the DTS1, the Write-Enable switch **MUST** be in the **READ-WRITE** position.

**CAUTION**

UPDATE ERROR / FAILURE. Before attempting any software / firmware updates, ensure the RMC module has been removed. Failure to remove the RMC module may result in update errors / failure.

**NOTE**

All updates to software / firmware should be accomplished using RS-232 serial data protocol.

**NOTE**

Contact Curtiss-Wright to obtain any available / applicable update files.

Before attempting to update the DTS1, set the write-enable switch to the **READ-WRITE** position. Refer to paragraph 3.2.2 **Write-Enable Switch** for detailed location information. After updating the unit, set the write-enable switch to the **READ** position.

The update files should be received from Curtiss-Wright as a tarball (compressed files package). The tarball will have to be uncompressed and the digital signature verified before loading the files into the DTS1 flash memory.

The fupdate command boots the DTS1 system into a RAM disk image where the user can install a new disk image onto the system. Upon logging into the new RAM disk image, a menu of operations to restore and verify the restoration of a new disk image activates.

**NOTE**

The fupdate command loads an image into memory to allow the user to update the boot image on the unit.

1. Type `fupdate` and press ENTER key.
  - ◆ The update utility will start.
2. If using Linux OS, save the operating system image to the DTS1 as follows:
  - a. Type `ip addr` and press ENTER.
  - b. DTS1 **IP address** will be shown.
  - c. Type `scp dts1_image_year_month_day-ver_#_##.tar root@IP_ADDRESS:/updates` and press ENTER.
3. If using Windows OS, save the operating system image to the DTS1 updates folder via a utility such as Win SCP.
4. Typically, the update file name should appear above the displayed menu (Figure 7.4) (e.g., `dts1_image_year_month_day-ver_#_##.tar`).
5. Select **3) Verify digital signature, md5sum and program image into DTS1 flash** and press ENTER key.
6. The DTS1 examines the digital signature to determine if the tarball has been compromised.
  - ◆ If tarball is uncompromised the update process will begin. If the tarball has been changed for any reason, the update process aborts.

```

root@dell-centos7:~
Curtiss-Wright DTS Flash Utility
Main Menu
Image File: dts_image_2018_jan_26_ver_2_01_00-fips.tar
Device: /dev/sda
#####
Commands to program the DTS onboard flash
#####
1) Scan for uploaded tarballed flash image
2) Force rescan for flash device (uncommon)
3) Verify digital signature, md5sum, and program image into DTS flash
4) Verify programmed DTS flash against md5 file
#####
Commands to backup the DTS onboard flash
#####
5) Set Major revision number for flash backup file ... Currently 1
6) Set Minor revision number for flash backup file ... Currently 0
7) Set Patch revision number for flash backup file ... Currently 0
8) Set FIPS mode for flash backup file ... Currently 0
9) Backup the flash and generate tarball
#####
0) Command Line Shell
r) Reboot
?
CTRL-A Z for help | 9600 8N1 | NOR | Minicom 2.6.2 | VT102 | Offline

```

Figure 7.4 DTS1 Update Utility

7. The update process will continue for approximately 3 to 5 minutes.
8. Power unit OFF and back ON to boot the new image.

## 7.9.2 Update Crypto Firmware



### CAUTION

RENDER INOPERABLE. Once the crypto firmware update is started, it must not be interrupted. If the update is interrupted, the DTS1 will be rendered inoperable.



### NOTE

For DTS1 units with operating software version prior to 3.00.00, the crypto firmware update will take approximately 90 minutes. For unit with operating system software 3.00.00 or later, the crypto firmware update will take approximately 10 minutes

Before updating crypto firmware:

- Ensure you are logged into the crypto module.
  - Ensure an RMC is installed in the DTS1.
1. Copy crypto firmware update files to mounted RMC via NFS/CIFS/FTP/etc. to /rmc\_shares/rmc0p1.
  2. Type `cmfwupdate -f DTS_v5.x_CSfC.bin -s DTS_v5.x_CSfC_signature.bin` and press Y.
    - ◆ Crypto firmware update begins.
  3. After update is complete, wait 10 seconds and then power unit OFF and back ON.

### Example

```

cw_dts> cmfwupdate -f DTS_v5.2_CSfC.bin -s DTS_v5.2_CSfC_signature.bin
[cmfwupdate]
The Trusted Firmware Update takes approximately 10 minutes to complete.
During the process you shall not operate or powerdown the device.
Interrupting this process can brick the device leaving it inoperable.
Proceed? y/n: y
STATUS: Activity[.....]
.....]
Update Complete. Please wait 10 seconds to power cycle the unit.
status=OK
[!cmfwupdate] OK

```

## 7.10 Access from Windows as NAS Device

### ! NOTE

When the partitions are formatted and mounted, they can be accessed from a PC running Windows.

1. Log into the DTS1 via SSH. Refer to paragraph 7.2.1.2 **Ethernet**.
2. Type `rmcctl` and press ENTER key.
  - ◆ The RMC module must have NAS services assigned, be formatted (fmt=ext4 or NTFS). and mounted (mnt=1). See Example.

### Example

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 -- 100GB NAS 0 na ext4 1 0 rmc0
[!rmcctl] OK

```

3. If required, format and mount RMC module as follows:
  - a. Type `rmcctl --serv NAS` and press ENTER key
  - b. Type `rmcctl -F -M` and press ENTER key.
4. Type `serv` and press ENTER key to see if CIFS and NFS is enabled.
  - ◆ NFS enabled: `nfs=1` NFS disabled: `nfs=0`
  - ◆ CIFS enabled: `cifs=1` CIFS disabled: `cifs=0`
5. If NFS is disabled type `serv --nfs 1` and press ENTER key.
6. If CIFS is disabled type `serv --cifs 1` and press ENTER key.
7. Open a File Explorer window.
8. Enter the IP address of the DTS1 in the address bar.

**Example** \\192.168.1.1\

9. Login as user:
  - a. Type `user` at user name prompt.
  - b. Type `password` at password prompt.

## 7.11 Access from Linux as NAS Device

### ! NOTE

When the partitions are formatted and mounted, they can be accessed from a PC running Linux.

### ! NOTE

This procedure is performed via Ethernet connected to DTS1 port 0.

1. Open a terminal window
2. Type `ssh admin@192.168.1.1`.
3. Press ENTER key.
4. Type `istrator` for password.
5. Press ENTER key.
6. Type `serv` and press ENTER key to see if NFS is enabled.
  - ◆ NFS enabled: `nfs=1` NFS disabled: `nfs=0`
7. If NFS is disabled type `serv --nfs 1`.

8. In the terminal window on the Linux PC:
  - a. Create a mount point.
  - b. Mount to the storage device.

Example

```
mkdir /rnc0
```

```
mount -t nfs 192.168.1.1:/rnc_shares/rnc_nas0 /fs
```

# System Configuration

The commands below are used to configure the crypto module, DTS1, and associated RMC module.

## 8.1 Crypto Module

The `cmlogin` command allows for initialization of / logging into the Hardware Encryption (HWE) crypto module. For status information, issue `cmlogin` without options. Refer to paragraph 12.3.5 **cmlogin** for detailed information about initializing / logging into the HWE crypto module.

The `cmkey` command allows for management of keys on the HWE crypto module. For status information, issue `cmkey` without options. Refer to paragraph 12.3.3 **cmkey** for detailed information about configuring the crypto module.

### 8.1.1 Initialize / Log In



#### NOTE

`[username]` and `[password]` are selected and entered by the user.

```
cmlogin -u [username] -p [password] -IInitialize HWE crypto module.
cmlogin -u [username] -p [password]Log into HWE crypto module.
cmlogin -M.....Authorize HWE crypto module
password.
```

### 8.1.2 Key Load / Unload

```
cmkey --autoAuto-load the saved key for RMC module.
cmkey --loadLoad a saved key for RMC module.
cmkey --unload.....Unload/zeroize key from RMC module.
```

### 8.1.3 Key Removal / Zeroize

```
cmkey --delDelete/zeroize a saved key.
cmkey -zZeroize crypto module. Clears any saved / loaded key.
cmkey --zpskZeroize the crypto unit PSK.
```

### 8.1.4 Key Commands

```
cmkey --saveSave key to non-volatile memory location (0-31).
cmkey -eEncrypted DEK (data encryption key) 40 byte value represented
by 80 hex characters.
cmkey -mMAC (message authentication code) 32 byte value represented
by 64 hex characters.
cmkey -pPlain Text PSK (pre-shared key) 32 byte value represented by 64
hex characters.
cmkey -dPlain Text DEK (data encryption key) 32 byte value represented
by 64 hex characters.
cmkey -kGenerates KEK (key encryption key).
cmkey -uUser defined plain text PSK (pre-shared key) 32 byte value
represented by 64 hex characters.
```

## 8.2 DTS1



#### CAUTION

**CONFIGURATION ACCESS.** Before attempting to setup or configure the DTS1, the Write-Enable switch **MUST** be in the **READ-WRITE** position.

Before attempting to configure the DTS1, set the write-enable switch to the **READ-WRITE** position. Refer to paragraph 3.2.2 **Write-Enable Switch** for detailed location information. After configuring the unit, set the write-enable switch to the **READ** position.

Refer to paragraph 12.3.12 **info** and paragraph 12.3.13 **ipconfig** for detailed information about configuring the DTS1.



## 8.2.1 Versions

The info command displays DTS hardware and software information, such as versions.

- info -A**.....Alternate short-form display.
- info -M**.....Show the media type(s) supported by each slot.
- info -R**.....Generate a status report of info useful for tech support.

## 8.2.2 Configure

The ipconfig command allows for configuration of an IP interface. By default, changes take effect on the next bootup.

- ipconfig -d**.....Use DHCP.
- ipconfig -e**.....Ethernet device: eth0, eth1. Default is 'all' when viewing status (see -V), otherwise eth0.
- ipconfig -g**.....Assign static gateway address. Use '.' to clear.
- ipconfig -i**.....Assign static IP address.
- ipconfig -m**.....View MAC address.
- ipconfig -n**.....Assign static IP netmask. Use '.' to clear.
- ipconfig -V**.....View interface status and configuration settings. Default action when other options absent.

## 8.3 RMC Module

### ! NOTE

The DTS1 has only 1 RMC module slot. As a result, the -s option is always -s 0.

Refer to paragraph 12.3.23 **rmcctl** and paragraph 12.3.29 **serv** for detailed information about configuring the RMC module.

The rmcctl command without options applied returns the RMC module status. When options are applied, the rmcctl command performs control tasks on the RMC modules, such as partitioning, formatting, mounting, and requesting removal.

### 8.3.1 RMCCTL Definitions

The rmcctl command without options is used to determine status. The response will be similar to that shown in the examples below.

#### Example - New RMC

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 na na -- ---- ---- na na na na 0 ----
[!rmcctl] OK

```

#### Example -HWE Active, 4 Partitions, SWE Active, formatted and Mounted

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 25 GB NAS 1 1 ext4 1 0 rmc0p1
RMC_S0: 1 1 1 2 25 GB NAS 1 1 ext4 1 0 rmc0p2
RMC_S0: 1 1 1 3 25 GB NAS 1 1 ext4 1 0 rmc0p3
RMC_S0: 1 1 1 4 25 GB NAS 1 1 ext4 1 0 rmc0p4
[!rmcctl] OK

```

- RMC\_S# .....RMC module slot number: DTS1 will always be 0.
- ins.....RMC module insertion status: 0 if no RMC module inserted; 1 if RMC module is inserted.
- hcrypt .....Hardware encryption: 0 if not ready; 1 if ready; na if not detected.
- osdr.....Operating system raw block device detection status: 0 if raw device not detected; 1 if raw device detected.

|              |                                                                                                                                            |
|--------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| p#.....      | Partition number: number of partitions present. Can be 0 to 128                                                                            |
| size.....    | Size of partitions: can be listed in MiB, MB, GiB, GB, TiB or TB. The minimum size allowed is 100MB.                                       |
| serv.....    | Services: can be none, iSCSI, NAS, or PCAP recording.                                                                                      |
| scryp .....  | Software encryption: 0 if no software encryption applied; 1 if software encryption is present                                              |
| osdm.....    | Operating system mapped block device detection status: 0 if software container is closed; 1 if software container is open                  |
| fmt.....     | Format: na / 0 if RMC module is unformatted; ext4 if RMC module is formatted ext4; ntfs if formatted ntfs                                  |
| mnt.....     | Mount: na / 0 if RMC module is unmounted; 1 if RMC module is mounted; ro is mounted read-only.                                             |
| rem.....     | Removal request status: 0 if not requested; RQ if requested; OK if ready for removal.                                                      |
| mtpoint..... | Mount point: Assign a mount point <name> to a partition. Limited to 32 characters, and may wrap or truncate depending on CLI terminal type |

### 8.3.2 Configure

|                            |                                                                                                                                                                                                                                                                                                                                     |
|----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>rmcctl -F</b> .....     | Format RMC module / partition. May take several minutes.                                                                                                                                                                                                                                                                            |
| <b>rmcctl -M</b> .....     | Mount RMC module / partition.                                                                                                                                                                                                                                                                                                       |
| <b>rmcctl -P</b> .....     | Create partition(s) on the RMC module disk. Size of partitions can be specified as percent of disk or sizes in MiB, MB, GiB, GB, TiB or TB. The minimum size allowed is 100MB. NAS services, iSCSI targets, and PCAP recordings need to be inactive, and the RMC module disk / partitions need to be unmounted to run this command. |
| <b>rmcctl --serv</b> ..... | Assign a service name to partition. Valid names are NONE, NAS, iSCSI, and iSCSI0/1.                                                                                                                                                                                                                                                 |
| <b>rmcctl -U</b> .....     | Unmount RMC module / partition.                                                                                                                                                                                                                                                                                                     |
| <b>rmcctl -W</b> .....     | Destructively clean the disk and any partitions. Must be used with the --force option.                                                                                                                                                                                                                                              |

### 8.3.3 Encrypt / Decrypt

|                        |                                                                              |
|------------------------|------------------------------------------------------------------------------|
| <b>rmcctl -C</b> ..... | Software encrypt RMC module. Passphrase is entered interactively.            |
| <b>rmcctl -D</b> ..... | Destructively overwrite S/W encryption information.                          |
| <b>rmcctl -E</b> ..... | Gain entry to S/W encrypted RMC module. Passphrase is entered interactively. |
| <b>rmcctl -X</b> ..... | Exit from S/W encrypted RMC module.                                          |

### 8.3.4 Insert / Remove

|                        |                                |
|------------------------|--------------------------------|
| <b>rmcctl -I</b> ..... | Undo request for removal (-R). |
| <b>rmcctl -R</b> ..... | Request RMC module removal.    |

### 8.3.5 Service

The serv command allows the user to set the boot configuration for DTS services and to manually start/stop services. When no options are given, the current boot configuration and active status is displayed for all the services.

|                      |                                                    |
|----------------------|----------------------------------------------------|
| <b>serv -a</b> ..... | All Services.                                      |
| <b>serv -B</b> ..... | Apply the settings to the boot-time configuration. |
| <b>serv -c</b> ..... | CIFS Service.                                      |
| <b>serv -d</b> ..... | DHCP Service.                                      |
| <b>serv -f</b> ..... | FTP Service.                                       |
| <b>serv -n</b> ..... | NFS Service.                                       |
| <b>serv -s</b> ..... | SNMP Service.                                      |
| <b>serv -t</b> ..... | TFTP Service.                                      |
| <b>serv -Z</b> ..... | Telnet Service.                                    |
| <b>serv -W</b> ..... | HTTP Read Service.                                 |

# Troubleshooting

The **ibit** command is able to detect many problems. While some problems may not have a user remedy, the problem(s) reported by the **ibit** CLI command should be recorded and discussed with a Curtiss-Wright service representative. The **mbit** CLI command can resolve some problems, but it will destroy stored data and formatting of the RMC module. The user should see **ibit** CLI command and **mbit** CLI command for additional information before using the commands.

The chart below provides a basic failure analysis by observing status indicators. If any one of the LEDs exhibits the failure status, the DTS1 may not function properly. The investigative/remedial actions offered should only be tried one or two times. Refer to paragraph 3.1 **Chassis Indicators** for information regarding front panel LEDs.

## 9.1 Chassis LED Fault Indicators



**NOTE**

If problems persist, contact Curtiss-Wright Defense Solutions Customer Support. Refer to paragraph 1.6 **Technical Support** for contact information.

Refer to Table 9.1 for chassis fault information.

**Table 9.1 Chassis LED Fault Indications**

| Symptoms/Condition              | Meaning                                                                                                                                               | Investigative/Remedial Action                                                                                                                                                                                                                                                                                   |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DTS1 red Fault LED on.          | Periodic Built In Test (PBIT) failed<br><br>Encryptor module failed one or more of the tests in the Error Codes table or a listed error has occurred. | <ol style="list-style-type: none"> <li>1. Run <b>ibit</b> CLI command. If the problem can be associated with the RMC module, run <b>mbit</b> CLI command.</li> <li>2. Cycle power and reinitialize the system.</li> <li>3. Run <b>cmkey</b> CLI command for an error report and reference Table 9.3.</li> </ol> |
| DTS1 green Power LED off        | Boot failed. Power not applied.                                                                                                                       | <ol style="list-style-type: none"> <li>1. Verify power is actually applied and at the correct level.</li> <li>2. Run <b>ibit</b> CLI command.</li> </ol>                                                                                                                                                        |
| DTS1 yellow Key Loaded LED off. | Encryption key not loaded or Zeroize button was pushed.                                                                                               | <ol style="list-style-type: none"> <li>1. Load encryption key.</li> <li>2. Run <b>cmkey</b> CLI command for an error report and reference Table 9.3.</li> </ol>                                                                                                                                                 |

## 9.2 RMC Module LED Fault Indications



**CAUTION**

**DATA LOSS.** Improper use of the **mbit** CLI command can destroy stored data and formatting of the RMC module



**NOTE**

If problems persist, contact Curtiss-Wright Defense Solutions Customer Support. Refer to paragraph 1.6 **Technical Support** for contact information.

The **ibit** command is able to detect many problems. While some problems may not have a user remedy, the problem(s) reported by the **ibit** CLI command should be recorded and discussed with a Curtiss-Wright service representative. The **mbit** CLI command can resolve some problems, but it will destroy stored data and formatting of the RMC module. The user should see **ibit** CLI command and **mbit** CLI command for additional information before using the commands.

**Table 9.2 RMC Module LED Fault Indications**

| Symptoms/Condition           | Meaning                     | Investigative/Remedial Action                                                                                                                               |
|------------------------------|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RMC module red Fault LED on. | Self-test failed            | 1. Run <b>ibit</b> CLI command. If the problem can be associated with the RMC module, run <b>mbit</b> CLI command.<br>2. Reseat RMC module and cycle power. |
| Cannot store data.           | RMC module may be full.     | Run <b>rmcfree</b> CLI command.                                                                                                                             |
| No access to RMC module.     | Cannot login to RMC module. | Encryptor battery dead. Replace battery. Refer to paragraph 10.2 <b>Battery</b> for detailed instructions.                                                  |

### 9.3 Encryptor Error Codes



#### NOTE

If problems persist, contact Curtiss-Wright Defense Solutions Customer Support. Refer to paragraph 1.6 **Technical Support** for contact information.

Refer to Table 9.3 for fault information.RMC module

**Table 9.3 Encryptor Error Codes**

| Symptoms/Condition | Meaning     | Investigative/Remedial Action                    |
|--------------------|-------------|--------------------------------------------------|
| 0x0103             | AES         | Memory allocation error                          |
| 0x0109             | AES         | KAT (known answer test) failed                   |
| 0x0203             | KEY_WRAP    | Memory allocation error                          |
| 0x0209             | KEY_WRAP    | KAT (known answer test) failed                   |
| 0x0210             | KEY_WRAP    | Initialization vector error                      |
| 0x0303             | SHA         | Memory allocation error                          |
| 0x0309             | SHA         | KAT (known answer test) failed                   |
| 0x0403             | HMAC        | Memory allocation error                          |
| 0x0409             | HMAC        | KAT (known answer test) failed                   |
| 0x0503             | DRBG        | Memory allocation error                          |
| 0x0509             | DRBG        | KAT (known answer test) failed                   |
| 0x0603             | RNG         | Memory allocation error                          |
| 0x0609             | RNG         | KAT (known answer test) or continual test failed |
| 0x0720             | encryptor   | 3.3Vpower supply error                           |
| 0x0730             | encryptor   | 2.5Vpower supply error                           |
| 0x0740             | encryptor   | 1.8Vpower supply error                           |
| 0x0709             | encryptor   | KAT (known answer test) failed                   |
| 0x0810             | I2C         | Interrupt handler error                          |
| 0x0901             | SATA_P_CTRL | Initialization error                             |
| 0x0904             | SATA_P_CTRL | Write error                                      |
| 0x0905             | SATA_P_CTRL | Read error                                       |
| 0x0A10             | ENCRYPTION  | Chip_A BIST error                                |
| 0x0A20             | ENCRYPTION  | Chip_B BIST error                                |
| 0x0A30             | ENCRYPTION  | Chip_C BIST error                                |

**Table 9.3 Encryptor Error Codes**

| <b>Symptoms/Condition</b> | <b>Meaning</b> | <b>Investigative/Remedial Action</b> |
|---------------------------|----------------|--------------------------------------|
| 0x0A40                    | ENCRYPTION     | Chip_D BIST error                    |
| 0x0A50                    | ENCRYPTION     | Chip_A POST error                    |
| 0x0A60                    | ENCRYPTION     | Chip_B POST error                    |
| 0x0A70                    | ENCRYPTION     | Chip_C POST error                    |
| 0x0A80                    | ENCRYPTION     | Chip_D POST error                    |
| 0x0A01                    | ENCRYPTION     | Key Load error                       |
| 0x0D04                    | SRAM           | Write error                          |
| 0x0D05                    | SRAM           | Read error                           |
| 0x0E03                    | E2PROM         | Memory allocation error              |
| 0x0E04                    | E2PROM         | Write error                          |
| 0x0E05                    | E2PROM         | Read error                           |
| 0x0F03                    | STORAGE        | Memory allocation error              |
| 0x0F04                    | STORAGE        | Write error                          |
| 0x0F05                    | STORAGE        | Read error                           |
| 0x2002                    | PBKDF2         | Invalid input length                 |

# Remove / Replace

## 10.1 RMC Module



### CAUTION

EQUIPMENT DAMAGE. Exercise ESD precautions when installing, removing, or handling the RMC module.


### 10.1.1 Install



### CAUTION

EQUIPMENT DAMAGE. The RMC is hot-swappable (remove / install with power applied), however, extreme caution must be used to ensure all ESD handling precautions are followed. Failure to properly handle the RMC will result in equipment damage.

1. Rotate the door latch (Figure 10.1) a quarter turn and open the door.
2. Orient the RMC module with the status LEDs closest to the DTS's door hinge.
3. Align the RMC module rails with the chassis slides and push the RMC module in until the connector makes contact.
4. Apply pressure on the RMC module handle to seat the connector into the backplane connector.
5. Close and latch the DTS1 door.
6. If the door will not latch
  - a. Remove the RMC module and inspect the connector contacts on the RMC module and the DTS1 backplane.
  - b. If no problem is found with the connectors, reinstall the RMC module and try latching the door again.
  - c. If the problem persists, contact Curtiss-Wright Defense Solutions.
7. Open the DTS1 door and observe the RMC module STATUS LED. When green LED turns ON, RMC module is ready.



DDOC0099-0008

**Figure 10.1 RMC Module Install / Remove**

## 10.1.2 Remove

**CAUTION**  
EQUIPMENT DAMAGE. The RMC is hot-swappable (remove / install with power applied), however, extreme caution must be used to ensure all ESD handling precautions are followed. Failure to properly handle the RMC will result in equipment damage.

1. Rotate the door latch a quarter turn and open the door.

**NOTE**

Removal may also be requested with the CLI command `rmctl`.

2. Press and hold the removal request button for three to five seconds to request removal of the RMC module.
  - ◆ The STATUS LED will blink at 5Hz for two seconds to acknowledge the request. After acknowledgment, the system will unmount and prepare the RMC module for removal.
  - ◆ When the RMC module is ready for removal, the STATUS LED will blink one time every five seconds.
3. Grasp the RMC module handle and pull the unit straight out.

## 10.2 Battery

**CAUTION**  
EQUIPMENT DAMAGE. Extreme caution must be used to ensure all ESD handling precautions are followed when replacing the battery. Failure to properly handle the DTS1 / battery will result in equipment damage.

**CAUTION**  
UNIT ZEROIZATION. Removal / replacement of the battery assembly will result in zeroization of the unit. Ensure all encryption keys are known and recorded before battery module is removed.

**NOTE**

Battery life is estimated to be approximately 5 years. As a result, Curtiss-Wright recommends replacing it every 5 years.

The DTS1 encryptor module uses a battery assembly to maintain the encryption key. The status can be checked by initiating the `sens` command and looking at `V_CRYPT` response. The battery should be replaced if the `V-CRYPT` reading is outside of the normal response ( $3.4 < x < 3.9$  Vdc).

Refer to Table 10.1 for possible consumable materials required to replace battery. Refer to **Ordering Information** section for battery assembly part number

**Table 10.1 Consumable Materials**

| Qty | U/M | Description                          | Curtiss-Wright P/N | OEM P/N   | OEM           |
|-----|-----|--------------------------------------|--------------------|-----------|---------------|
| 6   | EA  | Screw, Sealing Flat Head 2-56 x 0.25 | D700058-R00-LF     | 98070A079 | McMaster-Carr |
| 4   | EA  | Screw, BSHC, 1-64 x 0.125            | D700272-R00-LF     | 92949A314 | McMaster-Carr |

**NOTE**


O-rings are integral to sealing screws.

1. Remove six sealing screws, o-rings, and the battery access panel (Figure 10.2).
2. Remove four screws and battery assembly. Discard battery assembly in accordance with local regulations.
3. Align replacement battery assembly connector pins with DTS1 connector sockets.
4. Install the battery assembly in the DTS1. Make sure the pins/sockets properly engage.
5. Use four screws to secure the battery assembly in place. Tighten the screws to 1.7 in. lb.


**NOTE**

If an integral o-ring is damaged, replace sealing screw.

6. Use six sealing screws and o-rings to secure the battery access cover in place. Tighten the screws to 2.2 in. lb. using the pattern shown in Figure 10.3.



**Figure 10.2 Battery Assembly Replacement**



**Figure 10.3 Battery Access Panel Screws Tightening Sequence**



# Simple Network Management Protocol

## 11.1 SNMP MIB

The DTS1 supports Simple Network Management Protocol (SNMP). The user may configure SNMP for a Windows workstation via the Windows Control Panel. The user should consult with their network administrator for details on configuration and utilization of the SNMP traps and other data capture programs.

DTS1 SNMP Management Information Basis (MIB) Definitions are as follows:

```
CWCDS-DTS-MIB DEFINITIONS ::= BEGIN

--
-- MIB for CWCDS DTS.
--

IMPORTS
 MODULE-IDENTITY, OBJECT-TYPE, Integer32, enterprises,
 NOTIFICATION-TYPE FROM SNMPv2-SMI
 OBJECT-GROUP, NOTIFICATION-GROUP FROM SNMPv2-CONF
;

dtsSnm MODULE-IDENTITY
 LAST-UPDATED "201206250000Z"
 ORGANIZATION "www.cwcontrols.com"
 CONTACT-INFO
 "email: support@curtisswright.com"
 DESCRIPTION
 "MIB for CWCDS DTS."
 REVISION "201206250000Z"
 DESCRIPTION
 "version 1.0"
 ::= { enterprises 27675 }

--
-- top level structure
--
dtsSnmValues OBJECT IDENTIFIER ::= { dtsSnm 1 }

dtsSnmValuesGroup OBJECT-GROUP
 OBJECTS { dtsINFO,
 dtsSERV,
 dtsIPCONFIG,
 dtsRMCFREE,
 dtsRMCCTL,
 dtsRMCINFO,
 dtsLEDCTRL,
 dtsSENS,
 dtsSYSDATE,
 dtsIBIT,
 dtsCMLOGIN,
 dtsCMKEY }

 STATUS current
 DESCRIPTION
 "Group of all DTS variables."
 ::= { dtsSnm 4 }

--
```

```

-- Values
--

dtsINFO OBJECT-TYPE
 SYNTAX OCTET STRING (SIZE(1..4096))
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "Output of command: info"
 ::= { dtsSnmpValues 1 }

dtsSERV OBJECT-TYPE
 SYNTAX OCTET STRING (SIZE(1..4096))
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "Output of command: serv"
 ::= { dtsSnmpValues 2 }

dtsIPCONFIG OBJECT-TYPE
 SYNTAX OCTET STRING (SIZE(1..8192))
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "Output of command: ipconfig"
 ::= { dtsSnmpValues 3 }

dtsRMCFREE OBJECT-TYPE
 SYNTAX OCTET STRING (SIZE(1..4096))
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "Output of command: rmcfree"
 ::= { dtsSnmpValues 4 }

dtsRMCCTL OBJECT-TYPE
 SYNTAX OCTET STRING (SIZE(1..4096))
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "Output of command: rmcctl"
 ::= { dtsSnmpValues 5 }

dtsRMCINFO OBJECT-TYPE
 SYNTAX OCTET STRING (SIZE(1..8192))
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "Output of command: rmcinfo"
 ::= { dtsSnmpValues 6 }

dtsLEDCTRL OBJECT-TYPE
 SYNTAX OCTET STRING (SIZE(1..8192))
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "Output of command: ledctrl"
 ::= { dtsSnmpValues 7 }

dtsSENS OBJECT-TYPE
 SYNTAX OCTET STRING (SIZE(1..8192))

```

```
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "Output of command: sens"
 ::= { dtsSnmpValues 8 }
```

```
dtsSYSDATE OBJECT-TYPE
SYNTAX OCTET STRING (SIZE(1..8192))
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "Output of command: sysdate"
 ::= { dtsSnmpValues 9 }
```

```
dtsIBIT OBJECT-TYPE
SYNTAX OCTET STRING (SIZE(1..65536))
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "Output of command: ibit"
 ::= { dtsSnmpValues 10 }
```

```
dtsCMLOGIN OBJECT-TYPE
SYNTAX OCTET STRING (SIZE(1..8192))
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "Output of command: cmlogin"
 ::= { dtsSnmpValues 11 }
```

```
dtsCMKEY OBJECT-TYPE
SYNTAX OCTET STRING (SIZE(1..8192))
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "Output of command: cmkey"
 ::= { dtsSnmpValues 12 }
```

```
END
```

# Command Line Interface

The Command Line Interface (CLI) is the primary method of communicating with and configuring the DTS1 and / or RMC module.

## 12.1

### DTS1

- amnt**..... Auto mounter/starter control utility
- cmfwupdate** ..... Update DTS security processor
- cmkey** ..... Manage key on encryptor
- cmlog** ..... Read / clear crypto module error log
- cmlogin** ..... Login, Logout, initialize crypto module
- dhcpconfig**..... Configure DHCP services
- fdefaults** ..... Load factory default values
- fupdate** ..... Boot into RAM disk image to perform field update
- fwall** ..... Firewall control utility
- help**..... Display commands available to DTS1 admin user
- ibit\*** ..... Perform initiated built-in test (IBIT).
- info\*** ..... View DTS1 system information
- ipconfig\*** ..... Configure IP interfaces
- istarget** ..... Control iSCSI target services
- ledctrl\*** ..... Set/get duty cycle and status for DTS LEDs
- log**..... View DTS1 log files
- mbit**..... Perform maintenance built-in tests (MBIT)
- nfscctl**..... Change NFS options
- ntpdate** ..... Retrieve system time and date from ntp server
- password** ..... Change login password for an account
- pcap**..... Perform packet capture (PCAP) recording to capture network traffic
- rtp** ..... RTP video stream recording control and status.
- reboot**..... Reboot the DTS1
- sens\*** ..... View DTS1 sensor readings
- serv\*** ..... DTS1 service control and status utility
- shutdown** ..... Halt the DTS1
- sysdate\*** ..... Configure system time and date

## 12.2

### RMC Module

- rmcctl\*** ..... RMC control utility
- rmcfree\*** ..... Display file system free/used info for RMC storage devices
- rmcinfo\*** ..... View and set RMC identification information
- rmcpurge**..... Purge all data on the drives of RMC

\* Commands with SNMP service

## 12.3

### Commands

Refer to following paragraphs for detailed information regarding CLI commands.

### 12.3.1 amnt



**NOTE**

The DTS1 has only 1 RMC slot. As a result, the -s option is always -s 0.

**Description**

The amnt command is used to determine the configuration of the RMC auto mounter/starter daemon. The conditions that allow auto-mounting of NAS RMCs, and the auto-starting of iSCSI targets can be configured. When an action is not requested, the current state is reported. The default operation for NAS RMCs / partitions to auto mount at POR or the first insertion. The default operation for iSCSI RMCs to NOT auto-start the iSCSI targets. Configuring an RMC/partition to be NAS or iSCSI is done with the --serv command.

**Syntax**

```
amnt [-h | --help | --version]
amnt [-s slotnum] [--off] [--on] [--key] [--nas] [--iscsi] [--por] [--fin] [--sin]
 [--can] [--ro] [--restart]
```

**Options**

- h, --help.....Print help message.
- version.....Print program version.
- s, --slot <slotnum> ..... Slot number where the RMC is located(0,1,2,A). For all slots, use A or all. Omission will select slot 0.
- off, off, 0 .....Disable an option, or the auto mounter/starter capability as a whole.
- on, on, 1.....Enable an option, or the auto mounter/starter capability as a whole.
- key, key.....Configure auto key loading of the crypto unit
- nas, nas.....Configure the auto mounting of NAS file systems on the RMC described by --slot.
- iscsi, iscsi .....Configure the auto starting of iSCSI targets on the RMC described by --slot.
- por, por .....Configure the operation at POR of the RMC described by --slot.
- fin, fin.....Configure the operation at the first insertion of the RMC described by --slot.
- sin, sin.....Configure the operation at subsequent insertions of the RMC described by --slot.
- can, can.....Configure the operation at canceled removals of the RMC described by --slot.
- ro, ro .....Make the RMC mount read only, or the iSCSI target start read only. An RMC that is write-protected will automatically use this option.
- blk, blk <blk size>.....Configure the auto starting of iSCSI targets with this block size. Valid sizes are 512, 1024, 2048, and 4096. The default block size is 4096, the same as the istarget CLI command.
- restart, restart.....Restart the auto mounter/starter daemon for the RMC described by --slot.

**Example: Status display**

```

cw_dts> amnt
[amnt]
 AMT_S#: AMNT KEY iPOR iFIN iSIN iCAN iRO iBLK nPOR nFIN nSIN nCAN nRO

 AMT_S0: 1 0 1 0 0 0 0 512 1 0 0 0 0
[!amnt] <summary>
```

**Line Identifier**

AMT\_S# .....Current automounter status of RMC in slot "#"

**Enumerated types**

<summary> .....Command status summary (OK, ERR)

**Example: Turn off auto-mounting on slot 0 completely**

```
amnt -s 0 --off
```

**Example: Turn on H/W encryption auto key loading. A subsequent load of a H/W encryption key will attempt to auto-mount**

```
amnt -s 0 --key --on
```

**Example:** Turn off auto-mounting of NAS RMC / partitions

```
amnt -s 0 --nas --off
```

**Example:** Turn off auto-mounting of NAS RMC / partitions at POR

```
amnt -s 0 --nas --por --off
```

**Example:** Turn off auto-mounting of NAS RMC / partitions at first insertion

```
amnt -s 0 --nas --fin --off
```

**Example:** Turn off auto-mounting of NAS RMC / partitions at subsequent insertion

```
amnt -s 0 --nas --sin --off
```

**Example:** Turn off auto-mounting of NAS RMC / partitions at canceled removal

```
amnt -s 0 --nas --can --off
```

**Example:** Turn on read only mounting option for NAS RMC / partitions. Allowed during auto-mounting only. Doesn't affect CLI mounting.

```
amnt -s 0 --nas --ro --on
```

**Example:** Turn off auto-starting of iSCSI target RMC

```
amnt -s 0 --iscsi --off
```

**Example:** Turn off auto-starting of iSCSI RMC at POR

```
amnt -s 0 --iscsi --por --off
```

**Example:** Turn off auto-starting of iSCSI RMC at first insertion

```
amnt -s 0 --iscsi --fin --off
```

**Example:** Turn off auto-starting of iSCSI RMC at subsequent insertion

```
amnt -s 0 --iscsi --sin --off
```

**Example:** Turn off auto-starting of iSCSI RMC at canceled removal

```
amnt -s 0 --iscsi --can --off
```

**Example:** Turn on read only option for iSCSI RMC. Valid during auto-mounting only. Doesn't affect CLI iSCSI target starting.

```
amnt -s 0 --iscsi --ro --on
```

**Example:** Configure the block size for the auto started iSCSI targets.

```
amnt -s 0 --iscsi --blk 512
```

**Example:** Restart the auto mounter/starter daemon for the RMC described by --slot.

```
amnt -s 0 --restart
```

### 12.3.2 cmfwupdate

**Description:**

The cmfwupdate command provides the user the ability to update the firmware within the DTS security processor. The update is a trusted update that requires a binary image paired with its associated signature. This update file and signature will be verified during the transfer and will generate a failure if verification is unsuccessful.



**NOTE**

Place the provided files in the root of the NAS folder (/rmc\_shares/rmc0p1).



**NOTE**

Curtiss-Wright will be the only entity who provides a firmware update

**Syntax:**

```
cmfwupdate [-h | --help | -v | --version]
cmfwupdate [-f <str>] [-s <str>]
cmfwupdate - [options]
```

**Options:**

- h, --help.....Print help message.
- v, --version.....Report application version.
- f, --filename.....Filename (example: filename.bin).
- s, --signature.....signature (example: signature.bin).

**Returns:**

0 on success, else error

**Example:** Update crypto firmware.

```

cw_dts> cmfwupdate -f dts_crypto_csfc.bin -s dts_crypto_csfc_signature.bin
[!cmfwupdate] ERR
```

## 12.3.3

## cmkey

**NOTE**

The DTS1 has only 1 RMC slot. As a result, the -s option is always -s 0.

**Description**

The cmkey command allows for management of keys on the crypto module. For status information, issue cmkey without options.

**Syntax**

```
cmkey [-h | --help | --version]
cmkey -e KEY -m MAC [-s SLOT] [--save LOC] [-F]
cmkey -p PSK -d DEK [-s SLOT] [--save LOC] [-F]
cmkey -s SLOT [--load LOC | --auto | --unload] [-F]
cmkey --del LOC
cmkey --kek
cmkey --zero [--nowait]
```

**Options**

```
-h, --help.....Print help message
--version.....Print program version
--autoAuto-load the saved key for RMC selected by -s.
--save <loc>Save key to non-volatile memory location (0-31).
--del <loc>Delete/zeroize a saved key.
--load <loc>Load a saved key for RMC selected by -s.
--unload.....Unload/zeroize key from RMC selected by -s.
-s, --slot <num>.....RMC slot number (0, all) for which to load/install a key.
-e, --ekey <hex>.....Encrypted DEK (data encryption key) 40 byte value represented by
80 hex characters.
-m, --mac <hex>.....MAC (message authentication code) 48 byte value represented by
96 hex characters.
-p, --psk.....Plain Text PSK (pre-shared key) 32 byte value represented by 64
hex characters.
-d, --dek.....Plain Text DEK (data encryption key) 32 byte value represented by
64 hex characters.
-k, --kekGenerates KEK (key encryption key).
-r, --resetkekReset the key used to encrypt the KEK to the PSK.
```

**NOTE**

Must provide existing PSK (-p option) when using this option.

```
-u, --userpskUser defined plain text PSK (pre-shared key) 32 byte value
represented by 64 hex characters.
```

**NOTE**

The --zpsk option will restore the unit back to a state prior to assignment of the PSK making the unit inoperable. Will prompt user prior to performing the erase.

```
--zpskZeroize the crypto unit PSK.
-z, --zero.....Zeroize crypto module. Clears all saved/loaded keys.
--nowait.....Do not wait until zeroization is complete before returning.
-F, --force.....Force key load to RMC if key mismatch is detected.
```

**NOTE**

Options --save, --del, and --load operate on 32 non-volatile memory locations for key storage. These locations are within the crypto module. For security, the saved keys cannot be retrieved or viewed. Use of these memory locations is not required, and must be explicitly requested with option --save when entering a key. By default, keys are directly loaded/installed for the RMC selected with option -s.

**Example:** Get status regarding keys

```
cw_dts> cmkey
[cmkey]
CMKEY: id=<int> init= login= s0= s1= s2= deks=<mask> status=<sts>
[!cmkey] <summary>
```



**Line Identifier**

CMKEY ..... Status line

**Fields**

id=<int>..... Unique crypto module identifier  
 init=<b>..... Initialization indicator  
 login=<b>..... Login indicator  
 s0=<b>..... Key-loaded indicator for RMC slot 0  
 s1=<b>..... Key-loaded indicator for RMC slot 1  
 s2=<b>..... Key-loaded indicator for RMC slot 2  
 deks=<int>..... Saved key locations  
 status=<sts>..... Summary status for the line

**Enumerated types** (See above examples in fields)

<int> ..... An integer value  
 <b>..... Boolean status value (1=true, 0=false)  
 <sts> ..... Status message (OK, ERR "<str>")  
 <summary> ..... Command status summary (OK, ERR)

**Example:** Pass encrypted key, save to location 4, load for RMC..

```

cw_dts> cmkey --save 4 -s 0 -F -e [edek string] -m [mac string]
[cmkey]
CMKEY: action=inst slot=<int> status=<sts>
[!cmkey] <summary>

```

**Where**

[edek string] = 40 byte value represented by 80 hex characters  
 [mac string] = 32 byte value represented by 64 hex characters

**Line Identifier**

CMKEY ..... Status line

**Fields**

action=<act>..... Action being performed  
 slot=<int>..... RMC slot number  
 status=<sts>..... Summary status for the line

**Enumerated types** (See above examples in fields)

<int> ..... An integer value  
 <act> ..... Action (zero, auto, save, inst, load, unload, delete)  
 <sts> ..... Status message (OK, ERR "<str>")  
 <summary> ..... Command status summary (OK, ERR)

**Example:** Pass plain text key, load for RMC

```

cw_dts> cmkey -s 0 -d -p
[cmkey]
Please enter plaintext DEK: [User-generated plain text DEK string]
Please enter current PSK: [Curtiss-Wright provided PSK string]
CMKEY: action=inst slot=<int> status=<sts>
[!cmkey] <summary>

```

**Where**

[dek string] = 32 byte value represented by 64 hex characters  
 [psk string] = 32 byte value represented by 64 hex characters

**Example:** Pass plain text key, save to location 3.

```

cw_dts> cmkey --save 3 -d -p
[cmkey]
Please enter plaintext DEK: [User-generated plain text DEK string]
Please enter current PSK: [Curtiss-Wright provided PSK string]
CMKEY: action=save status=<sts>
[!cmkey] <summary>

```

**Example:** Load key from memory location 5 for RMC.

```

cw_dts> cmkey --load 5 -s 0
[cmkey]
CMKEY: action=inst slot=<int> status=<sts>
[!cmkey] <summary>

```

**Example:** Unload key for RMC.

```

cw_dts> cmkey --unload -s 0
[cmkey]
CMKEY: action=unload slot=<int> status=<sts>
[!cmkey] <summary>

```

**Example:** Delete key in memory location 3.

```

cw_dts> cmkey --del 3
[cmkey]
CMKEY: action=delete status=<sts>
[!cmkey] <summary>

```

**Example:** Zeroize crypto module

```

cw_dts> cmkey --zero
[cmkey]
CMKEY: action=zero status=<sts>
[!cmkey] <summary>

```

**Example:** Auto load keys for RMC

```

cw_dts> cmkey --auto -s all
[cmkey]
CMKEY: action=auto slot=<int> status=<sts>
[!cmkey] <summary>

```

**Example:** Generate KEK (key encryption key)

```

cw_dts> cmkey --kek
[cmkey]
CMKEY: kek=<str> mac=<str> status=<sts>
[!cmkey] <summary>

```

**Example:** Assign user defined PSK

```

cw_dts> cmkey -p -u
cmkey]
Please enter current PSK: [current psk string]
Please enter new PSK: [new psk string]
CMKEY: action=psk status=OK
[!cmkey] OK

```

#### Where

[current psk string] = current 32-bit plain-text PSK represented by 64 hex characters

[new psk string] = new 32-bit plain-text PSK represented by 64 hex characters

#### Line Identifier

CMKEY:.....Crypto init status line

#### Fields

kek=<str>..... Wrapped Key Encryption Key

mac=<str>..... Message Authentication Code

status=<sts> ..... Summary status for the line

#### Enumerated types (See above examples in fields)

<str> .....String

<sts> ..... Status message (OK, ERR "<str>")

<summary> ..... Command status summary (OK, ERR)

## 12.3.4 cmlog

**Description:**

The cmlog command allows a user to view the error log of the DTS crypto module. Only the crypto officer has permission to clear the error log

**Syntax:**

```
cmlog [-h | --help | -v | --version]
```

```
cmlog [-c | --clear]
```

```
cmlog
```

```
cmlog - [options]
```

**Options:**

-h, --help: ..... Print help message.

-v, --version: ..... Report application version.

-c, --clear: ..... Clear error log.

**Returns:**

0 on success, else error

**Example:** View crypto module error log

```
cw_dts> cmlog
[cmlog]
 CMLOG: Currently Logged Errors
 (0x0c20):[SECURITY] - tamper event: T1
 status=OK
[!cmlog] OK
```

**Example:** Clear crypto module error log

```
cw_dts> cmlog-c
[cmlog]
 CMLOG: status=OK
 status=OK
[!cmlog] OK
```

## 12.3.5 cmlogin

### Description

The cmlogin command allows the user to initialize and manage the login state of the crypto module. Initialization is required before crypto keys can be loaded and RMC formatted and mounted as storage. Initialization state is maintained across power cycles as long as a zeroization event has not occurred.

Login is required after each power up or initialization. Login state is not maintained across power cycles.

### Syntax

```
cmlogin [-h | --help | --version]
cmlogin -I -u username -p password [-F]
cmlogin [-L] -u username -p password
cmlogin -O
```

### Options

**-h, --help**..... Print help message.  
**--version**..... Print program version.  
**-u, --user <str>**..... Username for CM login. 1-15 characters.  
**-p, --pass <str>**..... Password for CM login. 8-15 characters, must contains at least one letter and one number (no special characters).  
**-M, --auth**..... HMAC used for password authorization. Must be completed after providing username/password to enter login state. The HMAC must be 96-ascii hex characters.  
**-I, --init** ..... Initialize crypto module  
**-F, --force** ..... Force reinitialization if module already initialized or RMC mounted. Re-init zeroizes a previously initialized crypto module.  
**-L, --login**..... Login to crypto module. Default operation when credentials are supplied.  
**-O, --logout**..... Logout of crypto module. (Undo login)

**Example:** Initialize crypto module.

```
cw_dts> cmlogin -u [user name] -p -I
[cmlogin]
Please enter password: [password]
Please verify password: [password]
CMLOGIN: action=save status=<sts>
[!cmlogin] <summary>
```

### Where

[user name] = 1-15 characters

[password] = 8-15 characters, Contains at least one letter, one number and no special characters

### Line Identifier

CMLOGIN ..... Command status line

### Fields

action=<act> ..... Action being performed  
status=<sts> ..... Summary status for the line

### Enumerated types (See above examples in fields)

<act> ..... Action (init, login, logout, auto, save, clear)  
<sts> ..... Status message (OK, ERR "<str>")  
<summary> ..... Command status summary (OK, ERR)

**Example:** Login to crypto module.

```
cw_dts> cmlogin -u [user name] -p
[cmlogin]
Please enter password: [password]
CMLOGIN: action=save status=<sts>
[!cmlogin] <summary>
```

**Where**

[user name] = 1-15 characters

[password] = 8-15 characters, Contains at least one letter, one number and no special characters

**Example:** Display current state.

```

cw_dts> cmlogin
cmlogin]
 CMLOGIN: state=<desc> init=<bool> login=<bool> status=<sts>
[!cmlogin] <summary>

```

**Line Identifier**

CMLOGIN ..... Command status line

**Fields**

state=<desc> ..... State description  
init=<bool> ..... Initialization indicator  
login=<bool> ..... Login indicator  
status=<sts> ..... Summary status for the line

**Enumerated types** (See above examples in fields)

<desc> ..... Description of crypto module state:  
  uninit..... Not initialized  
  init..... Initialized  
  ready ..... Initialized, Login complete  
  error ..... Error state  
  unknown..... Invalid state  
<bool> ..... Boolean status value (1=true, 0=false)  
<sts> ..... Status message (OK, ERR "<str>")  
<summary> ..... Command status summary (OK, ERR)

## 12.3.6 dhcpconfig

### Description

The dhcpconfig command allows the user to configure DHCP services on the DTS unit.

### Syntax

```
dhcpconfig [-h | --help | --version]
dhcpconfig -A -s IP NM [-r val] [-n val] [-g val] [-d val] [-t val]
dhcpconfig -D -s IP NM
dhcpconfig -A -b NAME [-m val | -c val] [-t val] [-f val] [-n val] [-g val] [-d val]
dhcpconfig -D -b NAME
```

### Options for subnet and BOOTP declarations

```
-h, --help..... Print help message.
--version..... Print program version.
-A, --add..... Add/Update subnet or bootp entry
-D, --delete..... Delete subnet or bootp entry
-n, --netmask <ip> Netmask to assign to subnet clients
-g, --gateway <ip> Gateway to assign to clients in subnet
-i, --domainserver <ip>... IP of Domain Name Server to assign to clients
-d, --domain <str> Domain Name to assign to clients
-o, --offset <str> Time offset from UTC in seconds
```

### Options specific to subnet declarations

```
-s, --subnet <ip> <nm> IP and netmask for DHCP Subnet entry (Required)
-r, --range <ip> <ip> Low to high range of IP addresses to provide
```

### Options specific to BOOTP declarations

```
-b, --bootp <str>..... Name for bootp entry (Required)
-m, --mac <str> Ethernet MAC to identify bootp client
-c, --clientid <str> Alternative bootp client identifier value
-t, --tftpfile <str> TFTP file for bootp client to download/boot
-f, --fixedip <ip> Fixed IP for bootp client
```

To start and stop the DHCP service, use command 'serv'.

### Example: View configuration (enumerated)

```

cw_dts> dhcpconfig
[dhcpconfig]
 SUBNET: subnet=<net> rn=<ip>-<ip> gw=<ip> dns=<ip> nm=<nm> dmn=<str> toff=<int>
 status=<sts>
 BOOTP: host=<str> mac=<mac> id=<str> tftp=<file> ip=<ip> nm=<nm> gw=<ip>
 dmn=<str> dns=<ip> toff=<int> status=<sts>
[!dhcpconfig] <summary>

```

### Line Identifier

```
SUBNET..... Reports a DHCP subnet declaration
HOST Reports a BOOTP client declaration
```

**Fields** (only fields defined for the entry are displayed)

```

subnet=<net> Reports subnet on which to assign addresses
rn=<ip>-<ip> Reports range of addresses to assign to clients
gw=<ip> Reports gateway address passed to clients
dns=<ip> Reports DNS server address passed to clients
nm=<nm> Reports netmask passed to clients
dmn=<str> Reports domain name passed to clients
toff=<int> Reports time offset passed to clients
host=<str> Reports name of BOOTP entry / hostname of client
mac=<mac> Reports MAC address of BOOTP client
id=<str> Reports client ID of BOOTP client
tftp=<file> Reports BOOTP file name
ip=<ip> Reports IP address to assign to client
status=<sts> Summary status for the given line.

```

**Enumerated types:**

```

<net> IPv4 dotted-decimal subnet address (Ex: 192.168.1.0)
<ip> IPv4 dotted-decimal address (Ex: 192.168.1.1)
<nm> IPv4 dotted-decimal netmask (Ex: 255.255.255.0)
<int> An integer value (Ex: -28800, 7200)
<mac> MAC address (Ex: 00:11:22:33:44:55)
<file> File name for BOOTP client (Ex: "/rmc0/bootimage")
<str> Text string
<sts> Status message (OK, ERR "<str>")
<summary> Command status summary (OK, ERR)

```

**Example:** View configuration (sample command output)

```

cw_dts> dhcpconfig
[dhcpconfig]
SUBNET: subnet=192.168.1.0 rn=192.168.1.1-192.168.1.10 gw=192.168.1.1
dns=192.168.1.1 nm=255.255.255.0 dmn="CWNAS" toff=-8 status=OK
BOOTP: host=target mac=00:1b:ac:70:10:42 tftp="/rmc0/bootfile" status=OK
[!dhcpconfig] OK

```

**Example:** Add subnet configuration

```

cw_dts> dhcpconfig -A -s 192.168.3.0 255.255.255.0 -g 192.168.3.5 -r 192.168.3.10
192.168.3.20 -i 192.168.3.10 -o -8
[dhcpconfig]
SUBNET: status=<sts>
[!dhcpconfig] <summary>

```

**Example:** Delete subnet configuration

```

cw_dts> dhcpconfig -D -s 192.168.3.0 255.255.255.0
[dhcpconfig]
SUBNET: status=<sts>
[!dhcpconfig] <summary>

```

**Example:** Add BOOTP client

```

cw_dts> dhcpconfig -A -b mypc -m 20:50:A4:FC:6B:B5 -f 192.168.3.55 -t /rmc0/bootfile
[dhcpconfig]
BOOTP: status=<sts>
[!dhcpconfig] <summary>

```

**Example:** Delete BOOTP client

```

cw_dts> dhcpconfig -D -b mypc
[dhcpconfig]
BOOTP: status=<sts>
[!dhcpconfig] <summary>

```

## 12.3.7 fdefaults

### Description

The fdefaults command set passwords, IP addresses, NAS configuration, etc. to factory default values and clears out saved crypto credentials, command history and saved ssh authorized keys.

### Syntax

```
fdefaults [-h | --help | --version | --go]
```

### Options

**-h, --help**.....Print help message.  
**--version**.....Print program version.  
**--go**.....Proceed with restoration to factory defaults



**12.3.8****fupdate****Description:**

The fupdate command boots the DTS system into a RAM disk image where the user can install a new DTS disk image onto the system. By default the new image file to be updated is uploaded via FTP or SCP into memory.

See paragraph 7.9 **Update Software / Firmware** for detailed instructions.

## 12.3.9 fwall

### Description

The fwall command is used to determine the configuration of the firewall. This command does not start or stop DTS services, but only allows the firewall to pass or block traffic for them. The default zone used is the public zone. The default configuration of the firewall is ON. The boot flash needs to be writeable to make changes to the firewall configuration permanent. There is a way to pass a user defined command straight through (no error checking) to the underlying firewall-cmd utility.

### Syntax

```
fwall [-h | --help | --version]
fwall [--status] [--start] [--stop] [--restart]
```

### Options

```
-h, --help..... Print help message.
--version..... Print program version.
--status..... Show the firewall status
--unmask..... Unmask the firewall
--start..... Start the firewall
--enable..... Enable the firewall at boot
--stop..... Stop the firewall
--disable..... Disable the firewall at boot
--mask..... Mask the firewall
--restart..... Restart the firewall
--reload..... Reload the firewalls permanent rules
--perm..... Make action permanent
--dhcp..... Add/remove dhcp
--ftp..... Add/remove ftp
--http..... Add/remove http
--iscsi..... Add/remove iscsi targets
--nfs..... Add/remove nfs
--telnet..... Add/remove telnet
--cifs..... Add/remove cifs
--ssh..... Add/remove ssh
--snmp..... Add/remove snmp
--tftp..... Add/remove tftp
--all..... Add/remove all DTSx services
--add..... Add a port, service, or interface
--rem..... Remove a port, service or interface
--port..... Port number to add/remove
--iface..... Interface to add/remove: eth0, etc.
--udp..... Define a port as udp
--tcp..... Define a port as tcp
--cmd "options"..... Pass "options" to firewall-cmd
```

### Example: Status display

```

cw_dts> fwall
[fwall]
FIREWALL: status=OK "The firewall IS running"
public (active)
target: default
icmp-block-inversion: no
interfaces: eth0 eth1
sources:
services: dhcp ssh
ports:
protocols:
masquerade: no
forward-ports:
sourceports:
icmp-blocks:
rich rules:
[!fwall] <summary>

```

**Line Identifier**

FIREWALL ..... Current fireWall status

**Enumerated types**

&lt;summary&gt; ..... Command status summary (OK, ERR)

**Example:** Display firewall status

```
fwall --status
```

**Example:** Unmask firewall

```
fwall --unmask
```

**Example:** Start firewall

```
fwall --start
```

**Example:** Enable firewall at boot

```
fwall --enable
```

**Example:** Stop firewall

```
fwall --stop
```

**Example:** Disable firewall at boot

```
fwall --disable
```

**Example:** Mask firewall

```
fwall --mask
```

**Example:** Restart firewall

```
fwall --restart
```

**Example:** Reload firewall permanent rules

```
fwall --reload
```

**Example:** Add eth0 to firewall

```
fwall --add --iface --eth0
```

**Example:** Add ftp service to firewall

```
fwall --add ftp
```

**Example:** Remove ftp service from firewall

```
fwall --rem ftp
```

**Example:** Add udp port 7777 to firewall permanently

```
fwall --add --perm --port 7777 udp
```

**Example:** Remove udp port 7777 from firewall permanently

```
fwall --rem --perm --port 7777 udp
```

**Example:** Pass command to firewall-cmd

```
fwall --cmd "--list-services"
```

**12.3.10****help****Description**

The help command displays a list of commands available to the DTS admin user if no arguments are supplied. For help information for a specific command, use help [command]. For example: help ipconfig. Alternatively, run the command with -h or --help as an argument.

**Syntax**

```
help
help [-h | --help | --version]
help command
```

**Options**

```
-h, --help..... Print help message.
--version..... Print program version.
```

**Examples**

```
ipconfig -h
help
```

## 12.3.11 **ibit**

### Description

The `ibit` command performs the initiated built-in test.

### Syntax

`ibit [-h | --help | --version]`

### Options

`-h, --help`..... Print help message.  
`--version`..... Print program version.  
`-v`..... Verbose mode. Print more info regarding tests.  
`-vf`..... Verbose-on-failure. Print more info about failures.



### NOTE

Additional output for `-v` and `-vf` is not formalized. Non-verbose IBIT output is at the end of the response.

### Example: IBIT execution

```

cw_dts> ibit
[ibit]
 IBIT_MON: mcu=<s> i2c=<s> volt=<s> status=<sts>
 IBIT_ETH: eth0=<s> eth1=<s>
 IBIT_RMC0: volt=<s> ata=<s> smart=<s> status=<sts>
[!ibit] <summary>

```

### Line Identifier

`IBIT_MON` ..... Results for system monitor subsystem.  
`IBIT_ETH` ..... Results for Ethernet subsystem.  
`IBIT_RMC#` ..... Results for RMC in slot '#'.

### Fields

`mcu=<s>` ..... Result for sysmon microcontroller  
`i2c=<s>` ..... Result for I2C bus  
`volt=<s>` ..... Result for voltage regulator monitors  
`eth#=<s>` ..... Result for Ethernet device eth# (eth0, eth1, ...)  
`ata=<s>` ..... Result for ATA driver log check  
`smart=<s>` ..... Result for disk S.M.A.R.T. self assessment  
`status=<sts>` ..... Summary status for the line.

### Enumerated types

`<s>` ..... Subtest status. 1=pass, 0=fail  
`<sts>` ..... Status message (OK, ERR "<str>")  
`<str>` ..... Text string  
`<summary>` ..... Command status summary (OK, ERR)

## 12.3.12 info



**NOTE**

The DTS1 has only 1 RMC slot. As a result, the -s option is always -s 0.

**Description**

The info command displays DTS hardware and software information, such as versions.

**Syntax**

```
info [-h | --help | --version | -R | -M | -A]
info
```

**Options**

- h, --help ..... Print help message.
- version..... Print program version.
- A..... Alternate short-form display.
- M..... Show the media type(s) supported by each slot.
- R..... Generate a status report of info useful for tech support. Output not formalized. With optional SLOT, export report to RMC.

**Example: Long-form output**

```

cw_dts> info
[info]
Manufacturer: Curtiss-Wright Controls
Cage Code: 1P423
System firmware: <ver>
Sysmon firmware: <ver>
Crypto firmware: <ver>
Media slots: <num>
[!info] <summary>

```

**Fields**

- System firmware..... Operating system firmware version
- Sysmon firmware..... System monitor firmware version
- Crypto firmware..... Encryption module firmware version
- Media slots ..... RMC/media slot count

**Enumerated types:**

- <ver> ..... Version string. 'ERR' on error, or 'na' for "not applicable"
- <num> ..... Number of slots (integer)
- <summary> ..... Command status summary (OK, ERR)

**Example: Short-form output**

```

cw_dts> info -A
[info]
DTS_INFO: system=<ver> sysmon=<ver> crypto=<ver> slots=<num> status=<sts>
[!info] <summary>

```

**Line Identifier**

- DTS\_INFO ..... Firmware versions and slot count data.

**Fields**

- system=<ver> ..... Operating system firmware version
- sysmon=<ver> ..... System monitor firmware version
- crypto=<ver> ..... Encryption module firmware version
- slots=<num> ..... RMC/media slot count
- status=<sts> ..... Summary status for the line

**Enumerated types** (See above examples in fields)

<sts> ..... Status message (OK, ERR "<str>")  
 <str> ..... Text string

**Example: Media types**

```

cw_dts> info -M
[info]
 DTS_MEDIA: slots=<num> type0=<t> type1=<t> type2=<t> status=<sts>
[!info] <summary>

```

**Line Identifier**

DTS\_MEDIA..... Media types supported by the media/RMC slot

**Fields**

slots=<num> ..... RMC/media slot count  
 type#=<t>..... RMC/media types supported by slot '#'.

**Enumerated types** (See above examples in fields)

<num> ..... Number of slots (integer)  
 <t> ..... Media type options. A hexadecimal value as follows:  
 Bit Mask Description  
 01 RMC  
 -.E Reserved



**NOTE**

The following error examples for phony example command 'cmd' are applicable to all commands supported by the CLI.

**Example: Invalid parameters / Command errors**

```

cw_dts> cmd --badoption
[cmd]
INVALID: status=ERR "<errstr>"
[!cmd] ERR

```

```

cw_dts> cmd --valid --options
[cmd]
ERROR: status=ERR "<errstr>"
[!cmd] ERR

```

**Line Identifier**

INVALID ..... Command parameter(s) invalid  
 ERROR ..... Critical error. Command did not complete.

**Enumerated types**

<errstr>..... Text string describing the error.

## 12.3.13 ipconfig

### Description

The ipconfig command allows for configuration of an IP interface. By default, changes take effect on the next bootup.

### Syntax

```
ipconfig [-h | --help | --version]
ipconfig [-e device] -V
ipconfig [-e device] -D [-F]
ipconfig [-e device] [-i address] [-n netmask] [-g gateway] [-F]
ipconfig [-e device] -D6 [-F]
ipconfig [-e device] [-i6 address] [-g6 gateway] [-F]
```

### Options

**-h, --help**.....Print help message.  
**--version**.....Print program version.  
**-e, --eth <str>**.....Ethernet device: eth0, eth1....eth[n] Default is 'all' when viewing status (see -V), otherwise eth0.  
**-i, --ip <str>**.....Assign static IPv4 address.  
**-n, --net <str>**.....Assign static IPv4 netmask. Use '.' to clear.  
**-g, --gate <str>**.....Assign static IPv4 gateway address. Use '.' to clear.  
**-D, --dhcp**.....Use DHCP with IPv4 addressing.  
**-i6, --ip6 <str>**.....Assign static IPv6 address. Use '.' to clear.  
**-D6, --dhcp6**.....Use DHCP with IPv4 and IPv6 Addressing.  
**-A6, --slaac**.....Use StateLess Address AutoConfiguration method for IPv6.  
**-O, --onboot**.....Configure interface to come up on boot



### NOTE

This will cause termination of active connections.

**-F, --force**.....Force reconfiguration without reboot.  
**-V, --view**.....View interface status and IPv4 configuration settings. Default action when other options absent.  
**-V6, --view6**.....View interface status and IPv6 configuration settings.  
**-M, --mac**.....View MAC addresses.  
**-S**.....Like -V, but status only.  
**-S6**.....Like -V6, but status only.

### Example: Status/config display

```

cw_dts> ipconfig -V
[ipconfig]
 STS_ETH_0: link=<lnk> ip=<ip> nm=<ip> gw=<ip> status=<sts>
 STS_ETH_1: link=<lnk> ip=<ip> nm=<ip> gw=<ip> status=<sts>
 CFG_ETH_0: prot=<prot> ip=<ip> nm=<ip> gw=<ip> status=<sts>
 CFG_ETH_1: prot=<prot> ip=<ip> nm=<ip> gw=<ip> status=<sts>
[!ipconfig] <summary>

```



### NOTE

Command 'ipconfig -S' reports only the STS\_ETH\_# lines as above.

### Line Identifier

**STS\_ETH\_#:**.....Current status for Ethernet device eth#.  
**CFG\_ETH\_#:**.....Configuration settings for Ethernet device eth#.

### Fields

**link=<lnk>**.....Link speed / link down indicator  
**ip=<ipv4>**.....IPv4 address  
**nm=<ipv4>**.....IPv4 subnet mask (netmask)  
**gw=<ipv4>**.....IPv4 gateway address  
**ip6=<ipv6>**.....IPv6 address  
**gw6=<ipv6>**.....IPv6 gateway address  
**prot=<prot>**.....Identifies protocol/method of assigning IP parameters.  
**status=<sts>**.....Summary status for the given line.



**Enumerated types**

<lnk> ..... Link speed (10, 100, 1000, down)  
 <ipv4> ..... IPv4 dotted-decimal address (Ex: 10.19.6.6), netmask (Ex: 255.255.255.0), gateway (Ex: 10.19.0.0), or 'NA' for "Not available"  
 <ipv6> ..... IPv6 colon-hexadecimal address (Ex: fd01::1) or 'NA' for "Not available"  
 <prot> ..... "dhcp" for DHCP assignment (ip, nm, gw fields absent) "static" for static assignment (ip, nm, gw fields follow)  
 <sts> ..... Status message (OK, ERR "<str>")  
 <str> ..... Text string  
 <summary> ..... Command status summary (OK, ERR)

**Example: MAC display**

```

cw_dts> ipconfig -M
[ipconfig]
 MAC_ETH_0: mac=<mac> link=<lnk> status=<sts>
 MAC_ETH_1: mac=<mac> link=<lnk> status=OK
[!ipconfig] <summary>

```

**Line Identifier**

MAC\_ETH\_# ..... MAC address / current status for Ethernet device eth#.

**Fields**

mac=<mac> ..... Interface MAC address  
 link=<lnk> ..... Link speed / link down indicator  
 status=<sts> ..... Summary status for the given line.

**Enumerated types** (See above examples in fields)

<mac> ..... MAC address (Ex format: 00:11:22:33:44:55)  
 <summary> ..... Command status summary (OK, ERR)

**Example: Set static IPv4 and netmask on interface eth1**

```

cw_dts> ipconfig -e eth1 -i 192.168.1.5 -n 255.255.255.0
[ipconfig]
 IP: status=<sts>
[!ipconfig] <summary>

```

**Example: Set static IPv6 on interface eth0**

```

cw_dts> ipconfig -e eth0 -i6 fd01::1/64
[ipconfig]
 IP: status=<sts>
[!ipconfig] <summary>

```

**Example: Set DHCP config / force reconfiguration on interface eth1**

```

cw_dts> ipconfig -e eth1 -D -F
[ipconfig]
 IP: status=<sts>
[!ipconfig] <summary>

```

**Example: Configure (enable) boot configuration of eth1**

```

cw_dts> ipconfig -e eth1 -O yes
[ipconfig]
 IP: status=<sts>
[!ipconfig] <summary>

```

**Line Identifier**

IP ..... Configuration status line

**Fields**

status=<sts> ..... Summary status for the given line.

## 12.3.14 istarget

### ! NOTE

The DTS1 has only 1 RMC slot. As a result, the -s option is always -s 0.

### Description

The istarget command starts, stops, and reports the status of the iSCSI target server.

### Syntax

```
istarget [-h | --help | --version]
istarget [--start | --stop | --status | --setTargetName <rmc idx> <part idx> <iqn name>]
```

### Options

```
-h, --help.....Print help message.
--version.....Print program version.
-s, --slot <slotnum>.....Specify RMC slot to use. 0,1,2 or 'all' for all slots
--start.....Start iSCSI Target service.
--stop.....Stop iSCSI Target service.
--status.....Status of iSCSI Target service (default).
--setTargetName <rmc idx> <part idx> <iqn name>: Set iSCSI qualified name (iqn)
 <rmc idx>.....rmc index 0,1, 2 ,etc
 <part idx>.....part index 1,2,etc 0 for whole disk
 <iqn name>.....iSCSI Qualified Name (IQN)
--getTargetNames.....Get iSCSI iqn target names
--clrTargetNames.....Clear saved iSCSI iqn target names
--blk <blksize>.....Sets blocksize. Only 512, 1024, 2048, and 4096 blocks are
 supported. The default blocksize is 4096
--ro.....Start iSCSI Targets as read only.
```

The IQN format takes the form 'iqn.yyyy-mm.naming-authority:unique name', where:

- 'yyyy-mm' is the year and month when the naming authority was established. 'naming-authority' is usually reverse syntax of the Internet domain name of the naming authority.
- 'unique name' is any name you want to use, for example, the name of your host.
- The information following the colon must be unique, such as:
  - iqn.2015-05.net.cwnas.iscsi:1
  - iqn.2015-05.net.cwnas.iscsi:2

### Responses

```
ISCSI#<idevY> [is_tgt_en] <status>
idevYISCSI target device iqn.2015-05.net.cwnas.iscsi:Y (Y=ISCSI target
 disk 0,1, or 2)
[is_tgt_en]iSCSI Target Enabled <bool> (0,1)
<status>.....Status <enum> (OK, ERR "<str>")
INVALID<status>
INVALIDCommand parameter(s) invalid
<status>.....Status <str> (ERR "<str>")
ERROR<status>
ERRORCritical error has occurred
<status>.....Status <str> (ERR "<str>")
```

### Example: Determine the iSCSI target status

```

cw_dts> istarget
[istarget]
RMC_S0_P1_L0: iqn.2015-05.net.cwnas.iscsi:rmc0p1 is_tgt_en=1 status=OK
RMC_S0_P2_L0: iqn.2015-05.net.cwnas.iscsi:rmc0p2 is_tgt_en=1 status=OK
[!istarget] OK

```

**NOTE**

See `rmctl --serv` command for information on controlling Ethernet interfaces targets will be available on.

**Example:** Start all the iSCSI targets on the RMC in slot 0.

```
cw_dts> istarget --start -s 0
[istarget]
 RMC_S0_P1_L0: iqn.2015-05.net.cwnas.iscsi:rmc0p1 is_tgt_en=1 status=OK
 RMC_S0_P2_L0: iqn.2015-05.net.cwnas.iscsi:rmc0p2 is_tgt_en=1 status=OK
[!istarget] OK
```

**Example:** Stop all the iSCSI targets on the RMC in slot 0.

```
cw_dts> istarget --stop -s 0
[istarget]
 RMC_S0_P1_L0: iqn.2015-05.net.cwnas.iscsi:rmc0p1 is_tgt_en=0 status=OK
 RMC_S0_P2_L0: iqn.2015-05.net.cwnas.iscsi:rmc0p2 is_tgt_en=0 status=OK
[!istarget] OK
```

## 12.3.15 ledctrl

### Description

The ledctrl command allows the user to set the duty cycle (brightness) of the DTS LEDs. When the duty cycle option is not provided, current duty cycle and on/off state of LEDs is reported. LED 0 is the POWER LED, other LEDs are reserved.

### Syntax

```
ledctrl [-h | --help | --version]
ledctrl [-l ledNum] [-d dutyCycle]
```

### Options

-h, --help ..... Print help message.  
 --version ..... Print program version.  
 -d, --duty <num> ..... Set LED duty cycle (0 - 100%). Duty cycle of 0 will prevent the LED from lighting.  
 -l, --led <str> ..... LED number ('A' for all LEDs: 0,1,2,3,4,5,6,7)

### Example: Status display

```

cw_dts> ledctrl
[ledctrl]
 LED: s0=<s> d0=<d> s1=<s> d1=<d> s2=<s> d2=<d> s3=<s> d3=<d> s4=<s> d4=<d> s5=<s>
 d5=<d> status=<sts>
[!ledctrl] <summary>

```



### NOTE

Line wrap above simulated for viewability

### Line Identifier

LED ..... LED status line

### Fields

s#=<s> ..... State of LED number #  
 d#=<d> ..... Duty cycle setting of LED number #  
 status=<sts> ..... Summary status for the line

### Enumerated types (See above examples in fields)

<s> ..... State of LED. Integer: 0 for off, 1 for on.  
 <d> ..... Duty cycle. Integer: 0 to 100  
 <sts> ..... Status message (OK, ERR <str>)  
 <str> ..... Text string  
 <summary> ..... Command status summary (OK, ERR)

### Example: Set duty cycle of all LEDs to 75%

```

cw_dts> ledctrl -l A -d 75
[ledctrl]
 LED: status=<sts>
[!ledctrl] <summary>

```

## 12.3.16 log



### NOTE

The DTS1 has only 1 RMC slot. As a result, the -s option is always -s 0.

### Description

The log command provides access to the DTS log files. Without options, a list of log files is printed. Without a filename, will list log files that are available for viewing. With filename, will display text of the log file. By default, only the last 100 are shown, but viewing mode can be modified with options.

### Syntax

```
log [-h | --help | --version]
log [-m MODE] FILENAME
```

### Options

```
-h, --help..... Print help message.
--version..... Print program version. List log files.
-M..... Paged using 'more' utility. 'q' to quit.
-L..... Paged using 'less' utility. 'q' to quit.
-A..... All. Unpaged full text dump.
-F..... Follow output with 'tail -f'. Ctrl-C to quit.
--export..... Export log files to an RMC selected by -s.
--archive..... Like --export, but package files in a .tar.gz file.
-s..... Selects RMC used by --export or --archive.
```

### Example: View list of log files

```
cw_dts> log
[log]
<filename>
<filename>
[!log] <summary>
```

### Enumerated types

```
<filename> Name of a log file
<summary> Command status summary (OK, ERR)
```

### Example: View log file pbit.log using paged viewer

```
cw_dts> log -M pbit.log
<file contents>
```



### NOTE

Output of viewer(s) not formalized.

### Example: Export an archive of log files to RMC

```
cw_dts> log --archive -s 1
[log]
LOG: status=<sts>
[!log] <summary>
```

### Line Identifier

```
LOG: Log export status line
```

### Fields

```
status=<sts> Summary status for the line
```

### Enumerated types

```
<sts> Status message (OK, ERR "<str>")
<str> Text string
<summary> Command status summary (OK, ERR)
```

## 12.3.17 mbit



### NOTE

The DTS1 has only 1 RMC slot. As a result, the -s option is always -s 0.

### Description

The mbit command executes maintenance built-in tests.

### Syntax

```
mbit [-h | --help | --version]
```

### Options

-h, --help.....Print help message.  
 --version.....Print program version.  
 -s, --slot.....Slot number where the RMC unit is located. Operations on all slots is prohibited.  
 -p, --pnum.....Partition number. Ranges from 1-128. Operations on all partitions is prohibited.  
 --go.....Required for destructive/disruptive tests.



### CAUTION

DATA LOSS. Use of --disk option will destroy data on the disk

--disk.....Run disk test on RMC in slot <slotNum> or on partition <partnum>.  
 --smart.....View SMART stats for RMC in slot <slotNum>.  
 --eth DEVICE.....Run Ethernet self-tests on DEVICE. DEVICE is one of: eth0, eth1. The interface will be taken offline for this test. Do not perform test on the interface used for the CLI.



### CAUTION

DATA LOSS. Use of --fsck option may destroy data on the disk

--fsck.....Run file system check on RMC in slot <slotNum> or on partition <partnum> on RMC <slotNum>. All --fsck\* options will unmount the RMC/partition.  
 --fsckro.....Read-only version of --fsck.



### CAUTION

DATA LOSS. Use of --fsckauto option may destroy data on the disk

--fsckauto.....Auto-repair version of --fsck. Fixes simple problems without intervention.



### CAUTION

DATA LOSS. Use of --fsckyes option may destroy data on the disk

--fsckyes.....Auto-repair version of --fsck, assuming 'yes' to all repair prompts.



### NOTE

Output of this command is not formalized. For interactive use.

#### Example: Full disk test output data

```

cw_dts> mbit --disk -s 0 --go
[mbit]
===== File is a block device
===== File corresponds to whole disk
dT=14 p=0 Tx=700 Rx=645 tM=141.86 rM=87.49 M=110.24 Ex2=0 Ex=0 LgB=-98.87
[!mbit] OK

```

#### Example: Disk partition test output data

```

cw_dts> mbit --disk -s 0 -p 1 --go
[mbit]
===== File is a block device
===== File corresponds to partition 1 on disk 2
dT=14 p=0 Tx=700 Rx=645 tM=141.86 rM=87.49 M=110.24 Ex2=0 Ex=0 LgB=-98.87
[!mbit] OK

```

**Fields**

dT.....	Elapsed time in seconds
p.....	Pass count. Number of times the full disk has been verified.
Tx.....	Count of transmitted (written) buffers
Rx.....	Count of received (read) buffers
tM.....	Cumulative Tx throughput (timed during write phase only)
rM.....	Cumulative Rx throughput (timed during read/verify phase only)
M.....	Cumulative total throughput (read/write combined)
Ex2.....	Errors other than data errors
Ex.....	Data verification errors
LgB.....	ROUGH representation of the byte error rate exponent

**Example: Disk file system check on RMC 0**

```

cw_dts> mbit --fsckro -s 0 --go
[mbit]
 e2fsck 1.42.9 (28-Dec-2013) /dev/rmc0: clean, 11/30531584 files, 1967964/
 122094592 blocks
S!mbit] OK

```

**Example: Disk file system check on RMC 0 partition 1**

```

cw_dts> mbit --fsckro -s 0 -p 1 --go
[mbit]
 e2fsck 1.42.9 (28-Dec-2013) /dev/rmc0p1: clean, 11/30531584 files, 1967964/
 122094592 blocks
[!mbit] OK

```

**12.3.18 nfsctl****NOTE**

The DTS1 has only 1 RMC slot. As a result, the -s option is always -s 0.

**Description:**

The `nfsctl` command is used to determine the configuration of the NFS exports for both the `/etc/exports` file, and the flags for the `exportfs` command used to dynamically create NFS exports. Those exports are created in two cases. The first is when the NFS server is running, and an RMC/partition is mounted. The second is when an RMC/partition is already mounted, and the NFS server is started,

The default `/etc/exports` file is:

```
/rmc_shares *(rw, fsid=0, sync, no_root_squash, no_all_squash)
```

This is meant to export the top level directory at `/rmc_shares`. RMCs/partitions will be created underneath this top level directory, with these default options:

```
rw, fsid=0, sync, no_root_squash, no_all_squash
```

The default options used for the `exportfs` command are:

```
rw, async, wdelay, root_squash, all_squash, no_subtree_check, anonuid=1000, anongid=1000
```

This is meant to export the RMC/partitions so they belong the user on the DTS1 and the files can be seen can be seen from other services, such as HTTP, FTP, CIFS, etc. that user has access too. Other configurations may be more appropriate, depending on the users intent for the DTS1.

**CAUTION**

**INCORRECT OPERATION.** Be careful to provide a correctly formed string for `<nfsString>`. No error checking is done on it.

**NOTE**

If an RMC/partition is mounted read only, the corresponding export will also be read only, regardless of the options set here.

**NOTE**

The NFS server needs to be restarted for a new `/etc/exports` file to take effect.

**Syntax:**

```
nfsctl [-h | --help | --version]
nfsctl [--exports] <phr>
nfsctl [--exportfs] <phr>
```

**Options:**

```
-h, --help Print help message.
--version Print program version.
--exports, exports <nfsString> Use <nfsString> as the options to the /etc/exports file.
--exportfs, exportfs <nfsString> Use <nfsString> as the options to the exportfs command.
```

**Example: Status command**

```
cw_dts> nfsctl
[nfsctl]
 exports:"rw, fsid=0, sync, no_root_squash, no_all_squash"
 exportfs:"rw, async, wdelay, root_squash, all_squash, no_subtree_check, anonuid=1000, a
nongid=1000"
[!nfsctl] <summary>
```

**Example: Turn off root\_squash command**

```
nfsctl --exportfs "rw, async, wdelay, all_squash, no_subtree_check, anonuid=1000,
anongid=1000"
```

**Example: Turn off autmounting on slot 0 completely command**

```
nfsctl --exports "rw, async, wdelay, root_squash, no_subtree_check"
```



## 12.3.19 ntpdate

### Description

The ntpdate command allows for configuration and retrieval of the time and date from specified list of ntp servers.

### Syntax

```
ntpdate [-h | --help | --version]
ntpdate [--ip <ip>] | [--ip6 <ip6>] | --name <str>]
ntpdate [--clear | --list]
```

### Options>

```
-h, --help.....Print help message.
--version.....Print program version.
-s, --setdateSet the local time and date via NTP
-i, --ip <str>.....IPv4 address of ntp server to add to list
-i6, --ip6 <str>.....IPv6 address of ntp server to add to list
-n, --name <str>.....Host name of ntp server to add to list
-c, --clear.....Clear stored ntp server values
-l, --list.....List stored ntp server values
-p, --poll <sec>.....Poll for time from ntp server
-q, --quitpollQuit polling for time from ntp server
--status.....Print server list and polling status
```

### Example: Set current time and date via NTP

```
cw_dts> ntpdate --setdate
[ntpdate]
 SETDATE: date=<date> time=<time> status=<sts>
[!ntpdate] <summary>
```

### Line Identifier

```
SETDATE.....Reports date/time configuration status
```

### Fields

```
date=<date>Reports system date
time=<time>Reports system time
status=<sts>Summary status for the given line.
```

### Enumerated types:

```
<str>.....Text string
<date>.....System date as month day year (Ex: Aug 2 2014)
<time>.....24-hour system time as Hour:Minute:Second (Ex: 23:05:06)
<sts>.....Status message (OK, ERR "<str>")
<summary>.....Command status summary (OK, ERR)
```



### NOTE

See 'help info' for format of parser and critical execution errors.

### Example: Store ntp server address

```
cw_dts> ntpdate --ip <ip>
[ntpdate]
 STORE: status=<sts>
[!ntpdate] <summary>
```

### Line Identifier

```
STORE.....Reports NTP server list config update status
```

### Fields

```
<ip>.....IPv4 dotted-decimal address (Ex: 10.19.6.6) to be added to NTP
server(s) list
```

**Enumerated types** (See above examples in fields)

**Example: Store ntp server name**

```

cw_dts> ntpdate --name <str>
[ntpdate]
 STORE: status=<sts>
[!ntpdate] <summary>

```

**Line Identifier**

STORE ..... Reports NTP server list config update status

**Fields**

<str> ..... host name of NTP server to be added to NTP server(s) list

**Enumerated types** (See above examples in fields)

**Example: Clear ntp server list**

```

cw_dts> ntpdate --clear
[ntpdate]
 CLEAR: status=<sts>
[!ntpdate] <summary>

```

**Line Identifier**

CLEAR ..... clearing entries from NTP servers list

**Enumerated types** (See above examples in fields)

**Example: List ntp server entries**

```

cw_dts> ntpdate --list
[ntpdate]
 LIST_SERVERS:
 <ip>
 <name>
[!ntpdate] <summary>

```

**Fields**

<name> ..... host name of NTP server

<ip> ..... IP address of NTP server

**Example: configuration status**

```

cw_dts> ntpdate [--status]
[ntpdate]
 STATUS: <sts>
 servers:
 <name>
 <ip>
 Polling for time every <sec> seconds.
[!ntpdate] <summary>

```

**Line Identifier**

STATUS ..... Configuration status

**Fields**

<name> ..... Host name of NTP server

<ip> ..... IP address of NTP server

<sec> ..... Number of seconds to wait before polling NTP server

**Enumerated types** (See above examples in fields)

### 12.3.20 password

#### Description

The password command allows the admin to change the login password. The optional -u option can be provided to change the password for a different login account.

#### Syntax

**password** [-h | --help | --version]  
**password** [-u userName] [-p userPass]

#### Options

- h, --help.....Print help message.
- version.....Print program version.
- u, --user <str>.....Username of account (admin, user)
- p, --pass <str>.....New password.

#### Example: Password change

```

cw_dts> password -u admin -p password
[password]
PASS: status=<sts>
[!password] <summary>

```

#### Line Identifier

PASS.....Password change status line

#### Fields

status=<sts> .....Summary status for the line

#### Enumerated types (See above examples in fields)

- <sts> .....Status message (OK, ERR "<str>")
- <str> .....Text string
- <summary> .....Command status summary (OK, ERR)

## 12.3.21 pcap



### NOTE

The DTS1 has only 1 RMC slot. As a result, the -s option is always -s 0.

### Description

The pcap command controls PCAP recording functions.

### Syntax

```
pcap [-s] -i interface --start filename [--ov][--filter filters]
pcap --stop [-i interface]
pcap [-h | --help | --version]
pcap --peek -i interface
pcap --stat
pcap
```

### Options

```
-h, --help..... Print help message.
--version..... Print program version.
-s, --slot <num>..... Slot number for RMC unit to record to, default 0
-p, --pnum <partnum>.... Partition number for RMC unit within a given slot number
--peek -i <interface>.. Show snippet of traffic from interface.
--start <filename> Start PCAP recording into file. Must be accompanied by --ov if file
 already exists.
--stop [<interface>] Stop PCAP recording on select interface if specified or all if not
 specified.
--stat Get PCAP recorder status. Default action when invoked with no
 parameters.
-i <interface>..... Name of interface to capture data from ex. eth0, eth1, etc.
--ov..... Overwrite file if file exists.
--filter <filters> TCP data filter. Selects which packets will be dumped. If no filter is
 given all packets on the net will be dumped into the file.
 Filter parameter follow standard PCAP format. See PCAP-
 filter for exact syntax.
```

### Example: PCAP recording

```
cw_dts> pcap
[pcap]
 No PCAP recorder active
[!pcap]
```

```
cw_dts> pcap -i eth0 -s 0 --start ch0.pcap
[pcap]
 Start recording on interface eth0 to file /rmc_shares/rmc0/ch0.pcap
 recording started
[!pcap]
```

```
cw_dts> pcap --stat
[pcap]
 PCAP recorder active
 Interface eth0: Recorded 24576 Bytes. (24K) to /rmc_shares/rmc0/ch0.pcap
[!pcap]
```

```
cw_dts> pcap --stop
[pcap]
 Stopping active PCAP recording.
[!pcap]
```

### 12.3.22 reboot

#### Description

The reboot performs a soft reset of the hardware.

#### Syntax

**reboot** [-h | --help | --version]

#### Options

- h, --help ..... Print help message.
- version ..... Print program version.
- now ..... Require option to avoid accidental reboot.

#### Example: Rebooting the DTS

```

cw_dts> reboot --now
[reboot]
 REBOOT: status=<sts>
[!reboot] <summary>

```

#### Line Identifier

REBOOT ..... Reboot status line

#### Fields

status=<sts> ..... Summary status for the line

#### Enumerated types (See above examples in fields)

- <sts> ..... Status message (OK, ERR "<str>")
- <str> ..... Text string
- <summary> ..... Command status summary (OK, ERR)

12.3.23

**rmcctl**



**NOTE**

The DTS1 has only 1 RMC slot. As a result, the -s option is always -s 0.

**Description**

The rmcctl command performs control tasks on the RMCs, such as partitioning, formatting, mounting, and requesting removal. When an action is not requested, the current state is reported.

**Syntax**

```
rmcctl [-h | --help | --version]
rmcctl [-s] [-p] [-M] [-U] [-F] [-C]
```

**Options**

- h, --help..... Print help message.
- version..... Print program version.
- s, --slot..... slot number where the RMC unit is located(0). For all slots, use "A" or "all".
- p, --pnum..... Partition number. Ranges from 1-128. Some operations on all partitions is prohibited.
- P, --part..... Create 1-n partition(s) on the RMC described with --slot.  
 <num parts> Number of partitions on the disk.  
 <part sizes> Size of partitions can be specified as percent of disk or sizes in MiB, MB, GiB, GB, TiB or TB. The minimum size allowed is 100MB. NAS services, iSCSI targets, and PCAP recordings need to be inactive, and the RMC / partitions need to be unmounted to run this command.
- force..... Necessary due to the destructive nature of --part. All services, iSCSI targets, and PCAP recordings need to be inactive, and the RMC / partitions need to be unmounted to run this command.
- W, --wipe..... Destructively clean the disk and any partitions.
- force..... Necessary due to the destructive nature of --wipe. All services, iSCSI targets, and PCAP recordings need to be inactive, and the RMC/partitions need to be unmounted to run this command.
- C, --crypt..... Software encrypt RMC. Passphrase is entered interactively
- D, --dcrypt..... Destructively overwrite S/W encryption information.
- E, --enter..... Gain entry to S/W encrypted RMC. Passphrase is entered interactively.
- X, --exit..... Exit from S/W encrypted RMC.
- F, --format..... Format RMC/partition. May take several minutes.
- force..... Force reformatting of a formatted RMC / partition.
- fs..... Choose either EXT4 (default) or NTFS. NTFS can only be used with partitions and RMC USB adapter to provide compatibility with Windows. This option can only be used with the -F option.
- M, --mount..... Mount RMC/partition.
- ro..... Mount file system. This option can only be used with the -M option.
- U, --unmount..... Unmount RMC/partition.
- S, --scan..... Scan for undetected RMCs.



**CAUTION**

**EQUIPMENT DAMAGE.** The RMC is hot-swappable (remove / install with power applied), however, extreme caution must be used to ensure all ESD handling precautions are followed. Failure to properly handle the RMC will result in equipment damage.

- R, --remove..... Request RMC removal.
- I, --insert..... Undo request for removal (-R).
- status..... Display current state of RMCs.

**--serv** ..... Assign a service name to partition. Valid names are NONE, NAS, iSCSI, and iSCSI/1.



**NOTE**

Each partition in the system needs to have a unique (mntpoint) <name>.

**--mntpoint**..... Assign a mount point <name> to a partition. Limited to 32 characters, and may wrap or truncate depending on CLI terminal type.

**Example: Status display (multi-partition)**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 1 16.0GB NONE 0 na 0 na 0 rmc0p1
RMC_S0: 1 1 1 2 16.0GB NONE 0 na 0 na 0 rmc0p2
RMC_S0: 1 1 1 3 16.0GB NONE 0 na 0 na 0 rmc0p3
RMC_S0: 1 1 1 4 6.40GB NONE 0 na 0 na 0 rmc0p4
[!rmcctl] <summary>

```

**Example: Status display (no partitioning))**

```

cw_dts> rmcctl
[rmcctl]
RMC_S#: ins hcrypt osdr p# size serv scryp osdm fmt mnt rem mntpoint

RMC_S0: 1 1 1 -- 64.0GB ----- 0 na 1 1 0 rmc0
[!rmcctl] <summary>

```

**Line Identifier**

RMC\_S#:..... Current status of RMC in slot "#"

**Fields /Columns**

- ins..... Reports insertion status of RMC (default). 0 = not inserted, 1 = inserted
- hcrypt ..... Reports H/W encryption status 0 = not ready, 1 = ready, na = not detected
- osdr..... Reports raw block device detection status 0 = Raw device not detected, 1 = detected
- p#..... Partition number
- size..... Size of partition
- serv..... Service type
- scryp ..... Reports S/W encryption mode 0 = not encrypted, 1 = encrypted
- osdm..... Reports mapped block device detection status 0 = Mapped device not detected, 1 = detected
- fmt..... Reports file system format status 0 = not formatted, ext4 = formatted ext4, nfs = formatted nfs
- mnt..... Reports file system mount status 0 = not mounted, 1 = mounted, ro = mounted read only
- rem..... Reports removal request status 0 = not requested, RQ = requested, OK = ready for removal

**Enumerated types:**

<summary> ..... Command status summary (OK, ERR)

**Example: Create 2 partitions of size 100Gib and 900Gib.**

```
rmcctl --part 2 100Gib 900Gib --force
```

**Example: Create 3 partitions, using disk percentages: 35, 35, and 20.**

```
rmcctl -P 3 35% 35% 20% --force
```

**Example: Format partition 1 of the RMC.**

```
rmcctl -p 1 -F
```

**NOTE**

RMC / partition must be formatted before mounting.

**Example:** Mount partition 1 of the RMC0.

```
rmcctl -p 1 -M
```

**Example:** Unmount RMC/partition 1 of the RMC in slot 0.

```
rmcctl -s 0 -U
rmcctl -s 0 -p 1 -U
```

**Example:** Software encrypt RMC in slot 0.

```
rmcctl -s 0 -C
```

**Example:** Access S/W encrypted RMC in slot 0.

```
rmcctl -s 0 -E
```

**Example:** Exit from S/W encrypted RMC mode in slot 0.

```
rmcctl -s 0 -X
```

**Example:** Destructively overwrite S/W encryption info on RMC in slot 0.

```
rmcctl -s 0 -D
```

**Example:** Associate RMC slot 0 partition 1 with general NAS use.

```
mcctl -s 0 -p 1 --serv NAS
```

**Example:** Associate RMC slot 0 partition 1 with an iSCSI target available on all the Ethernet interfaces.

```
rmcctl -s 0 -p 1 --serv iSCSI
```

**Example:** Associate RMC slot 0 partition 1 with an iSCSI target available only on Ethernet interface eth0.

```
rmcctl -s 0 -p 1 --serv iSCSI0
```

**Example:** Name the mount point for RMC 0 partition 1 "/rnc\_shares/lancer".

```
rmcctl -s 0 -p 1 --mntpoint lancer
```

**Example:** Perform wipe operation on RMC in slot 0.

```
rmcctl -s 0 --wipe --force
```



## 12.3.24 rmcfree

**NOTE**  
The DTS1 has only 1 RMC slot. As a result, the -s option is always -s 0.

**NOTE**  
The rmcfree information displayed in the CLI help is incorrect. It will be updated in the next DTS software release.

### Description

The rmcfree command displays RMC storage status and usage.

### Syntax

```
rmcfree [-h | --help | --version]
rmcfree [-s]
```

### Options

-h, --help..... Print help message.  
 --version..... Print program version.  
 -s, --slot..... Slot number of an RMC (0, A, all). Default is 'A' for all slots.  
 -p, --pnum..... Partition number (1-128, A, all). Default is 'A' for all partitions.

### Example: Status display

```

cw_dts> rmcfree
[rmcfree]
RMC_F#: det p# fmt mnt size used free used

RMC_F0: 1 1 ext4 1 252G 63M 252G 1
[!rmcfree] <summary>

```

### Line Identifier

RMC\_F#:..... Current disk utilization status of RMC in slot "#"

### Fields

det=<d> ..... Reports if RMC is detected  
 p=<#>..... Number of partitions  
 fmt=<f> ..... File system format  
 mnt=<d> ..... Reports if RMC is mounted  
 size=<sz>..... Size of RMC  
 used=<sz>..... Amount of file system used  
 free=<sz>..... Amount of file system available  
 used=<p> ..... Percentage

### Enumerated types:

<#> ..... Integer showing numerical value  
 <d> ..... Status. 0 = not detected / not mounted, 1 = detected / mounted  
 <f> ..... File system type (ext4, NA)  
 <p> ..... Percentage used. Integer from 0 to 100, or "na".  
 <summary> ..... Command status summary (OK, ERR)  
 <sz> ..... Disk space with unit indicators as powers of 1000. (G - Gigabytes, M - Megabytes, K - Kilobytes). Examples: 46G, 180M. Also, "NA" for not available

### Example: Display storage status and usage of RMC in slot 0 .

```
rmcfree -s 0
```

### Example: Display RMC storage status and usage of partition 1 of the RMC in slot 0..

```
rmcfree -s 0 -p 1
```

### 12.3.25 rmcinfo



**NOTE**

The DTS1 has only 1 RMC slot. As a result, the -s option is always -s 0.

**Description**

The rmcinfo command displays RMC identification and manufacturing data.

**Syntax**

**rmcinfo** [-h | --help | --version]

**rmcinfo** [-s]

**Options**

- h, --help.....Print help message.
- version.....Print program version.
- s, --slot.....Slot number of the target RMC. For all slots, use "A" or "all" (default).
- F.....Force retrieval of info data from RMC. By default, will display from a cached copy.
- n, --name **STRING**.....Set the volume name to STRING.

**Example: Information display (RMC installed)**

```

cw_dts> rmcinfo -s 0
[rmcinfo]
RMC_I0:
 Manufacturer: Curtiss-Wright Controls
 Cage Code: 1P423
 RMC Assembly P/N: <str>
 RMC Assembly S/N: <str>
 RMC Assembly Rev: <str>
 Assembly Date: <str>
 Drive Vendor Name: <str>
 Drive Vendor P/N: <str>
 Drive Vendor S/N: <str>
 Drive Capacity: <str>
 Drive Media Type: <str>
 Volume Name: <str>
[!rmcinfo] <summary>

```

**Enumerated types:**

- <sts> .....Status message (OK, ERR "<str>")
- <str> .....Text string
- <summary> .....Command status summary (OK, ERR)

**Example: Information display (RMC not installed)**

```

cw_dts> rmcinfo -s 2
[rmcinfo]
RMC_I2:
RMC not installed
[!rmcinfo] OK

```

**Example: Set volume name**

```

cw_dts> rmcinfo -s 0 -n "Mission Data"
[rmcinfo]
RMC_I0: action=setname status=<sts>
[!rmcinfo] <summary>

```

**Line Identifier**

RMC\_# ..... Reports status of request for RMC in slot "#"

**Fields**

status=<sts> ..... Summary status for the given line.

**Enumerated types:**

<sts> ..... Status message (OK, ERR "<str>")  
<str> ..... Text string  
<summary> ..... Command status summary (OK, ERR)

### 12.3.26 **rmcpurge**



**NOTE**

The DTS1 has only 1 RMC slot. As a result, the -s option is always -s 0.

**Description**

The rmcpurge command allows the user to purge all data on a selected RMC by issuing an ATA Security Erase or ATA Security Enhanced Erase command to the selected storage device.

**Syntax**

**rmcpurge** [-h | --help | --version]  
**rmcpurge** [-s] [-E | -N]

**Options**

- h, --help..... Print help message.
- version..... Print program version.
- s, --slot..... Slot number of the target RMC (0, A,all). For all slots, use "A" or "all" (default).
- N, --normal..... Issue ATA Security Erase Command.
- E, --enhanced ..... Issue ATA Security Enhanced Erase Command.

**Example:** Enhanced erase of RMC

```

cw_dts> rmcpurge -s A -E
[rmcpurge]
 RMC_P0: status=<sts>
 RMC_P1: status=<sts>
 RMC_P2: status=<sts>
[!rmcpurge] <summary>

```

**Line Identifier**

RMC\_P#..... Reports status of purge request for RMC in slot "#"

**Fields**

status=<sts> ..... Summary status for the given line.

**Enumerated types**

- <sts> ..... Status message (OK, NA, ERR "<str>")
- <str> ..... Text string
- <summary> ..... Command status summary (OK, ERR)

**Example:** Normal erase of RMC in slot 1

```

cw_dts> rmcpurge -s 1 -N
[rmcpurge]
 RMC_P1: status=<sts>
[!rmcpurge] <summary>

```

**12.3.27 rtp****Description**

The rtp command provides controls for starting, stopping and reporting status of RTP video stream recordings. Supports recording of RTP video streams with H.264 encoding and MPEGTS formatting.

**Syntax**

```
rtp [-h | --help | --version]
rtp --start [-s <slot>][-p <part>][-m <dir>][-i <ip>][-P <port>]
 [-S <sdp>] -f <file> [--ov] [-t <sec>]
rtp --stop [-i <ip>][-P <port>][-c <str>][-f <str>]
rtp --stat
```

**Options**

```
-h, --help.....Print help message.
--version.....Print program version.
-s, --slot <num>.....Slot number for RMC unit to record to, default 0.
-p, --pnum <partnum>....Partition number to indicate RMC partition to record to, default 1.
-m, --mntpt <dirname>..Alternate mount point where the recording file is to be stored.
-f, --filename <str>....String indicating the filename to record to.
--ov.....Overwrite file if file exists.
-i, --ip <str>.....IPv4 address of network interface to listen on.
-i6, --ip6 <str>.....IPv6 address of network interface to listen on.
-P, --port <str>.....Interface port to listen on.
-S, --sdp <str>.....String indicating the RTP Session Description Protocol filename.
-t, --segtime <num>.....Time in seconds to record to the filename before creating a new file.
 Each file will be appended with an integer indicating the index of
 the file.
--startStart RTP recording into file. Must be accompanied by --ov if file
 already exists.
--stopStop RTP recording on select interface or filename if specified or all
 if not specified.
--statGet RTP recording status. Default action when invoked with no
 parameters.
```

**Example:** Start video stream capture with IPv4 address and port

```
cw_dts> rtp --start -i 192.168.1.1 -P 1234 -f videoFile
[rtp]
RTP: action=start status=OK
[!rtp] OK
```

**Example:** Start video stream capture with IPv6 address and port

```
cw_dts> rtp --start -i6 fd01::1 -P 5004 -f videoFile
[rtp]
RTP: action=start status=OK
[!rtp] OK
```

**Example:** Start video stream capture using sdp file

```
cw_dts> rtp --start -S rtpChan1.sdp -f videoFile
[rtp]
RTP: action=start status=OK
[!rtp] OK
```

**Example:** Stop specified video using start parameters

```
cw_dts> rtp --stop -i6 fd01::1 -P 5004 -f videoFile
[rtp]
RTP: action=stop status=OK
[!rtp] OK
```

**Example: Stop all video stream capture processes**

```
cw_dts> rtp --stop
[rtp]
RTP: action=stop status=OK
[!rtp] OK
```

**Example: Status example**

```
cw_dts> rtp --stat
[rtp]
RTP: action=stat instances=2 status=OK
RTP_1: ip=fd01::1 port=1234 filename=videoFile1 state=started
RTP_2: ip=fd01::1 port=5004 filename=videoFile2 state=capturing
[!rtp] OK
```

**12.3.28****sens****Description**

The sens command displays DTS voltage and temperature sensor readings.

**Syntax**

```
sens [-h | --help | --version]
```

```
sens [-S] [-T] [-V] [-p PERIOD]
```

**Options**

```
-h, --help.....Print help message.
--version.....Print program version.
-p PERIOD.....Refresh display every PERIOD milliseconds. Ctrl-C to exit.
-S.....View Advantech subset of sensors only
-T.....View Temperature subset of sensors only
-V.....View Voltage subset of sensors only
```

**12.3.29 serv**



**NOTE**

The DTS1 has only 1 RMC slot. As a result, the -s option is always -s 0.

**Description**

The serv command allows the user to set the boot configuration for DTS services and to manually start/stop services. When no options are given, the current boot configuration and active status is displayed for all the services.

**Syntax**

```
serv [-h | --help | --version]
serv [-a] [-n] [-w] [-h] [-f] [-d] [-t]
serv --boot [-a] [-n] [-w] [-h]
```

**Options**

- h, --help ..... Print help message.
- version ..... Print program version.
- B, --boot ..... Apply the settings to the boot-time configuration.
- a, --all <num> ..... All Services
- c, --cifs <num> ..... CIFS Service
- n, --nfs <num> ..... NFS Service
- f, --ftp <num> ..... FTP Service
- w, --http <num> ..... HTTP Read Service
- d, --dhcp <num> ..... DHCP Service
- t, --tftp <num> ..... TFTP Service
- z, --tel <num> ..... Telnet Service
- s, --snmp <num> ..... SNMP Service

**Enumerated type:**

<num> ..... Selects server state. 0=Disable, 1=Enable, 2=Use boot setting

**Example: Status/configuration display**

```

cw_dts> serv
[serv]
 BOOTCFG: cifs=<s> nfs=<s> ftp=<s> http=<s> dhcp=<s> tftp=<s> tel=<s> snmp=<s>
 status=<sts>
 LIVECFG: cifs=<s> nfs=<s> ftp=<s> http=<s> dhcp=<s> tftp=<s> tel=<s> snmp=<s>
 status=<sts>
[!serv] <summary>
```

**Line Identifier**

- BOOTCFG ..... Reports of service states to be applied at boot-up.
- LIVECFG ..... Reports the current operation state of each service.

**Fields**

- cifs=<s> ..... Common Internet File System service state
- nfs=<s> ..... Network File System service state
- ftp=<s> ..... File Transfer Protocol service state
- http=<s> ..... Hypertext Transfer Protocol service state
- dhcp=<s> ..... Dynamic Host Configuration Protocol service state
- tftp=<s> ..... Trivial File Transfer Protocol service state
- tel=<s> ..... Telnet service state
- snmp=<s> ..... Simple Network Management Protocol service state
- status=<sts> ..... Summary status for the line



**NOTE**

The 'status' field appears on the same line as the others. The example output above is line wrapped for clarity.

**Enumerated types:**



<s> ..... Configuration state. 0=Disabled, 1=Enabled, ERR=Unknown  
 <sts> ..... Status (OK, NA, ERR "<str>")  
 <str> ..... Text string  
 <summary> ..... Command status summary (OK, ERR)

**Example: Boot configuration**

```

cw_dts> serv --boot --cifs 1 --nfs 0
[serv]
 BOOTSET: status=<sts>
[!serv] OK

```

**Line Identifier**

BOOTSET ..... Indicates boot configuration update performed

**Fields**

status=<sts> ..... Summary status for the line

**Example: Start/stop servers**

```

cw_dts> serv --cifs 1 --nfs 0 --ftp 1
[serv]
 LIVESET: cifs=1 status=OK
 LIVESET: nfs=0 status=OK
 LIVESET: ftp=1 status=ERR "Failed to start server"
[!serv] ERR

```

**Line Identifier**

LIVASET ..... Indicates change to operational state of server.

**Fields**

<serv>=<s> ..... Indicator of which server is being started/stopped

status=<sts> ..... Status for action (OK, ERR "<str>")

### 12.3.30 shutdown

#### Description

Shutdown halts the DTS operating system.

#### Syntax

**shutdown** [-h | --help | --version]

#### Options

- h, --help ..... Print help message.
- version ..... Print program version.
- now ..... Require option to avoid accidental shutdown.

#### Example: Rebooting the DTS

```

cw_dts> shutdown now
[shutdown]
 SHUTDOWN: status=<sts>
[!shutdown] <summary>
```

#### Line Identifier

SHUTDOWN ..... Shutdown status line

#### Fields

status=<sts> ..... Summary status for the line

#### Enumerated types (See above examples in fields)

- <sts> ..... Status message (OK, ERR "<str>")
- <str> ..... Text string
- <summary> ..... Command status summary (OK, ERR)

### 12.3.31 sysdate

#### Description

The sysdate command allows for configuration and retrieval of the time and date. When no options are given, the current date is printed.

#### Syntax

**sysdate** [-h | --help | --version]  
**sysdate** [-d] [-t]

#### Options

- h, --help.....Print help message.
- version.....Print program version.
- d, --date.....Set date. (Year/Month/Day)
- t, --time.....Set time. (Hour:Minute:Second)

#### Example: View current time and date

```

cw_dts> sysdate
[sysdate]
DATE: date=<date> time=<time> status=<sts>
[!sysdate] <summary>

```

#### Line Identifier

DATE.....Reports the current date and time

#### Fields

- date=<date> .....Reports system date
- time=<time> .....Reports system time
- status=<sts> .....Summary status for the given line.

#### Enumerated types:

- <date> .....System date as year/month/day (Ex: 2012/01/07)
- <time> .....24-hour system time as Hour:Minute:Second (Ex: 23:05:06)
- <sts> .....Status message (OK, ERR "<str>")
- <str> .....Text string
- <summary> .....Command status summary (OK, ERR)

#### Example: Set current time and date

```

cw_dts> sysdate -d 2018/04/01 -t 00:00:01
[sysdate]
SETDATE: status=<sts>
[!sysdate] <summary>

```

#### Line Identifier

SETDATE.....Reports date/time configuration status

#### Fields

- status=<sts> .....Summary status for the given line.


**Enumerated types:** (See above examples in fields)

# Specifications

## A.1 Envelope / Mounting Dimensions

### A.1.1 RMC Module

**NOTE**  
Dimensions are in inches and (millimeters).



DDOC0099-0025

Figure A.1 RMC Module

### A.1.2 Panel Mount

**NOTE**  
 Dimensions are in inches and (millimeters).





Figure A.2 DTS1 (Panel Mount)

### A.1.3 DZUS Fastener Mount

**NOTE**  
Dimensions are in inches and (millimeters).



DDOC0099-0024

Figure A.3 DTS1 (Dzus Mount)

## A.2 DTS1 Specifications

### Physical Dimensions

Height..... 1.50 In. (38.1 mm) chassis  
 Width..... 5.00 In. (127.0 mm) chassis  
 Depth..... 7.99 In. (202.9mm) knob to GND lug.

### Weight:

Without RMC Module ..... 2.60 lb. (1.18 kg)

### Power

Input Power .....28 VDC (MIL-STD 704E)  
 Power Dissipation ..... 14 Watts average with RMC  
 Peak Inrush Current..... 1.3 Amps

## A.3 RMC Module Specifications

### RMC Module Physical Dimensions

Height..... 0.66 In. (16.76 mm)  
 Width..... 3.000 + 0.22 In.rails (76.20 mm +5.59 mm rails)  
 Depth..... 5.000 + 0.390 In. knob (27.0mm +9.9 mm knob)  
 Weight..... 0.7 lb. (0.317kg)

\* RMC module weight dependent on configuration. Weight provided is maximum weight for any RMC module configuration.

### Reliability

Data Reliability ..... <1 non-recoverable error in 10<sup>14</sup> bits read  
 Data Retention ..... >10 years  
 SSD Endurance ..... >100,000 writes

### Capacity

256 GB (unformatted) .....235 GB (formatted)  
 1 TB (Unformatted) .....931 GB (formatted)  
 2 TB (Unformatted) ..... 1.862 TB (formatted)  
 4 TB (Unformatted) ..... 3,725 TB (formatted)  
 8 TB (Unformatted) ..... 7,496 TB (formatted)

## A.4 Mean Time Between Failures

These Mean Time Between Failure (MTBF) values (provided in hours) are calculated using Windchill Quality Solutions Relex 2011 software with MIL-HDBK- 217 FN2 with parts screening / de-rating based on ANSI/VITA 51.1-2008 specifications.

**Table A.1** DTS1 / RMC Calculated Mean Time Between Failures

Order Number	MTBF
VS-DTS1SL-F (L-Bracket Mounting)	
VS-DTS1SL-FD (DZUS Panel Mounting)	
Ground Benign / Controlled @ 30°C	132,906
Ground Mobile @ 30°C	65,687
Naval Sheltered @ 30°C	95,464
Airborne Uninhabited Cargo @ 30°C	55,900
Airborne Uninhabited Fighter @ 30°C	46,984
Airborne Rotary Wing @ 30°C	40,956
VS-RMC8192M-00 (8 TB SSD) and VS-RMC4096M-00 (4 TB SSD)	

**Table A.1** DTS1 / RMC Calculated Mean Time Between Failures

<b>Order Number</b>	<b>MTBF</b>
Ground Benign / Controlled @ 30°C	625,644
Ground Mobile @ 30°C	146,503
Naval Sheltered @ 30°C	230,992
Airborne Uninhabited Cargo @ 30°C	98,205
Airborne Uninhabited Fighter @ 30°C	85,131
Airborne Rotary Wing @ 30°C	69,000
VS-RMC2048M-00 (2TB SSD) VS-RMC1024M-00 (1TB SSD)	
Ground Benign / Controlled @ 30°C	698,477
Ground Mobile @ 30°C	166,876
Naval Sheltered @ 30°C	264,999
Airborne Uninhabited Cargo @ 30°C	117,425
Airborne Uninhabited Fighter @ 30°C	99,206
Airborne Rotary Wing @ 30°C	77,966
VS-RMC256M-00 (256GB SSD)	
Ground Benign / Controlled @ 30°C	517,682
Ground Mobile @ 30°C	117,751
Naval Sheltered @ 30°C	183,815
Airborne Uninhabited Cargo @ 30°C	73,986
Airborne Uninhabited Fighter @ 30°C	66,313
Airborne Rotary Wing @ 30°C	56,097
VS-RMC0000-00 (No SSD)	
Ground Benign / Controlled @ 30°C	1,073,322
Ground Mobile @ 30°C	286,330
Naval Sheltered @ 30°C	474,625
Airborne Uninhabited Cargo @ 30°C	284,406
Airborne Uninhabited Fighter @ 30°C	196,851
Airborne Rotary Wing @ 30°C	127,777

## A.5 Environmental, EMI, Electrical Specifications

The DTS1 CSfC has been tested to the following environmental conditions using the standards, test procedures, and methods indicated below (test reports are available from Curtiss-Wright on request):

- High Temperature - Storage (Non-operational) per MIL-STD-810G, Method 501.5 Procedure I
  - 7 cycles: from 35C 7% RH to 85C 1% RH within 7 hours, maintain 85C 1% RH for 3 hours, to 35C 7% RH within 7 hours and maintain 35C 7% RH for 7 hours. Total of 7 24 hour cycles.
- High Temperature - Operational per MIL-STD-810G, Method 501.5 Procedure II
  - 3 cycles: +71C for 2 hours, +55C for 3 hours, +35C for 3 hours. Total 24 hours.
- Low Temperature - Storage (Non-operational) per MIL-STD-810G, Method 502.5 Procedure I
  - -45C, maintain for 24 hours following temperature stabilization of the test item, rate of temperature change not exceeding 3C per minute.



- Low Temperature - Operational per MIL-STD-810G, Method 502.5 Procedure II
  - -45C for 4 hours
- Temperature Shock per MIL-STD-810G, Method 503.5 Procedure I, Non-operational
  - -45C to +85C, 3 cycles, less than 5 minute transition time
- Temperature Variation per RTCA/DO-160E, Section 5, Category B, Operational
  - -45C to +55C, 10 cycles, no power cycling, > 5degC/min
- Humidity Tropical Exposure per MIL-STD-810G, Method 507.5, Operational
  - 24 hr baseline, 95% Humidity for 48 hrs, +20 to +55C, 5 cycles
- Altitude per MIL-STD-810G, Method 500.5 Procedure II, Operational
  - 0 ft to 20,000 ft, 5000 feet per minute, no hold time required
- Rapid decompression per MIL-STD-810G, Method 500.5 Procedure III, Operational
  - Ambient temperature, pressure at 8,000 feet (10.9 PSIA) then reduce pressure to 40,000 feet (2.73 PSIA) within (15) fifteen seconds. Hold ambient temperature and pressure at 40,000 feet for a period of (10) ten minutes.
- Vibration - Narrowband Random over Broadband Random per MIL-STD-810G, Method 514.6 Procedure I, Operational
  - Category 13 - Aircraft, Propeller, Installed Material vibration environment, Figure 514.6D-2 and Table 514.6D-II, 1 hour per axis
    - 0 = 68 Hz @ L0 = 0.3 g<sup>2</sup>/Hz
    - 1 = 136 Hz @ 0.15 g<sup>2</sup>/Hz
    - 2 = 272 Hz @ 0.075 g<sup>2</sup>/Hz
    - 3 = 544 Hz @ 0.0375 g<sup>2</sup>/Hz
- Vibration Endurance Frequency Sweep per DEF STAN 0035, Part 3, Chapter 2-01, Operational
  - 1 hr frequency sweep (Curve N) at 1 octave per minute in 3 directions
- Crash Landing per MIL-STD-810G, Method 513.6 Procedure III, Pre-Test: Operational, Test: Non-operational, Post-Test: Operational
  - 20g in all directions > 10 seconds
- Acceleration per MIL-STD-810G, Method 513.6, Procedure II, Pre-Test: Operational, Test: Non-operational, Post-Test: Operational
  - Linear 3 seconds from 0g to 5g, remain at 5g for 10 seconds, linear fall back to 0 in 3 seconds. 3 directions
- Operational Shock per MIL-STD-810G, Method 516.6, Procedure I
  - 20g peak, 11 ms wide, 3 shocks in each direction per each axis
- Crash Safety per MIL-STD-810G, Method 516.6, Procedure V, Non-operational
  - 40g peak, 11 ms wide, 2 shocks in each direction per each axis
- Bench Handling per MIL-STD-810G, Method 516.6, Procedure VI, Pre-Test: Operational, Test: Non-operational, Post-Test: Operational
- Salt Fog (Mist) per MIL-STD-810G, Method 509.5 Procedure I, Pre-Test: Operational, Test: Non-operational, Post-Test: Operational
- Explosion Proofness per MIL-STD-810G, Method 511.5, Procedure I, Operational
  - 15,000 feet
- EMI/EMC per MIL-STD-461G
  - CE101 - Conducted Emissions, Power Leads, 30 Hz to 10 kHz
  - CE102 - Conducted Emissions, Power Leads, 10 kHz to 10 MHz
  - RE101- Radiated Emissions, Magnetic Field, 30 Hz to 100 kHz
  - RE102 - Radiated Emissions, Electric Fields, 2 MHz to 18 GHz
  - CS101 - Conducted Susceptibility, Power Leads, 30 Hz to 150 kHz
  - CS114 - Conducted Susceptibility, Bulk Cable Injection, 10 kHz to 200 MHz, Curve 5
  - CS115 - Conducted Susceptibility, Bulk Cable Injection, Impulse Excitation

- CS116 - Conducted Susceptibility, Damped Sinusoid Transients, Cables and Power Leads, 10 kHz to 100 MHz
- RS101 - Radiated Susceptibility, Magnetic Fields, 30 Hz to 100 kHz
- RS103 - Radiated Susceptibility, Electric Fields, 2 MHz to 18 GHz, 200 Volts/meter
- Electrical Power per MIL-STD-704F
  - Normal, Aircraft Electrical Operation
    - LDC101 Load Measurements
    - LDC102 Steady State Limits for Voltage
    - LDC103 Voltage Distortion Spectrum
    - LDC104 Total Ripple
    - LDC105 Normal Voltage Transients
  - Transfer, Aircraft Electrical Operation
    - LDC201 Power Interrupt Abnormal, Aircraft Electrical Operation
    - LDC301 Abnormal Steady State Limits for Voltage
    - LDC302 Abnormal Voltage Transients (Overvoltage/Undervoltage)
  - Emergency, Aircraft Electrical Operation
    - LDC401 Emergency Limits for Voltage Starting, Aircraft Electrical Operation
    - LDC501 Starting Voltage Transients
  - Power Failure, Aircraft Electrical Operation
    - LDC601 Power Failure
    - LDC602 Polarity Reversal
- ESD per RTCA/DO-160E, Section 25
  - 10 ESD discharges of +15000V and -15000V at each knob or connector (4 places) Operational

The DTS1 has been designed to meet the following environmental conditions:

- Water Proofness per MIL-STD-810G, Method 506.5, Procedure III
- Mold Growth (Fungus) per MIL-STD-810F, Method 508.5
- Contamination by Fluids per MIL-STD-810F, Method 504.1
- Blowing Dust per MIL-STD-810F, Method 510.5, Procedure I
- Ice Formation per MIL-STD-810G, Method 521.3
- Flammability per RTCA/DO-160E, Section 26, Fire, Category C

# Connectors / Cables

The Glenair Series 801 Mighty Mouse Connectors feature double-start ACME threads with anti-decoupling spring or ratchet and provide fast mating requiring only 1-½ turns to fully engage.

## B.1 Power Connector J1 / Power Lab Cable



**NOTE**


The EMI / safety ground on J1 pin 4 is isolated from the +28VDC\_RTN line within the DTS1. This isolation should be maintained. All +28VDC power return current must be carried on +28VDC\_RTN line and not the EMI / safety ground.

Table B.1 provides DTS1 bulkhead J1 connector pin signals. Figure B.1 show the DTS1 bulkhead J1 connector pinout. Table B.2 shows the DTS1 power lab cable connection pin signals. Figure B.1 show the power lab cable wiring diagram.

Connector Manufacturer: Glenair  
 Connector Reference Designator: J1  
 Connector..... PN 801-023-07M9-4PA  
 Mating Connector PN 801-007-16M9-4SA

**Table B.1 Power Connector J1 Signals**


Connector Pin	Signal Name	Signal Type	Direction	Description / Functions
1	28V DC	Analog	In	Main 28VDC Power Input
2	28 VDC RTN	Analog	Out	Main 28VDC Power RTN
3	Power Disable	Analog	In	DTS1 power off control. Short to +28VDC_RTN to turn off the DTS1
4	EMI GND	Analog		EMI / Safety Ground



**Figure B.1 Power Connector J1**

**Table B.2 Power Lab Cable (VS-DTS1PWRCAB-0)**

Connector Description	Mates With / Signal Name
P1	DTS1 J1
P2 Banana Plug - Red	28 VDC
P3 Banana Plug - Black	28 VDC RTN
P4 Banana Plug - Green	Chassis Ground
J1 3.5mm Audio Jack Tip	28VDC RTN
J1 3.5mm Audio Jack Ring	PWR DISABLE – Short to +28 VDC RTN to power off DTS1



DDOC0099-0036

**Figure B.2 Power Lab Cable Diagram**

## B.2 Utility Connector J2 / Utility Lab Cable

Table B.3 provides DTS1 bulkhead J2 connector pin signals. Figure B.3 show the DTS1 bulkhead J2 connector pinout. Table B.4 shows the DTS1 utility lab cable connection pin signals. Figure B.4 show the utility lab cable wiring diagram.

Connector Manufacturer Glenair  
 Connector Reference Designator J2  
 Connector.....PN 801-023-07M9-19PA  
 Mating ConnectorPN 801-007-16M9-19SA

**Table B.3 Utility Connector J2 Signals**

Connector Pin	Signal Name	Signal Type	Direction	Description / Functions
1	ZEROIZE_N	Analog	In	Active low open collector/switch closure to induce Zeroization of DTS. This signal must be active for a minimum of 5 seconds for the zeroization process to take affect.
2	RST_IN_N	Analog	In	Active low external reset input. Short to GND to invoke DTS reset.
3	GND	Analog		Signal return/GND for ZEROIZE_N and RST_IN_N
4	GND	Analog		NC
5	NASP_RXD	RS-232	In	NAS Processor Serial Port Receive I/F
6	GND	Analog		Signal return/GND for NASP_RXD and NASP_TXD
7	BI_DA1-	GbE	In / Out	Gigabit Ethernet Bi-directional pair A1+/-
8	BI_DD1+	GbE	In / Out	Gigabit Ethernet Bi-directional pair D1+/-
9	GND	Analog		NC
10	NASP_TXD	RS-232	Out	NAS Processor Serial Port Transmit I/F
11	GND	Analog		NC
12	BI_DA1+	GbE	In / Out	Gigabit Ethernet Bi-directional pair A1+/-
13	BI_DD1-	GbE	In / Out	Gigabit Ethernet Bi-directional pair D1+/-
14	GND	Analog		NC
15	GND	Analog		NC
16	BI_DB1-	GbE	In / Out	Gigabit Ethernet Bi-directional pair B1+/-
17	BI_DC1+	GbE	In / Out	Gigabit Ethernet Bi-directional pair C1+/-
18	BI_DC1-	GbE	In / Out	Gigabit Ethernet Bi-directional pair C1+/-
19	BI_DB1+	GbE	In / Out	Gigabit Ethernet Bi-directional pair B1+/-




Figure B.3 Utility Connector J2

Table B.4 Utility Lab Cable (VS-DTS1ETHCAB-J2)

Connector Description	Mates With / Signal Name
P1	DTS1 J2
P2 TIA/EIA-568B Modular Plug	Gigabit Ethernet TIA/EIA-568B Modular Jack
J1 D-sub DE-9 Female/Socket	RS-232 Pin 2: DTS1 transmit Pin 3: DTS1 receive Pin 5: GND
J2 3.5mm Audio Jack Tip	ZEROIZE – Short to GND to ZEROIZE Crypto Keys. This signal must be active for a minimum of 5 seconds for the zeroization process to take affect.
J2 3.5mm Audio Jack Ring	RESET – Short to GND to reset DTS1
J2 3.5mm Audio Jack Shield	GND




Figure B.4 Utility Lab Cable Diagram


### B.3 Ethernet Connector J3 / Ethernet Lab Cable

Table B.5 provides DTS1 bulkhead J3 connector pin signals. Figure B.5 show the DTS1 bulkhead J3 connector pinout. Table B.6 shows the DTS1 Ethernet lab cable connection pin signals. Figure B.6 show the utility lab cable wiring diagram.

Connector Manufacturer Glenair  
 Connector Reference Designator J3  
 Connector.....PN 801-023-07M9-19PB  
 Mating Connector PN 801-007-16M9-19SB

**Table B.5 Ethernet Connector J3 Signals**

Connector Pin	Signal Name	Signal Type	Direction	Description / Functions
1				
2				
3	GND	Analog		NC
4	GND	Analog		NC
5				
6	GND	Analog		NC
7	BI_DA2-	GbE	In / Out	Gigabit Ethernet Bi-directional pair A2+/-
8	BI_DD2+	GbE	In / Out	Gigabit Ethernet Bi-directional pair D2+/-
9	GND	Analog		NC
10				
11	GND	Analog		NC
12	BI_DA2+	GbE	In / Out	Gigabit Ethernet Bi-directional pair A2+/-
13	BI_DD2-	GbE	In / Out	Gigabit Ethernet Bi-directional pair D2+/-
14	GND	Analog		NC
15	GND	Analog		NC
16	BI_DB2-	GbE	In / Out	Gigabit Ethernet Bi-directional pair B2+/-
17	BI_DC2+	GbE	In / Out	Gigabit Ethernet Bi-directional pair C2+/-
18	BI_DC2-	GbE	In / Out	Gigabit Ethernet Bi-directional pair C2+/-
19	BI_DB2+	GbE	In / Out	Gigabit Ethernet Bi-directional pair B2+/-



DDOC0099-0041

**Figure B.5 Ethernet Connector J3**

**Table B.6 Ethernet Lab Cable (VS-DTS1ETHCAB-J3)**

Connector Description	Mates With / Signal Name
P1	DTS1 J3
P2 – TIA/EIA-568B Modular Plug	Gigabit Ethernet TIA/EIA-568B Modular Jack




Figure B.6 Ethernet Lab Cable Wiring Diagram

## B.4 Ground Cable



**NOTE**

Do not loosen nut / washer installed on ground stud E1. Ensure nut / washer on ground stud remain properly tightened when installing / removing ground cable.



**NOTE**

It is recommended that the grounding cable used be a flat, braided, low impedance cable and be as short as possible.

To ensure proper grounding of the DTS1, a ground cable, split lock washer, and hex nut are required, but not provided. The ground cable (Figure B.7) terminal is installed on the DTS1 ground stud E1. The hex nut and split lock washer used to secure the ground cable terminal to ground stud E1 should be torqued to 15 in. lb. to ensure proper connection.




Figure B.7 DTS1 Ground Connection

DDOC0099-0047

# Ordering Information

## C.1 DTS1 / RMC Module / Lab Cables

This appendix contains the ordering numbers for the DTS1 CSfC chassis (Table C.1), RMC module (Table C.2), lab cables (Table C.3), and crypto battery (Table C.4). For an up to date list, or for inquiries about these products, contact Curtiss-Wright Defense Solutions Sales at <http://www.cwodefensesolutions.com/sales.html>.

**Table C.1 DTS1 CSfC Chassis**

Order Number	Description
VS-DTS1SL-F	DTS1 Chassis Without RMC Module (L Bracket Mount)
VS-DTS1SL-FD	DTS1 Chassis Without RMC Module (DZUS Panel Mount)

**Table C.2 RMC Module**

Order Number	Description
VS-RMC8192M-00	RMC, 8 TB
VS-RMC4096M-00	RMC, 4 TB
VS-RMC2048M-00	RMC, 2 TB
VS-RMC1024M-00	RMC, 1 TB
VS-RMC256M-00	RMC, 256 GB
VS-RMC0000-00	RMC, empty cartridge

**Table C.3 DTS1 Lab Cables**

Order Number	Description
VS-DTS1PWRCAB-0	DTS1 Power Lab Cable
VS-DTS1ETHCAB-J2	DTS1 Utility Lab Cable
VS-DTS1ETHCAB-J3	DTS1 Ethernet Lab Cable

**Table C.4 DTS1 Battery**

Order Number	Description
VS-DTS1SL-Battery	DTS1 Battery Module